

Ford**Transit**
Owner's handbook

Feel the difference



The information contained in this publication was correct at the time of going to print. In the interest of development the right is reserved to change specifications, design or equipment at any time without notice and without incurring any obligations. This publication, or part thereof, may not be reproduced nor translated without our approval. Errors and omissions excepted.

© Ford Motor Company 2009

All rights reserved.

Part number: 9C1J-19A321-DA (CG3527en) 05/2009 20090604133655



Mixed Sources

Product group from well-managed
forests, controlled sources and
recycled wood or fiber
www.fsc.org Cert no. SGS-COC-2452
© 1996 Forest Stewardship Council

Table of contents

Introduction

About this handbook.....	5
Symbols glossary.....	5
Parts and accessories.....	5

Quick start

Quick start.....	6
------------------	---

Occupant protection

Principle of operation.....	13
Fastening the seat belts.....	14
Seat belt height adjustment.....	15
Using seat belts during pregnancy.....	16
Disabling the passenger airbag.....	16

Keys and remote controls

General information on radio frequencies.....	18
Programming the remote control.....	18

Locks

Locking and unlocking.....	19
----------------------------	----

Engine immobiliser

Principle of operation.....	23
Coded keys.....	23
Arming the engine immobiliser.....	23
Disarming the engine immobiliser.....	23

Alarm

Principle of operation.....	24
Arming the alarm.....	24
Disarming the alarm.....	25

Steering wheel

Audio control.....	26
Voice control.....	27

Wipers and washers

Windscreen wipers.....	28
Autowipers.....	28
Windscreen washers.....	29
Rear window wiper and washers.....	29
Checking the wiper blades.....	30
Changing the wiper blades.....	30

Lighting

Lighting control.....	31
Autolamps.....	32
Front fog lamps.....	32
Rear fog lamps.....	32
Headlamp levelling.....	33
Hazard warning flashers.....	33
Direction indicators.....	33
Interior lamps.....	33
Stepwell lamps.....	34
Changing a bulb.....	34
Bulb specification chart.....	42

Windows and mirrors

Electric windows.....	44
Exterior mirrors.....	44
Electric exterior mirrors.....	44
Sliding windows.....	45
Rear quarter windows.....	45

Instruments

Gauges.....	46
Warning lamps and indicators.....	48
Audible warnings and indicators.....	52

Information displays

General information.....	53
Information messages.....	55
Personalised settings.....	57

Table of contents

Climate control

Principle of operation.....	60
Air vents.....	60
Manual climate control.....	61
Heated windows and mirrors.....	63
Auxiliary heater.....	63

Seats

Sitting in the correct position.....	67
Front seats.....	67
Rear seats.....	69
Head restraints.....	70
Heated seats.....	71

Convenience features

Clock.....	72
Ticket holders.....	72
Cigar lighter.....	72
Ashtray.....	73
Auxiliary power sockets.....	73
Cup holders.....	73
Storage compartments.....	74
Bottle holder.....	74
Auxiliary input (AUX IN) socket.....	75
Floor mats.....	75

Starting the engine

General information.....	76
Starting a petrol engine.....	76
Starting a diesel engine.....	77
Diesel particulate filter (DPF).....	77
Switching off the engine.....	78

Fuel and refuelling

Safety precautions.....	79
Fuel quality - Petrol.....	79
Fuel quality - Diesel.....	79
Catalytic converter.....	79
Fuel filler flap.....	80

Refuelling.....	80
Fuel consumption.....	80
Technical specifications.....	81

Transmission

Manual transmission.....	85
All-wheel drive (AWD).....	85

Brakes

Principle of operation.....	86
Hints on driving with ABS.....	86
Parking brake.....	86

Stability control

Principle of operation.....	87
Using stability control.....	87

Hill start assist

Principle of operation.....	89
Using hill start assist.....	89

Traction control

Principle of operation.....	91
Using traction control.....	91

Parking aid

Principle of operation.....	92
Using the parking aid.....	92

Rear view camera

Principle of operation.....	94
Using the rear view camera.....	94

Cruise control

Principle of operation.....	98
Using cruise control.....	98

Table of contents

Automatic speed limiter (ASL)

Principle of operation.....	100
-----------------------------	-----

Load carrying

General information.....	101
Load retaining fixtures.....	101
Roof racks and load carriers.....	103

Towing

Towing a trailer.....	104
-----------------------	-----

Driving hints

Running-in.....	105
Cold weather precautions.....	105
Reduced engine performance.....	105

Emergency equipment

First aid kit.....	106
Warning triangle.....	106
Emergency exit.....	106

Status after a collision

Fuel cut-off switch.....	107
Inspecting safety system components.....	107

Fuses

Fuse box locations.....	108
Changing a fuse.....	110
Fuse specification chart.....	110

Vehicle recovery

Towing points.....	119
Towing the vehicle on four wheels.....	119
Towing the vehicle on four wheels - AWD.....	120

Maintenance

General information.....	121
--------------------------	-----

Opening and closing the bonnet.....	122
Engine compartment overview - 2.3L Duratec-HE (M14).....	123
Engine compartment overview - 2.2L Duratorq-TDCi (Puma) Diesel.....	124
Engine compartment overview - 3.2L Duratorq-TDCi (Puma) Diesel/2.4L Duratorq-TDCi (Puma) Diesel.....	126
Engine oil dipstick - 2.3L Duratec-HE (M14).....	127
Engine oil dipstick - 2.2L Duratorq-TDCi (Puma) Diesel.....	127
Engine oil dipstick - 3.2L Duratorq-TDCi (Puma) Diesel/2.4L Duratorq-TDCi (Puma) Diesel.....	127
Engine oil check.....	127
Engine coolant check.....	128
Brake and clutch fluid check.....	129
Power steering fluid check.....	129
Draining the fuel filter water trap.....	129
Fuel filter service indicator check.....	130
Washer fluid check.....	131
Technical specifications.....	131

Vehicle care

Cleaning the exterior.....	134
Cleaning the interior.....	134
Repairing minor paint damage.....	135

Vehicle battery

Using booster cables.....	136
Changing the vehicle battery.....	137
Battery connection points.....	137

Child safety

Child seats.....	138
Child seat positioning.....	139
Booster cushions.....	141
ISOFIX anchor points.....	142
Child safety locks.....	142

Table of contents

Wheels and tyres

General information.....	144
Changing a road wheel.....	144
Tyre repair kit.....	151
Tyre care.....	155
Using winter tyres.....	156
Using snow chains.....	156
Technical specifications.....	157

Vehicle identification

Vehicle identification plate.....	164
Vehicle identification number (VIN).....	164

Technical specifications

Technical specifications.....	165
-------------------------------	-----

Telephone

General information.....	178
Telephone setup.....	178
Bluetooth setup.....	179
Telephone controls.....	180
Using the telephone - Vehicles Without: Navigation System.....	180
Using the telephone - Vehicles With: Navigation System.....	183

Voice control

Principle of operation.....	185
Using voice control.....	185
Audio unit commands.....	186
Telephone commands.....	192
Navigation system commands.....	196

Appendices

Type approvals.....	197
Electromagnetic compatibility.....	197

Introduction

ABOUT THIS HANDBOOK

Thank you for choosing Ford. We recommend that you take some time to get to know your vehicle by reading this handbook. The more that you know about it, the greater the safety and pleasure you will get from driving it.

WARNING



Always drive with due care and attention when using and operating the controls and features on your vehicle.

Note: *This handbook describes product features and options available throughout the range, sometimes even before they are generally available. It may describe options not fitted to your vehicle.*

Note: *Always use and operate your vehicle in line with all applicable laws and regulations.*

Note: *Pass on this handbook when selling your vehicle. It is an integral part of the vehicle.*

SYMBOLS GLOSSARY

Symbols in this handbook

WARNING



You risk death or serious injury to yourself and others if you do not follow the instructions highlighted by the warning symbol.

CAUTION



You risk damaging your vehicle if you do not follow the instructions highlighted by the caution symbol.

Symbols on your vehicle



When you see these symbols, read and follow the relevant instructions in this handbook before touching or attempting adjustment of any kind.


PARTS AND ACCESSORIES

Genuine Ford parts and accessories have been designed specifically for your vehicle. Unless we have specifically stated, we have not tested non-Ford parts and accessories and, therefore, we will not guarantee that they are suitable for your vehicle. We recommend that you ask your Ford Dealer for advice on parts and accessories suitable for your vehicle.

Quick start

QUICK START


Instrument panel overview - left-hand drive



E70781

Quick start

Instrument panel overview - right-hand drive



E76166


- A Electric exterior mirror switch. See **Electric exterior mirrors** (page 44).
- B Lighting control. See **Lighting control** (page 31).
- C Multifunction lever. See **Direction indicators** (page 33). See **Lighting control** (page 31).
- D Instrument cluster. See **Gauges** (page 46).
- E Clock.
- F Hazard warning flasher switch. See **Hazard warning flashers** (page 33).
- G Heated windscreen switch. See **Heated windows and mirrors** (page 63).
- H Heated rear window switch. Heated exterior mirrors switch. See **Heated windows and mirrors** (page 63).
- I Tray with cup holders. See **Cup holders** (page 73).
- J Audio unit. See separate handbook.
- K Air vents. See **Air vents** (page 60).
- L Cigar lighter. See **Cigar lighter** (page 72).

Quick start


- M Climate controls. See **Climate control** (page 60).
- N Gear lever. See **Manual transmission** (page 85).
- O Passenger airbag deactivation warning lamp. See **Disabling the passenger airbag** (page 16).
- P All wheel drive (AWD) switch. See **All-wheel drive (AWD)** (page 85). Stability control (ESP) switch. See **Stability control** (page 87).
- Q Wiper lever. See **Wipers and washers** (page 28).
- R Ignition switch.
- S Horn.
- T Headlamp levelling control. See **Headlamp levelling** (page 33).
- U Cup holder. See **Cup holders** (page 73).

Quick start

Information displays




E73982



E73265

Use the rotary control to scroll through the menu.



E73266

Press the **SET and RESET** button to select a sub-menu or the item that you want to adjust.

See **Information displays** (page 53).

Warning lamps and indicators



Brake pad wear warning lamp



Brake system warning lamp



Cruise control indicator



Hill start assist indicator



Message indicator lamp



Stability control (ESP) and traction control warning lamp



Service interval indicator lamp (vehicles with a diesel engine)



Shift indicator

Quick start




Water-in-fuel indicator lamp
(vehicles with a diesel engine)

See **Warning lamps and indicators**
(page 48).

Locking and unlocking


Rear doors



E71287

- A Unlock or open
- B Lock
- C White visible, door locked


Sliding door



E71289

- A Van and Kombi
- B Bus
- C Lock
- D Unlock

Double rear doors




E71290

- A Outside
- B Inside

Quick start

Tailgate



E71292

- A Outside
- B Inside

Locking system operation


The locking system of your vehicle may have been configured to operate in one of three main lock operation combinations.

See **Locking and unlocking** (page 19).

Auxiliary power sockets

CAUTION

 If you use the auxiliary power socket when the engine is not running, the battery may discharge.



E69125

See **Auxiliary power sockets** (page 73).


Engine idle speed after starting

The engine may idle at a higher speed than normal immediately after starting from cold.

See **Starting the engine** (page 76).

Manual transmission

Selecting reverse gear



E99067

On some vehicles it is necessary to raise the collar whilst selecting reverse gear.

See **Manual transmission** (page 85).

Diesel particulate filter (DPF)

WARNING



Do not park or idle your vehicle over dry leaves, dry grass or other combustible materials. The DPF regeneration process creates very high exhaust gas temperatures and the exhaust will radiate a considerable amount of heat during and after DPF regeneration, and after you have switched the engine off. This is a potential fire hazard.

See **Diesel particulate filter (DPF)** (page 77).

Occupant protection

PRINCIPLE OF OPERATION

Airbags

WARNINGS



Do not modify the front of your vehicle in any way. This could adversely affect deployment of the airbags.



Original text according to ECE R94.01: Extreme Hazard! Do not use a rearward facing child restraint on a seat protected by an air bag in front of it!



Wear a seat belt and keep sufficient distance between yourself and the steering wheel. Only when you use the seat belt properly, can it hold you in a position that allows the airbag to achieve its optimum effect. See **Sitting in the correct position** (page 67).



Have repairs to the steering wheel, steering column, seats, airbags and seat belts carried out by properly trained technicians.



Keep the areas in front of the airbags free from obstruction. Do not affix anything to or over the airbag covers.



Do not poke sharp objects into areas where airbags are fitted. This could damage and adversely affect deployment of the airbags.




Use seat covers designed for seats with side airbags. Have these fitted by properly trained technicians.

Note: You will hear a loud bang and see a cloud of harmless powdery residue if an airbag deploys. This is normal.

Note: The front passenger airbag protects both positions of a double seat.

Note: Only wipe airbag covers with a damp cloth.

Driver and front passenger airbags




E68581

The driver and front passenger airbags will deploy during significant frontal collisions or collisions that are up to 30 degrees from the left or the right. The airbags will inflate within a few thousandths of a second and deflate on contact with the occupants, thus cushioning forward body movement. During minor frontal collisions, overturns, rear collisions and side collisions, the driver and front passenger airbags will not deploy.

Occupant protection

Side airbags



E68905

Side airbags are fitted inside the seatback of the front seats. A label indicates that side airbags are fitted to your vehicle.

The side airbags will deploy during significant lateral collisions. Only the airbag on the side affected by the collision will deploy. The airbags will inflate within a few thousandths of a second and deflate on contact with the occupants, thus providing protection for the head and rib areas. During minor lateral collisions, overturns, front collisions and rear collisions, the side airbags will not deploy.

Seat belts

WARNINGS

 Wear a seat belt and keep sufficient distance between yourself and the steering wheel. Only when you use the seat belt properly, can it hold you in a position to achieve its optimum effect. See **Sitting in the correct position** (page 67).

 Use a seat belt for only one person.


 Use the correct buckle for each seat belt.

WARNINGS

-  Do not use a seat belt that is slack or twisted.
-  Do not wear thick clothing. The seat belt must fit tightly around your body to achieve its optimum effect.
-  Position the shoulder strap of the seat belt over the centre of your shoulder and position the lap strap tightly across your hips.

Seat belt pretensioners have a lower deployment threshold than the airbags. During minor collisions, it is possible that only the seat belt pretensioner will deploy.

FASTENING THE SEAT BELTS



E68584


Occupant protection

SEAT BELT HEIGHT ADJUSTMENT

Front seat belt




E68585



E68901

Rear seat belt



E68586


WARNING



Insert the tongue into the buckle until you hear a distinct click. You have not fastened the seat belt properly if you do not hear a click.

Pull the seat belt out steadily. It may lock if you pull it sharply or if the vehicle is on a slope.

Press the red button on the buckle to release the seat belt. Let it retract completely and smoothly.



E73074


WARNING



Make sure that the seat belt runs smoothly through the guide.

Occupant protection

USING SEAT BELTS DURING PREGNANCY



E68587

WARNING

 Position the seat belt correctly for your safety and that of your unborn child. Do not use only the lap strap or the shoulder strap.

Position the lap strap comfortably across your hips and low beneath your pregnant abdomen. Position the shoulder strap between your breasts, above and to the side of your pregnant abdomen.

DISABLING THE PASSENGER AIRBAG

WARNING

 To avoid the risk of death or serious injury, **NEVER** use a rearward facing child restraint in the front, unless the airbag is **OFF**.




E71313

The key switch and the airbag deactivation lamp are located in the instrument panel.

If the airbag warning lamp in the instrument cluster illuminates intermittently, it means that there is a malfunction. Remove the child restraint from the front. Have the system checked by a suitably trained technician for your own safety. See **Warning lamps and indicators** (page 48).

Disabling the passenger airbag



E71312

To use a child restraint in the front, make sure that the key switch is turned to position **A**.

When you switch the ignition on, check that the passenger airbag deactivation warning lamp comes on. See **Quick start** (page 6).

Occupant protection

Enabling the passenger airbag

WARNING



For the adult restraint system to perform as intended, make sure that the airbag is **ON**.

After removing the child restraint from the front, make sure that you turn the key switch to position **B**.

Keys and remote controls

GENERAL INFORMATION ON RADIO FREQUENCIES

CAUTION



The radio frequency used by your remote control can also be used by other short distance radio transmissions (e.g. amateur radios, medical equipment, wireless headphones, remote controls and alarm systems). If the frequencies are jammed, you will not be able to use your remote control. You can lock and unlock the doors with the key.

Note: *You could unlock the doors if you press the buttons on the remote control unintentionally.*

The operating range between your remote control and your vehicle varies depending on the environment.

PROGRAMMING THE REMOTE CONTROL

You can programme a maximum of eight remote controls to use with your vehicle (including any supplied with your vehicle). Ask your dealer for instructions.

Locks

LOCKING AND UNLOCKING

Double locking

WARNING




Do not activate double locking when persons or animals are inside the vehicle. You will not be able to unlock the doors from the inside if you have double locked them.

Double locking is a theft protection feature that prevents someone from opening the doors from the inside. You can only double lock the doors if they are all closed. If you try to double lock the doors when a door is still open, you may hear a short tone from the horn and the locks will cycle. The door locks will return to their previous state.

If you have double locked the doors successfully, the direction indicators will flash **twice**. If the hazard warning flashers are on, the direction indicators will give two long flashes.

Locking and unlocking the doors with the key



E71294

A Unlock


B Lock

Double locking the doors with the key

Turn the key to the unlock position and then to the lock position to double lock the doors.

Locks

Locking and unlocking the doors with the remote control



E71293

- A Lock
- B Unlock
- C Cargo unlock


Press the appropriate button **once**.

Double locking the doors with the remote control

Press the lock button **twice**.

Locking and unlocking the doors with the handles

Front doors




E71286

- A White mark
- B Lock
- C Unlock

If you see the white mark, the door is locked.

Rear doors




E71287

- A Unlock or open
- B Lock
- C White mark

If you see the white mark, the door is locked.

Sliding door




E71289

- A Van and Kombi
- B Bus

Locks

- C Lock
- D Unlock

Double rear doors




E71290

- A Outside
- B Inside



E71291

Tailgate



E71292

- A Outside
- B Inside

Access the release button through the aperture at the bottom of the tailgate.

Slam locking

Note: Do not leave your keys in the vehicle.

Note: You may hear a short tone from the horn if you try to lock the doors when a door is still open.

Slam locking allows you to lock a door with the key or remote control with the door open. The door will be locked when it is closed.

Automatic locking

Note: Your dealer can permanently disable this function if required.

The doors will lock automatically when you exceed 8 km/h (5 mph). Unlock the doors with the interior handle.

Automatic re-locking

The doors will re-lock automatically if you do not open a door within 45 seconds of unlocking the doors with the remote control. The door locks and the alarm will return to their previous state.

Locks

One-stage unlocking

Note: *The direction indicators will flash once when you unlock the doors.*

When enabled, the following features are available:

You will unlock all of the doors when you:

- pull either interior handle (except if you have double locked the doors).
- turn the key in either of the door locks.
- press the unlock button on the remote control **once**.
- press the cargo unlock button on the remote control **once** (Chassis Cab).

You will unlock the rear doors or tailgate and the sliding door if you press the cargo unlock button **once**.

Two-stage unlocking

Note: *The direction indicators will flash once when you unlock the doors.*

You will unlock the front doors when you:

- pull either interior handle (except if you have double locked the doors).
- turn the key in either of the door locks.
- press the unlock button on the remote control **once** (Van, Bus and Kombi).

You will unlock the driver side door when you:

- press the unlock button on the remote control **once** (Chassis Cab).

You will unlock the front doors, rear doors and loadspace doors when you:

- turn the key in either of the front door locks **twice** within three seconds.
- press the unlock button on the remote control **twice** within three seconds.

On Van vehicles, you will unlock the rear doors or tailgate and the sliding door if you press the cargo unlock button **once**.

On Chassis Cab vehicles, you will unlock the passenger side door if you press the cargo unlock button **once**.

Zone re-locking

The locks on Van, Bus and Kombi are split into two zones, cabin and cargo. Chassis Cab has only the cabin zone.

- Exit the vehicle and press the lock button.
- Press the unlock button or the cargo unlock button once to open the respective zone.

If you now open a door within the unlocked zone, the other doors in that zone will automatically lock.

Configurable unlocking

Configurable unlocking is set at the time of vehicle purchase and allows you to select which doors unlock when the unlock and cargo unlock buttons on the remote control are pressed once or twice. If you have this feature deactivated, it can not be reactivated. Ask your dealer for further information.

Engine immobiliser

PRINCIPLE OF OPERATION

The engine immobiliser is a theft protection system that prevents someone from starting the engine with an incorrectly coded key.

CODED KEYS

Note: *Do not shield your keys with metal objects. This may prevent the receiver from recognising your key as a valid one.*

Note: *Have all of your remaining keys erased and recoded if you lose a key. Ask your dealer for further information. Have replacement keys recoded together with your existing keys.*

If you lose a key, you can obtain a replacement from your Ford Dealer. If possible, provide them with the key number from the tag provided with the original keys. You can also obtain additional keys from your Ford Dealer.

ARMING THE ENGINE IMMOBILISER

The engine immobiliser is armed automatically a short time after you have switched the ignition off.

The indicator in the instrument cluster will flash to confirm that the system is operating.

DISARMING THE ENGINE IMMOBILISER

The engine immobiliser is disarmed automatically when you switch the ignition on with a correctly coded key.

The indicator in the instrument cluster will come on for approximately three seconds and then go out. If the indicator stays on for one minute or flashes for approximately one minute and then repeatedly at irregular intervals, your key has not been recognised. Remove the key and try again.

If you are unable to start the engine with a correctly coded key, this indicates a malfunction. Have the immobiliser checked immediately.

Alarm

PRINCIPLE OF OPERATION

All vehicles

If the alarm is triggered, the alarm horns will sound for 30 seconds and the hazard warning flashers will flash for five minutes. If the cause of the alarm being triggered has been removed, the alarm will return to its previous armed state. If the cause has not been removed, the alarm horns will sound again.

Vehicles with a perimeter alarm

The perimeter alarm is a deterrent against unauthorised access to your vehicle through the doors and the bonnet. It also protects the audio unit and the trailer (if a Ford trailer-tow kit is fitted). You can fully arm or partially arm the alarm. Trailer detection is disabled when you have partially armed the alarm.

The perimeter alarm will be triggered if someone:

- opens a door.
- opens the bonnet.
- attempts to start the engine with an incorrectly coded key.
- removes the audio unit.
- disconnects the trailer electrical connector (if it was connected at the time the alarm was armed).

Vehicles with a category one alarm



E71401

The category one alarm is additional to the perimeter alarm. Ultrasonic interior motion detection protects your vehicle against unauthorised access to the passenger compartment and the cargo area. You can fully arm or partially arm the alarm. Trailer detection and interior motion detection are disabled when you have partially armed the alarm. Interior motion detection is not activated if you arm the alarm when a door is open.

The category one alarm will only function correctly if all windows are fully closed. Keep the area in front of the motion sensors free from obstruction.

The category one alarm is triggered if:

- motion is detected in the passenger compartment or cargo area.
- someone attempts to access the cargo area through the rear door or tailgate window.

ARMING THE ALARM

Perimeter alarm

The alarm is armed 20 seconds after you have locked the doors. This delay allows you to close any doors or the bonnet without triggering the alarm.

Partial arming

Lock the doors with the key. See **Locking and unlocking** (page 19).

Full arming

Lock the doors with the remote control or double lock the doors with the key or the remote control. See **Locking and unlocking** (page 19).

Alarm

Category one alarm

Partial arming

Lock the doors with the key. See **Locking and unlocking** (page 19).

Full arming

Note: *Do not fully arm the alarm if someone is inside the vehicle.*

Lock the doors with the remote control or double lock the doors with the key or the remote control. See **Locking and unlocking** (page 19).

DISARMING THE ALARM

Perimeter alarm

Disarm and silence the alarm by unlocking the doors with the key, switching the ignition on with a correctly coded key or unlocking the doors with the remote control. See **Locking and unlocking** (page 19).

Category one alarm

Disarm and silence the alarm by unlocking the doors with the key in the driver's door and switching the ignition on with a correctly coded key within 12 seconds or unlocking the doors with the remote control. See **Locking and unlocking** (page 19).



Steering wheel

AUDIO CONTROL

Select radio, CD or cassette mode on the audio unit.

The following functions can be operated with the remote control:

Volume





E78046

Volume up: Press the top button on the back of the remote control.

Volume down: Press the bottom button on the back of the remote control.

Seek




E78047

Move the lever up or down:

- In **radio mode**, this will locate the next radio station up or down the frequency band.
- In **CD mode**, it will select the next or previous track.

Mode



E78048

Briefly press the button on the side:

Steering wheel

- In **radio mode**, this will locate the next pre-set radio station.
- In **CD mode**, this will select the next CD if a CD changer is fitted.
- In **all modes** to abort a traffic message during broadcasting.

Press and hold the button on the side:

- In **radio mode** to change the waveband.

VOICE CONTROL




E78049

To select or deselect voice control, press the button on the top.

For further information See **Voice control** (page 185).

Wipers and washers


WINDSCREEN WIPERS



E71012

- A Single wipe
- B Intermittent wipe
- C Normal wipe
- D High speed wipe

Intermittent wipe




E71013

- A Long wipe interval
- B Intermittent wipe
- C Short wipe interval

AUTOWIPERS

Autowipers



E71014


CAUTIONS

- ! Do not switch autowipers on in dry weather conditions. The rain sensor is very sensitive and the wipers may operate if dirt, mist or flies hit the windscreen.
- ! Replace the wiper blades as soon as they begin to leave bands of water and smears. If you do not replace them, the rain sensor will continue to detect water on the windscreen and the wipers will operate, even though the majority of the windscreen is dry.
- ! Fully defrost the windscreen in icy conditions before you switch autowipers on.
- ! Switch autowipers off before you enter a car wash.

If you switch autowipers on after you have switched the ignition on, the wipers will cycle once regardless of whether the windscreen is wet or dry. The rain sensor will then continuously measure the amount of water on the windscreen and adjust the speed of the wipers automatically.

Wipers and washers

If you switch the ignition on with autowipers already switched on, the wipers will not cycle until the rain sensor detects water on the windscreen.



E71015

A Low sensitivity

B High sensitivity

Adjust the sensitivity of the rain sensor using the rotary control. If you set the control to low sensitivity, the wipers will operate when the sensor detects a lot of water on the windscreen. If you set the control to high sensitivity, the wipers will operate if the sensor detects a small amount of water on the windscreen.

WINDSCREEN WASHERS



E71016

WARNING



Do not operate the windscreen washers for more than 10 seconds or when the reservoir is empty.

REAR WINDOW WIPER AND WASHERS

Intermittent wipe




E71017

The rear window wiper will follow the windscreen wiper interval.

Reverse gear wipe

The rear window wiper will operate automatically when you select reverse gear if the wiper lever is in position **A**, **B**, **C** or **D**.

Rear window washer



E71018


Wipers and washers

WARNING



Do not operate the rear window washer for more than 10 seconds or when the reservoir is empty.

CHECKING THE WIPER BLADES




E66644


Run the tip of your fingers over the edge of the blade to check for roughness.

Clean the wiper blade lips with water applied with a soft sponge.


CHANGING THE WIPER BLADES




E93783



E93784



E93785




E93786

Install in the reverse order.

Lighting

LIGHTING CONTROL

Lighting control positions



E71094

- A Off
- B Side and tail lamps
- C Headlamps
- D Front fog lamps
- E Rear fog lamps
- F Parking lamps


Parking lamps

First, switch off the ignition.

Both sides

Push the lighting control inwards and turn it to position **F**.


Single side



E77368

- A Right-hand side
- B Left-hand side

Main and dipped beam



E71095

Pull the lever fully towards the steering wheel to switch between main and dipped beam.

Headlamp flasher

Pull the lever slightly towards the steering wheel.

Lighting


Home safe lighting

Switch the ignition off and pull the direction indicator lever towards the steering wheel to switch the headlamps on. You will hear a short tone. The headlamps will go off automatically after 3 minutes with any door open, or 30 seconds after the last door has been closed.

With all doors closed, but within the 30 second delay, opening any door will result in the 3 minute timer starting again.

The home safe lights can be cancelled by either pulling the direction indicator lever towards the steering wheel again or by turning the ignition switch ON.

AUTOLAMPS



E73840

Note: If you have switched autolamps on, you can only switch the main beam on when autolamps has switched the headlamps on.

The headlamps will come on and go off automatically depending on the ambient light.

FRONT FOG LAMPS



E71096


WARNING



Only use the front fog lamps when visibility is considerably restricted by fog, snow or rain.

Note: You cannot switch the front fog lamps on if you have switched autolamps on.

REAR FOG LAMPS



E71097

WARNING




Do not use the rear fog lamps when it is raining or snowing and visibility is more than 50 metres.

Lighting

Note: You cannot switch the rear fog lamps on if you have switched autolamps on.

HEADLAMP LEVELLING

You can adjust the level of the headlamp beams according to the vehicle load.



E74611

- A Raise beams
- B Lower beams


Set the headlamp levelling control to zero when your vehicle is unloaded. Set it to provide illumination between 35 and 100 metres when your vehicle is partially or fully loaded.

HAZARD WARNING FLASHERS



For item location: See **Quick start** (page 6).

DIRECTION INDICATORS




E71098

Note: Tap the lever up or down to make the direction indicators flash only three times.

INTERIOR LAMPS

Courtesy lamps - Vehicles without interior sensors



E71099

- A On
- B Off
- C Door contact

Courtesy lamps that are not fitted with a switch will only come on when the switch on the front courtesy lamp is set to position **C** and you open a door.

Lighting


Vehicles with double locking

If you set the switch to position **C**, the courtesy lamps will stay on for a short time after you close the doors. They will go off immediately when you switch the ignition on.

When you switch the ignition off, the courtesy lamps will come on. They will go off automatically after a short time.

If you leave a door open, the courtesy lamps will go off automatically after 30 minutes. To switch them back on, switch the ignition on for a short time.

Courtesy lamp - Vehicles with interior sensors



E71945


- A Off
- B Door contact
- C On

If you set the switch to position **B**, the courtesy lamp will come on when you unlock or open a door or the tailgate. If you leave a door open, it will go off automatically after a short time to prevent the vehicle battery from discharging. To switch it back on, switch the ignition on for a short time.

The courtesy lamp will also come on when you switch the ignition off. It will go off automatically after a short time or when you start or restart the engine.

If you set the switch to position **C**, the courtesy lamp will come on. It will go off automatically after a short time to prevent the vehicle battery from discharging. To switch it back on, switch the ignition on for a short time.

Reading lamps



E71946

If you switch the ignition off, the reading lamps will go off automatically after a short time to prevent the vehicle battery from discharging. To switch them back on, switch the ignition on for a short time.

STEPWELL LAMPS

The stepwell lamps will come on and go off automatically when you open and close the doors. If you unlock the doors with the remote control, they will come on. They will go off automatically after a short time.

CHANGING A BULB

WARNINGS



Switch the lights and the ignition off.



Let the bulb cool down before removing it.

Lighting

CAUTIONS


- ⚠ Do not touch the glass of the bulb.
- ⚠ Only fit bulbs of the correct specification. See **Bulb specification chart** (page 42).

Note: We recommended that you ask your dealer to change the bulbs if your vehicle is fitted with air conditioning. Some bulbs are difficult to access.

Note: You will need to remove the headlamp to change the headlamp, side lamp or front direction indicator bulbs.



Note: The following instructions describe how to remove the bulbs. Fit replacements in the reverse order unless otherwise stated.

Removing a headlamp



1. Open the bonnet. See **Maintenance** (page 121).
2. Remove the screws.
3. Disconnect the electrical connector.
4. Remove the headlamp.


Headlamp main and dipped beam



Lighting

1. Remove the headlamp.
2. Release the clips.
3. Remove the cover.
4. Disconnect the electrical connector.
5. Release the clip and remove the bulb.


Side lamps



E71060

1. Remove the headlamp.
2. Remove the cover.
3. Remove the bulb and the bulb holder.
4. Remove the bulb.


Front direction indicators



E71061

1. Remove the headlamp.
2. Turn the bulb holder anti-clockwise and remove it.
3. Gently press the bulb into the bulb holder, turn it anti-clockwise and remove it.

Front fog lamps



E71062


Note: You cannot separate the bulb from the bulb holder.

1. Disconnect the electrical connector.
2. Turn the bulb holder anti-clockwise and remove it.

Lighting

Side repeaters


Type 1



E71063

1. Carefully remove the side repeater.
2. Hold the bulb holder, turn the housing anti-clockwise and remove it.
3. Remove the bulb.

Type 2




E71064

1. Turn the lens clockwise and remove it.
2. Gently press the bulb into the bulb holder, turn it anti-clockwise and remove it.

Side marker lamps


Chassis cab and Flatbed truck with extended frame



E75022

1. Disconnect the electrical connector.
2. Turn the bulb holder anti-clockwise and remove it.
3. Remove the bulb.

Jumbo van




E71065

1. Turn the lens in either direction and remove it.
2. Remove the bulb.


Lighting

Rear lamps

Bus and Kombi



E71066




E71067

- A Tail and brake lamp
- B Direction indicator
- C Reversing lamp
- D Fog lamp


1. Remove the wing nuts.
2. Remove the rear lamp and unclip the bulb holder.
3. Gently press the bulb into the bulb holder, turn it anti-clockwise and remove it.

Lighting

Chassis cab and Flatbed truck



E71068




E71069

- A Direction indicator
- B Brake lamp
- C Tail lamp
- D Reversing lamp
- E Fog lamp

1. Release the retaining clip and move the plastic frame to the side.
2. Remove the lens.
3. Gently press the bulb into the bulb holder, turn it anti-clockwise and remove it.

Rear side lamps


Flatbed truck



E71072

1. Carefully prise the lens from the holder.
2. Gently press the bulb into the bulb holder, turn it anti-clockwise and remove it.

Central brake lamp




E71071

1. Remove the screws.
2. Remove the lamp.
3. Remove the bulb.

Lighting

Roof position lamps




E71073

1. Remove the screws.
2. Remove the lens.
3. Gently press the bulb into the bulb holder, turn it anti-clockwise and remove it.

Number plate lamp


Vehicles with double rear doors



E71074

1. Remove the lens.
2. Remove the bulb.


Vehicles with a tailgate



E71075

1. Open the lens.
2. Gently press the bulb into the bulb holder, turn it anti-clockwise and remove it.

Flatbed truck




E71076

1. Remove the lens.
2. Gently press the bulb into the bulb holder, turn it anti-clockwise and remove it.

Lighting

Front interior lamps


Vehicles without interior sensors




E71077

1. Carefully prise out the lamp.
2. Gently press the bulb into the bulb holder, turn it anti-clockwise and remove it.

Vehicles with interior sensors




E73091



E73092

1. Carefully prise out the lamp.
2. Remove the lens.
3. Remove the bulb.


Rear interior lamps



E71078

1. Carefully prise out the lamp.
2. Remove the bulb.


Front reading lamps



E73938


Lighting

Stepwell lamps



E73939

1. Carefully prise out the lamp.
2. Turn the bulb holder anti-clockwise and remove it.
3. Remove the bulb.



E71080

1. Carefully prise out the lamp.
2. Remove the bulb holder.
3. Remove the bulb.

BULB SPECIFICATION CHART

Bulb	Watts (Specification)
Brake lamp - Chassis Cab and Flatbed Truck	21
Central brake lamp	16
Front direction indicator	21
Front fog lamp	55 (H11)
Headlamp main and dipped beam	55/60
Interior lamp	10
Number plate lamp - Except vehicles with double rear doors	10
Number plate lamp - Vehicles with double rear doors	5
Reading lamp	10
Rear direction indicator	21
Rear fog lamp	21

Lighting

Bulb	Watts (Specification)
Rear side lamp - Flatbed Truck	4
Reversing lamp	21
Roof marker lamp	4
Side lamp	5
Side marker lamp	3
Side repeater (type 1)	5
Side repeater (type 2)	21/5
Stepwell lamp	10
Tail and brake lamp	21/5
Tail lamp - Chassis Cab and Flatbed Truck	10


Windows and mirrors

ELECTRIC WINDOWS

WARNING



Do not operate the electric windows unless they are free from obstruction.



E71327

Switch on the ignition to operate the electric windows.

Opening the driver window automatically

Press the switch to the second action point and release it. Press it again to stop the window.

EXTERIOR MIRRORS

WARNING



Do not overestimate the distance of the objects that you see in the convex mirror. Objects seen in convex mirrors will appear smaller and further away than they actually are.

Manual folding mirrors


Folding

Push the mirror towards the door window glass.

Unfolding


Make sure that you fully engage the mirror in its support when returning it to its original position.

ELECTRIC EXTERIOR MIRRORS



E71280

- A Left-hand mirror
- B Off
- C Right-hand mirror




E71281

Windows and mirrors

The electric exterior mirrors are fitted with a heating element that will defrost or demist the mirror glass. See **Climate control** (page 60).

SLIDING WINDOWS



E66497

REAR QUARTER WINDOWS




E66498

Pull the lever outwards to open the window. Press the lever in the middle to engage it in its catch. Pull the lever in the middle to close the window. Push it backwards until it engages in its catch.

Instruments

GAUGES

Low series instrument cluster




E71334

- A Tachometer
- B Engine coolant temperature gauge
- C Fuel gauge
- D Speedometer
- E Tripmeter reset button
- F Odometer, tripmeter, clock, distance to empty and door open warning indicator
- G Clock set button

Instruments

High series instrument cluster



E73043

- A Tachometer
- B Engine coolant temperature gauge
- C Fuel gauge
- D Speedometer
- E Message warning lamp
- F Message centre. See **General information** (page 53).

Instruments

Engine coolant temperature gauge

Shows the temperature of the engine coolant. At normal operating temperature, the needle will remain in the centre section.

CAUTION



Do not restart the engine until the cause of overheating has been resolved.


If the needle moves towards 120°C, the engine is overheating. Stop the engine, switch the ignition off and determine the cause **once the engine has cooled down**. See **Engine coolant check** (page 128). See **Reduced engine performance** (page 105).

Fuel gauge

The arrow adjacent to the fuel pump symbol tells you on which side of your vehicle the fuel filler cap is located.

Odometer, tripmeter and clock

Low series instrument cluster



E71335

- A Clock and distance to empty
- B Tripmeter
- C Odometer

The tripmeter will register the distance of individual journeys. Press the reset button to reset the tripmeter.

WARNING LAMPS AND INDICATORS

Low series instrument cluster

The following warning lamps and indicators will come on briefly when you switch the ignition on to confirm that the system is operational:

- ABS
- Airbag
- Brake pad wear
- Brake system
- Cruise control
- Door open
- Engine

Instruments

- Hill start assist
- Ignition
- Low fuel level
- Oil pressure
- Service interval
- Shift
- Stability control (ESP) and traction control
- Water-in-fuel

High series instrument cluster

The following warning lamps and indicators will come on briefly when you switch the ignition on to confirm that the system is operational:

- ABS
- Airbag
- Brake pad wear
- Brake system
- Cruise control
- Engine
- Hill start assist
- Ignition
- Low fuel level
- Message indicator
- Shift
- Stability control (ESP) and traction control
- Water-in-fuel

If a warning or indicator lamp does not illuminate when the ignition is switched on, this indicates a malfunction. Have the system checked by properly trained technician.

ABS warning lamp



If it illuminates when you are driving, this indicates a malfunction. You will continue to have normal braking (without ABS). Have the system checked by a properly trained technician as soon as possible.

Airbag warning lamp



If it illuminates when you are driving, this indicates a malfunction. Have the system checked by a properly trained technician.

Brake pad wear warning lamp



It will illuminate when the brake pads have worn down to a predetermined limit. Have this checked by a properly trained technician as soon as possible.

Brake system lamp



It illuminates when the parking brake is engaged.

WARNING



Reduce your speed gradually and stop your vehicle as soon as it is safe to do so. Use your brakes with care.

If it illuminates when you are driving, check that the parking brake is not engaged. If the parking brake is not engaged, this indicates a malfunction. Have the system checked by a properly trained technician immediately.

Cruise control indicator



It will illuminate when you have set a speed using the cruise control system. See **Using cruise control** (page 98).

Instruments

Direction indicator



Flashes during operation. A sudden increase in the rate of flashing warns of a failed indicator bulb. See **Changing a bulb** (page 34).

Door open warning lamp



It will illuminate when you switch the ignition on if you have not closed the doors, the bonnet or tailgate properly.

Engine warning lamps

Malfunction indicator lamp



Powertrain warning lamp



All vehicles

If either lamp illuminates when the engine is running, this indicates a fault. The engine will continue to run but it may have limited power. If it flashes when you are driving, **reduce the speed of your vehicle immediately**. If it continues to flash, avoid heavy acceleration or deceleration. Have the system checked by a properly trained technician immediately.

WARNING



Have this checked immediately.

If **both** lamps illuminate together, **stop your vehicle as soon as it is safe to do so** (continued use may cause reduced power and cause the engine to stop). Turn the ignition off and attempt to restart the engine. If the engine restarts have the system checked by a properly trained technician immediately. If the engine does not restart the vehicle must be checked before continuing your journey.

Front fog lamp indicator



It will illuminate when you switch the front fog lamps on.

Glow plug indicator



See **Starting a diesel engine** (page 77).

Headlamp indicator



It will illuminate when you switch the headlamp dipped beam or the side and tail lamps on.

Hill start assist indicator



While driving, it illuminates during activation of the system. After switching on the ignition, if it does not illuminate this indicates that the system has been disabled. Your dealer can re-enable it. During a malfunction, the system switches off and it will not illuminate while driving.

Ignition warning lamp



If it illuminates when you are driving, this indicates a malfunction. Switch off all unnecessary electrical equipment. Have the system checked by a properly trained technician immediately.

Instruments

Low fuel level warning lamp



If it illuminates, refuel as soon as possible.

The arrow adjacent to the fuel pump symbol tells you on which side of your vehicle the fuel filler cap is located.

Main beam indicator



It will illuminate when you switch the headlamp main beam on. It will flash when you use the headlamp flasher.

Message indicator



It will illuminate when a new message is stored in the information display. See

Information messages (page 55).

Oil pressure warning lamp

CAUTION



Do not resume your journey if the oil pressure warning lamp illuminates despite the oil level being correct.

Have the system checked by a properly trained technician immediately.



If the lamp stays on after starting or illuminates during a journey, this indicates a malfunction. Stop your vehicle as soon as it is safe to do so and switch the engine off. Check the engine oil level. See

Engine oil check (page 127).

Rear fog lamp indicator



It will illuminate when you switch the rear fog lamps on.

Service interval indicator

Vehicles with a diesel engine



It will illuminate when a service is due or there is excessive soot or sludge in the oil. Have the engine oil changed as soon as possible.

Your dealer will switch the service interval indicator lamp off for you after completing the service.

Shift indicator



It will illuminate to inform you that shifting to a higher gear may give better fuel economy and lower CO₂ emissions. It will not illuminate during periods of high acceleration, braking or when the clutch pedal is pressed.

Stability control (ESP) and traction control warning lamp

Note: *If either the ESP system or traction control system malfunctions, the respective system will switch off automatically.*



It will flash when either system is operating. If it does not flash or it comes on when you are driving, this indicates a malfunction. Have the system checked by a properly trained technician immediately.

If you switch ESP off, the warning lamp will come on. The lamp will go out when you switch the system back on or when you switch the ignition off.

Instruments

Water-in-fuel indicator

Vehicles with a diesel engine



It will illuminate if there is excess water in the fuel filter. Drain off the water immediately. See

Draining the fuel filter water trap (page 129).

AUDIBLE WARNINGS AND INDICATORS

Door open warning

The door open warning chime will sound if you switch the ignition on and you have not closed the doors, the bonnet or tailgate properly.

Message centre

See **Personalised settings** (page 57).

Information displays

GENERAL INFORMATION

WARNING




For road safety reasons, set and reset the functions only when the vehicle is stationary.

Various functions can be programmed using the **message centre** and the multi-function lever on the steering column.

The message centre also provides warning messages about faults or system malfunctions. See **Information messages** (page 55).

Main menu

Overview of the main menu displays




E73982

The various sub-menus are accessed from the main menu.


Information displays

Controls



E73265

Use the rotary control to scroll through the menu.




E73266

Note: If the chimes are activated, a short tone will sound each time the button is pressed.


Press the **SET** and **RESET** button to select a sub-menu or the item that you want to adjust.

Odometer



E73983


Tripmeter



E73984

Press the **SET** and **RESET** button for at least 2 seconds to reset.

Distance to empty




E73985

Note: Changes in driving pattern may cause the value to vary.

Indicates the approximate distance the vehicle will travel on the fuel remaining in the tank.

Average fuel consumption




E73986

Indicates the average fuel consumption since the function was last reset.

Press the **SET** and **RESET** button to reset.

Information displays

Average speed




E73987

Indicates the average speed calculated over the last 1 000 kilometres (600 miles) or since the function was last reset.

Press the **SET** and **RESET** button to reset.

Outside air temperature



E73988

WARNING



Even if the temperature rises to above +4 °C there is no guarantee that the road is free of hazards caused by inclement weather.


A warning chime will sound in the following conditions:

- +4 °C or lower: frost warning
- 0 °C or lower: danger of icy roads

INFORMATION MESSAGES

Warning messages

When certain warning message appear in the display, you must press the **SET** and **RESET** button to acknowledge them.



E73273

Some warning messages are supplemented by the message centre warning lamp above the display which comes on red or amber, depending on the severity of the problem.

If a warning message accompanied by the warning lamp is present, the warning lamp will remain on.

Messages	Warning lamp	Meaning
ENGINE MALFUNCTION	red	Malfunction of the engine or related systems. Stop the vehicle as soon as safely possible and switch off the engine immediately. Have the engine checked by properly trained technicians.


Information displays

Messages	Warning lamp	Meaning
LOW OIL LEVEL	red	Low oil level. Stop the vehicle as soon as safely possible and switch off the engine immediately. Top up the engine oil. See Engine oil check (page 127).
WATER DETECTED IN FUEL	red	Water has been detected in the fuel. Have the fuel system checked by properly trained technicians.
LOW OUTSIDE TEMPERATURE	red	Outside temperature is below 0 °C
LOW OUTSIDE TEMPERATURE	amber	Outside temperature is below +4 °C
SERVICE OIL NOW	amber	Have your vehicle checked by properly trained technicians.
DOOR AJAR CLOSE DOOR	amber	Check all doors are fully closed.
DRIVER DOOR OPEN	amber	The driver's door is open.
PASSENGER DOOR OPEN	amber	The front passenger's door is open.
DRIVER SIDE REAR DOOR OPEN	amber	The rear door on the driver's side is open.
PASSENGER SIDE REAR DOOR OPEN	amber	The rear door on the passenger's side is open.
LUGGAGE COMP OPEN	amber	The cargo compartment or rear door is open.
BONNET OPEN	amber	The bonnet is open.
SERVICE OIL SOON xx DAYS	-	Indicates the oil service is due.
SERVICE OIL RESET IN PROG	-	Service oil reset is in progress.
SERVICE OIL RESET COMPLETE	-	Service oil reset is complete.
ALARM RESET TO STOP	-	Alarm clock is ringing. See Personalised settings (page 57).

Information displays


PERSONALISED SETTINGS

Overview of the your settings menu displays



E73990

Your settings menu



E73989

The following sub-menus are available in the **your settings menu**:

- Language
- Clock setting
- Alarm setting
- Time format
- Units of measure
- Message chimes

Language setting



E73991

A choice of eleven languages are available:

English (UK), German, Italian, French, Spanish, Turkish, Russian, Dutch, Polish, Swedish, Portuguese.


Once selected, turn the rotary control to save the setting and exit the menu.

Clock setting

See **Clock** (page 72).

Information displays


Alarm setting



E74286

- Press and hold **SET** and **RESET**. The day starts to flash. Adjust using the rotary control.
- Press the **SET** and **RESET** button to confirm the setting and move to the month.
- Proceed in the same way to set the year, hours and minutes.
- After setting the minutes and pressing **SET** and **RESET**, the time is stored.
- Press **SET** and **RESET** to turn the alarm on or off.

Alarm activated




E74287



E74387

Press **SET** and **RESET** to turn off.


Time format



E73995

Press **SET** and **RESET** to toggle between 12 and 24 hour format.

Units of measure



E73993

Press **SET** and **RESET** to toggle between metric and imperial units.

Message chimes

The following chimes can be deactivated:

- ambient temperature at 4°C
- set time confirmation
- **SET** and **RESET** button press



E73994

Press **SET** and **RESET** to toggle the chimes on and off.

Information displays

Your Settings - Exit



E73996

Press **SET** and **RESET** to exit.

Climate control

PRINCIPLE OF OPERATION

Outside air

Keep the air intakes forward of the windscreen free from obstruction (snow, leaves etc.) to allow the climate control system to function effectively.

Recirculated air

CAUTION

⚠ Prolonged use of recirculated air may cause the windows to mist up. If the windows mist up, follow the settings for defrosting and demisting the windscreen.

The air currently in the passenger compartment will be recirculated. Outside air will not enter the vehicle.

Heating

Heating performance depends on the temperature of the engine coolant.

Air conditioning

Note: The air conditioning operates only when the temperature is above 4°C (39°F).

Note: If you use the air conditioning, the fuel consumption of your vehicle will be higher.

Air is directed through the evaporator where it is cooled. Humidity is extracted from the air to help keep the windows free of mist. The resulting condensation is directed to the outside of the vehicle and it is therefore normal if you see a small pool of water under your vehicle.

General information on controlling the interior climate

Fully close all the windows.


Warming the interior

Direct the air towards your feet. In cold or humid weather conditions, direct some of the air towards the windscreen and the door windows.

Cooling the interior

Direct the air towards your face.

AIR VENTS




E71344

- A Left
- B Right
- C Open
- D Close
- E Down
- F Up

Climate control

MANUAL CLIMATE CONTROL

Air distribution control



E65965

- A Face level
- B Footwell
- C Windscreen


Note: A small amount of air is always directed towards the windscreen.

Temperature control



E65966

Blower




E65967

- A Off

Note: If you switch the blower off, the windscreen may mist up.

Recirculated air



E65968

- A Recirculated air
- B Outside air

Defrosting and demisting the windscreen quickly



E65969

Close all of the air vents for maximum airflow to the windscreen. If necessary, switch the heated windows on. See **Heated windows and mirrors** (page 63).

Heating the interior quickly



E65970

Climate control


Ventilation



E65971

Air conditioning

Switching the air conditioning on and off



E65972

- A Recirculated air
- B Outside air
- C On and off
- D Air conditioning indicator

Note: The indicator in the control will come on when the air conditioning is operating.

Cooling with outside air



E65973

Switch the air conditioning on.

Cooling the interior quickly



E65974

Switch the air conditioning on.

Defrosting and demisting the windscreen



E65975

- A Windscreen

Set the air distribution control to position **A** and select outside air. When the temperature is above 4°C (39°F), the air conditioning will switch on automatically. The indicator in the control will **not** come on in this instance.

Climate control

Reducing interior air humidity



E65976

A Windscreen

Set the air distribution control to position **A** and select outside air. When the temperature is above 4°C (39°F), the air conditioning will switch on automatically. The indicator in the control will **not** come on in this instance.

HEATED WINDOWS AND MIRRORS

Heated windows

Use the heated windows to defrost or demist the windscreen or rear window.

Note: The heated windows operate only when the engine is running.

Heated windscreen



Heated rear window



Heated exterior mirrors



Electric exterior mirrors are fitted with a heating element that will defrost or demist the mirror glass. They will switch off automatically after a short time.

AUXILIARY HEATER

General information

WARNINGS



Do not operate the programmable fuel fired heater at filling stations, near sources of combustible vapours or dust or in enclosed spaces.



Do not refuel when the programmable fuel fired heater display is on.

Note: The programmable fuel fired heater will switch off automatically when the battery voltage is low.

Note: All symbols on the display will flash if the power to the programmable fuel fired heater has been interrupted. The heater will not operate under these circumstances. Re-set the clock time.

Note: The programmable fuel fired heater will shut down in the event of a malfunction. Have the system checked by an expert.

Observe the following information:

- Switch the programmable fuel fired heater on for approximately 10 minutes at least once a month, all year round. This prevents the water pump and heater motor from seizing.
- To avoid corrosion, make sure the coolant in your vehicle contains at least 10 % antifreeze all year round.
- Make sure the coolant level is between the **MAX** and **MIN** marks on the reservoir to prevent air locks. See **Engine coolant check** (page 128).

Climate control

- Programmable blower operation begins when the coolant reaches a certain temperature. In this mode, ambient temperature has no effect.
- In continuous heater operation, the unit senses the ambient temperature. If this is above 5°C (41°F) the programmable fuel fired heater will not activate.

The programmable fuel fired heater operates independently of the vehicle heater by heating the engine's coolant circuit. It is fed from the vehicle fuel tank. It may also be used while the vehicle is in motion to help the vehicle heater warm up the interior more quickly.

It is possible that when the programmable fuel fired heater is activated, exhaust fumes may come from under the sides of the vehicle. This is normal.

Principle of operation

Before operation


CAUTION

- ! Turning the blower switch to a position other than position one will reduce battery life or even flatten the battery.

Before activating or programming the heater, prepare the following settings:

- Set the vehicle heater temperature control to maximum.
- Turn the blower switch to position one.
- Switch on the recirculated air before turning the ignition off. Wait at least five seconds for the ventilation system to close the outside air vents.
- Open all the cabin air vents.


Setting the clock time



E71347

Press and hold button **A** for more than three seconds, until the time flashes in the display. Within five seconds, press buttons **B** and **D** to set the time. To adjust the time rapidly, press and hold the respective button.

Setting the heating duration



E71348

CAUTION

- ! The recommended setting is 30 minutes. Longer durations will reduce battery life or even flatten the battery.

Climate control

Note: The heating duration for pre-set times and the timed heating mode can be set between 10 and 120 minutes.

Press and hold button **A** for more than three seconds, until the time flashes in the display. Wait for five seconds until the heating symbol appears and the heating time flashes.


Press buttons **B** and **D** to adjust the heating duration.

After setting the heating duration, press button **A**. The display will show the clock time with the colon flashing.

Switching off the heater

Press the heating symbol button. The heater will operate for an additional three minutes, and then stop. The display will then show the clock time.


Timed heating mode



E71349

The heater may be switched on to heat for the pre-set duration at any time. Press button **C**. The display will light up and show the remaining heating time and the heating symbol.

Continuous heater operation



E71350

WARNING



The heater will continue to operate after the ignition is switched off.

Switch the heater off to avoid unnecessary heating.

Press and hold button **B**. Press button **C**. The heater will now operate until button **C** is pressed again. The display will light up and show the clock time and the heating symbol.


Programmable heating mode

The heater will come on automatically at the activated pre-set start time, and will stay on for the programmed duration. The display will light up and show the remaining heating duration and the heating symbol.

You can program up to three different pre-set start times.

Climate control

Programming the pre-set heating start times



E71351

Press button **A** repeatedly, until the symbol (**1**, **2** or **3**) for the desired pre-set time is displayed. Press buttons **B** and **D** to set the time. To adjust the time rapidly, press and hold the respective button.

After programming the pre-set start times press button **A**. The display will show the clock time with the colon flashing.

Activating and deactivating pre-set start times




E71352

Press button **A** repeatedly, until the symbol (**1**, **2** or **3**) for the desired pre-set time is displayed. Press button **C**. The **ON** symbol will appear in the display. To deactivate a pre-set time, press button **C** again.

Seats

SITTING IN THE CORRECT POSITION



E68595

WARNINGS



Do not adjust the seats when the vehicle is moving.



Only when you use the seat belt properly, can it hold you in a position that allows the airbag to achieve its optimum effect.

When you use them properly, the seat, head restraint, seat belt and airbags will provide optimum protection in the event of a collision. We recommend that you:

- sit in an upright position with the base of your spine as far back as possible.
- do not recline the seatback more than 30 degrees.
- adjust the head restraint so that the top of it is level with the top of your head and as far forwards as possible, remaining comfortable.
- keep sufficient distance between yourself and the steering wheel. We recommend a minimum of 250 millimetres (10 inches) between your breastbone and the airbag cover.

- hold the steering wheel with your arms slightly bent.
- bend your legs slightly so that you can press the pedals fully.
- position the shoulder strap of the seat belt over the centre of your shoulder and position the lap strap tightly across your hips.

Make sure that your driving position is comfortable and that you can maintain full control of your vehicle.

FRONT SEATS

WARNING



Do not adjust the seats when the vehicle is moving.

Moving the seats backwards and forwards



E66529

WARNING




Rock the seat backwards and forwards after releasing the lever to make sure that it is fully engaged in its catch.

Seats

CAUTION

⚠ Do not move the front seats too close to the instrument panel. The front nine catch positions are only to provide access to the vehicle battery.

Adjusting the lumbar support



E66530

- A Increase
- B Decrease

Adjusting the angle of the seat base



E66531



E66532

Adjusting the angle of the seatback



E66533

Adjusting the armrest



E66534

Turn the wheel underneath the armrest.

Seats

Rotating the seat

WARNING




Make sure that the seats and the seatbacks are secure and fully engaged in their catches.

CAUTION



Rotate the seat only towards the centre of the vehicle and not towards the door.



E99961

REAR SEATS

WARNINGS



Do not use the bench seats as a bed when the vehicle is moving.




Make sure that the seats and the seatbacks are secure and fully engaged in their catches.




When folding the seatbacks up, make sure that the belts are visible to an occupant and not caught behind the seat.

Folding a single seatback forwards



E70789

Folding the entire seatback forwards



E68610

To fold the seatback:


1. Pull the release straps down and hold them there.
2. Push the seatback forwards.

Seats


To return the seatback to its upright position:

1. Pull the release straps down and hold them there.
2. Push the seatback to the upright position.

Removing the bench seats



E68611



E68612

WARNINGS



Plug the bolt holes that are exposed when you remove the seats to prevent exhaust fumes from entering the vehicle.

WARNINGS



The bench seat weighs 89 kilogrammes.

CAUTION




Store the seat in a dry and secure place.

1. Fold the seatback forwards.
2. Pull the release up and hold it there.
3. Gently pull the seat backwards until the front of the seat frame clears the catches on the floor.
4. Remove the seat.

Install the seat in the reverse order.

HEAD RESTRAINTS



E66539

Adjusting the head restraint

WARNING



Raise rear head restraint when the rear seat is occupied by a passenger or a child restraint.

Adjust the head restraint so that the top of it is level with the top of your head.

Seats

Removing the head restraint

Press the locking buttons and remove the head restraint.

HEATED SEATS



E66540

Note: Start the engine to use the heated seats.

The heated seats will reach their maximum temperature after five or six minutes. They will go off automatically.

Convenience features

CLOCK

Vehicles with clock displayed in the audio or navigation unit

For detailed instructions on how to adjust the clock, refer to the separate audio or navigation manual.


Vehicles with low series instrument cluster

Note: You will hear a short tone when the time is set.

Note: Press and hold the clock set button for more than one second to toggle between 12 and 24 hour format.

1. Switch the ignition to position II.
2. Press and hold the clock set button for more than three seconds, until the time flashes in the display.
3. Press the clock set button to adjust the time. To adjust the time rapidly, press and hold the button.

Vehicles with high series instrument cluster




E73992

1. Scroll to this display. Press and hold **SET** and **RESET**. The day starts to flash. Adjust using the rotary control.
2. Press the **SET** and **RESET** button to confirm the setting and move to the month.
3. Proceed in the same way to set the year, hours and minutes.

After setting the minutes and pressing **SET** and **RESET**, the time and date are stored.

TICKET HOLDERS



E77059


CIGAR LIGHTER

CAUTIONS

- ! If you use the socket when the engine is not running, the battery may discharge.
- ! Do not hold the cigar lighter element pressed in.

Note: You can use the socket to power 12 volt appliances that have a maximum current rating of 20 Amperes. Use only Ford accessory connectors or connectors specified for use with SAE standard sockets.

Convenience features




E72972

Press the element in to use the cigar lighter. It will pop out automatically.

For item location: See **Quick start** (page 6).

ASHTRAY



E69119


AUXILIARY POWER SOCKETS

CAUTION




If you use the auxiliary power socket when the engine is not running, the battery may discharge.

Note: You can use the socket to power 12 volt appliances that have a maximum current rating of 20 Amperes. Use only Ford accessory connectors or connectors specified for use with SAE standard sockets.




E69125

CUP HOLDERS



E69128

Convenience features




E69129

WARNINGS

-  Do not place hot drinks in the cup holders when the vehicle is moving.
-  Do not use the tray when the vehicle is moving.
-  Do not place glass objects in the cup holders.

STORAGE COMPARTMENTS

Overhead storage compartment



E69133

WARNING




Do not place heavy objects in the overhead storage compartment.

Front storage compartment



E77061

BOTTLE HOLDER



E75484

WARNING




Do not place glass objects in the bottle holder.

Convenience features

AUXILIARY INPUT (AUX IN) SOCKET

See separate audio handbook.



FLOOR MATS

WARNING



When using the floor mats, always make sure the floor mat is properly secured using the appropriate fixings and positioned so that it does not interfere with the operation of the pedals.

Starting the engine

GENERAL INFORMATION

General points on starting

If the battery has been disconnected the vehicle may exhibit some unusual driving characteristics for approx. 8 kilometres (5 miles) after reconnecting the battery.

This is because the engine management system must realign itself with the engine. Any unusual driving characteristics during this period may be disregarded.

Starting the engine by towing or pushing

WARNING



To prevent damage you must not push or tow start your vehicle. Use booster cables and a booster battery. See **Using booster cables** (page 136).

STARTING A PETROL ENGINE

Note: *You can only operate the starter for a maximum of 30 seconds at a time.*

Cold or hot engine

All vehicles

CAUTION



When the temperature is below -20°C (-4°F), switch the ignition on for at least one second before starting the engine. This will make sure that the maximum fuel pressure is established for starting the engine.

Vehicles with manual transmission

Note: *Do not touch the accelerator pedal.*

1. Fully depress the clutch pedal.

2. Start the engine.

Vehicles with automatic transmission

Note: *Do not touch the accelerator pedal.*

1. Select park or neutral.
2. Fully depress the brake pedal.
3. Start the engine.

All vehicles

If the engine does not start within 15 seconds, wait for a short period and try again.

If the engine does not start after **three** attempts, wait 10 seconds and follow the **Flooded engine** procedure.

If you have difficulty starting the engine when the temperature is below -25°C (-13°F), press the accelerator pedal between 1/4 to 1/2 of its travel and try again.

Flooded engine

Vehicles with manual transmission

1. Fully depress the clutch pedal.
2. Fully depress the accelerator pedal and hold it there.
3. Start the engine.

Vehicles with automatic transmission

1. Select park or neutral.
2. Fully depress the accelerator pedal and hold it there.
3. Fully depress the brake pedal.
4. Start the engine.

All vehicles

If the engine does not start, repeat the **Cold or hot engine** procedure.

Starting the engine

Engine idle speed after starting

The speed at which the engine idles immediately after starting will vary depending on the engine temperature.

If the engine is cold then the idle speed will automatically be increased in order to heat the catalytic converter as quickly as possible. This ensures that vehicle emissions are kept to an absolute minimum.

The idle speed will slowly decrease to the normal level as the catalytic converter warms up.

STARTING A DIESEL ENGINE

Cold or hot engine

All vehicles

Note: When the temperature is below -15°C (5°F), you may need to crank the engine for up to 25 seconds. If you consistently operate the vehicle in such temperatures, we recommend that you have an engine block heater fitted.

Note: Continue cranking the engine until it starts.

Note: You can only operate the starter for a maximum of 30 seconds at a time.

Note: If the engine fails to start after a number of attempts, the engine warning lamp will illuminate. See **Warning lamps and indicators** (page 48). The engine must be left for 30 minutes before further starting attempts can be made to prevent damage to the starter motor.



Switch the ignition on and wait until the glow plug indicator goes off.

Vehicles with manual transmission

Note: Do not touch the accelerator pedal.

1. Fully depress the clutch pedal.
2. Start the engine.

Vehicles with automatic transmission

1. Select park or neutral.
2. Fully depress the brake pedal.
3. Start the engine.

DIESEL PARTICULATE FILTER (DPF)

The DPF forms part of the emissions reduction systems fitted to your vehicle. It filters harmful diesel particulates (soot) from the exhaust gas.

Regeneration

WARNING



Do not park or idle your vehicle over dry leaves, dry grass or other combustible materials. The DPF regeneration process creates very high exhaust gas temperatures and the exhaust will radiate a considerable amount of heat during and after DPF regeneration, and after you have switched the engine off. This is a potential fire hazard.

Unlike a normal filter which requires periodic replacement, the DPF has been designed to regenerate, or clean itself to maintain operating efficiency. The regeneration process takes place automatically. However, some driving conditions mean that you may need to support the regeneration process.

Starting the engine

If you drive only short distances or your journeys contain frequent stopping and starting, occasional trips with the following conditions could assist the regeneration process:

- Drive your vehicle, preferably on a main road or motorway, for up to 20 minutes avoiding prolonged idling, but always observing speed limits and road conditions.
- Do not switch off the ignition.
- Use a lower gear than normal to maintain a higher engine speed during this journey, where appropriate.

SWITCHING OFF THE ENGINE

Vehicles with a turbocharger

CAUTION



Do not switch the engine off when it is running at high speed. If you do, the turbocharger will continue running after the engine oil pressure has dropped to zero. This will lead to premature turbocharger bearing wear.

Release the accelerator pedal. Wait until the engine has reached idle speed and then switch it off.

Fuel and refuelling

SAFETY PRECAUTIONS

WARNINGS



Stop refuelling after the fuel nozzle stops the second time. Additional fuel will fill the expansion space in the fuel tank which could lead to fuel overflowing. Fuel spillage could be hazardous to other road users.



Do not use any kind of flames or heat near the fuel system. The fuel system is under pressure. There is a risk of injury if the fuel system is leaking.

FUEL QUALITY - PETROL

Note: We recommend that you use only high quality fuel without additives or other engine treatments.

CAUTION



Do not use leaded petrol or petrol with additives containing other metallic compounds (e.g. manganese-based). They could damage the emission system.

Use **minimum 95 octane unleaded** petrol that meets the specification defined by **EN 228**, or equivalent.

FUEL QUALITY - DIESEL

WARNING



Do not mix diesel with oil, petrol or other liquids. This could cause a chemical reaction.

CAUTION



Do not add kerosene, paraffin or petrol to diesel. This could cause damage to the fuel system.

Note: We recommend that you use only high quality fuel without additives or other engine treatments.

Note: We do not recommend the prolonged use of additives intended to prevent fuel waxing.

Use diesel that meets the specification defined by **EN 590**, or equivalent.

You can use diesel that contains up to 5% RME (bio diesel).

Long-term storage

Most diesel fuels contain bio-diesel, it is recommended to fill the tank with purely mineral diesel (where available) or add an anti-oxidant prior to long-term storage of your vehicle exceeding two months. Your dealer can help you with a suitable anti-oxidant.

CATALYTIC CONVERTER

WARNING



Do not park or idle your vehicle over dry leaves, dry grass or other combustible materials. The exhaust will radiate a considerable amount of heat during use, and after you have switched the engine off. This is a potential fire hazard.

Driving with a catalytic converter

CAUTIONS



Avoid running out of fuel.



Do not crank the engine for long periods.



Do not run the engine when a spark plug lead is disconnected.

Fuel and refuelling

CAUTIONS

- ❗ Do not push-start or tow-start your vehicle. Use booster cables. See **Using booster cables** (page 136).
- ❗ Do not switch the ignition off when driving.

FUEL FILLER FLAP


WARNINGS

- ⚠ Take care when refuelling to avoid spilling any residual fuel from the fuel pipe nozzle.
- ⚠ We recommend that you wait at least 10 seconds before removing the fuel pipe nozzle to allow any residual fuel to drain into the fuel tank.


CAUTION

- ❗ If you use a high pressure spray to wash your vehicle, only spray the fuel filler flap briefly from a distance not less than 20 centimetres (8 inches).

Note: It is normal to hear a hissing noise when you remove the filler cap.



E66588



E95392

REFUELLING

CAUTION

- ❗ Do not attempt to start the engine if you have filled the fuel tank with the incorrect fuel. This could damage the engine. Have the system checked by a properly trained technician immediately.

FUEL CONSUMPTION

The CO₂ and fuel consumption figures are derived from laboratory tests according to EEC Directive 80/1268/EEC and subsequent amendments and are carried out by all vehicle manufacturers.

They are intended as a comparison between makes and models of vehicles. They are not intended to represent the real world fuel consumption you may get from your vehicle. Real world fuel consumption is governed by many factors including; driving style, high speed driving, stop/start driving, air conditioning usage, the accessories fitted and towing etc.

Your Ford dealer can give you advice on improving your fuel consumption.

Fuel and refuelling

TECHNICAL SPECIFICATIONS

Fuel consumption figures

Variant	Urban	Extra-urban	Combined	CO2 emissions
	l/100 km (mpg)	l/100 km (mpg)	l/100 km (mpg)	g/km
Tourneo 2.2L DuraTorq-TDCi 62.5kW (85 PS), Axle ratio: 4.23	9.3 (30.4) - 9.6 (29.4)	6.6 (42.8) - 6.9 (40.9)	7.6 (37.2) - 7.9 (35.8)	201 - 208
Tourneo 2.2L DuraTorq-TDCi 81kW (110 PS), Axle ratio: 4.23	9.3 (30.4) - 9.6 (29.4)	6.6 (42.8) - 6.9 (40.9)	7.6 (37.2) - 7.9 (35.8)	201 - 208
Tourneo 2.2L DuraTorq-TDCi 85kW (115 PS), Axle ratio: 4.36, 6-speed manual transmission	9.8 (28.8) - 10.1 (28.0)	6.3 (44.8) - 6.6 (42.8)	7.6 (37.2) - 7.9 (35.8)	200 - 208
Tourneo 2.2L DuraTorq-TDCi 96kW (130 PS), Axle ratio: 4.54	9.8 (28.8) - 10.1 (28.0)	6.7 (42.2) - 7.0 (40.4)	7.8 (36.0) - 8.1 (34.7)	207 - 215
Tourneo 2.2L DuraTorq-TDCi 103kW (140 PS), Axle ratio: 4.36, 6-speed manual transmission	9.8 (28.8) - 10.1 (28.0)	6.3 (44.8) - 6.6 (42.8)	7.6 (37.2) - 7.9 (35.8)	200 - 208
Kombi 2.2L DuraTorq-TDCi 62.5kW (85 PS), Axle ratio: 4.23	9.1 (31.0) - 9.6 (29.4)	6.4 (44.1) - 6.9 (40.9)	7.4 (38.2) - 7.9 (35.8)	195 - 208
Kombi 2.2L DuraTorq-TDCi 81kW (110 PS), Axle ratio: 4.23	9.1 (31.0) - 9.6 (29.4)	6.4 (44.1) - 6.9 (40.9)	7.4 (38.2) - 7.9 (35.8)	195 - 208
Kombi 2.2L DuraTorq-TDCi 81kW (110 PS), Axle ratio: 4.54	9.1 (31.0) - 9.5 (29.7)	6.7 (42.2) - 7.1 (39.8)	7.6 (37.2) - 8.0 (35.4)	200 - 211
Kombi 2.2L DuraTorq-TDCi 85kW (115 PS), Axle ratio: 4.36, 6-speed manual transmission	9.6 (29.4) - 10.1 (28.0)	6.1 (46.3) - 6.6 (42.8)	7.4 (38.2) - 7.9 (35.8)	195 - 208

Fuel and refuelling

Variant	Urban	Extra-urban	Combined	CO2 emissions
	l/100 km (mpg)	l/100 km (mpg)	l/100 km (mpg)	g/km
Kombi 2.2L DuraTorq-TDCi 85kW (115 PS), Axle ratio: 4.93, 6-speed manual transmission	9.6 (29.4) - 10.0 (28.3)	6.4 (44.1) - 6.8 (41.5)	7.6 (37.3) - 8.0 (35.4)	200 - 211
Kombi 2.2L DuraTorq-TDCi 96kW (130 PS), Axle ratio: 4.54 up to T300	9.6 (29.4) - 10.1 (28.0)	6.5 (43.5) - 7.0 (40.4)	7.6 (37.0) - 8.1 (34.7)	202 - 215
Kombi 2.2L DuraTorq-TDCi 96kW (130 PS), Axle ratio: 4.54 T330 and above	9.4 (30.1) - 9.8 (28.8)	6.7 (42.2) - 7.1 (39.8)	7.7 (36.7) - 8.1 (34.9)	203 - 214
Kombi 2.2L DuraTorq-TDCi 103kW (140 PS), Axle ratio: 4.36, 6-speed manual transmission	9.6 (29.4) - 10.1 (28.0)	6.1 (46.3) - 6.6 (42.8)	7.4 (38.2) - 7.9 (35.8)	195 - 208
Kombi 2.2L DuraTorq-TDCi 103kW (140 PS), Axle ratio: 4.93, 6-speed manual transmission	9.6 (29.4) - 9.7 (29.1)	6.4 (44.1) - 6.8 (41.5)	7.6 (37.3) - 8.0 (35.4)	200 - 211
Kombi 2.4L DuraTorq-TDCi 74kW (100 PS), Axle ratio: 4.78	11.2 (25.2) - 11.5 (24.6)	7.5 (37.7) - 7.9 (35.8)	8.9 (31.9) - 9.2 (30.6)	234 - 244
Kombi 2.4L DuraTorq-TDCi 74kW (100 PS), Axle ratio: 3.73, 6-speed manual transmission, with DPF	10.8 (26.2) - 11.0 (25.7)	7.2 (39.2) - 7.4 (38.2)	8.5 (33.1) - 8.7 (32.4)	225 - 230
Kombi 2.4L DuraTorq-TDCi 74kW (100 PS), Axle ratio: 5.11	12.0 (23.5) - 12.4 (22.8)	8.0 (35.3) - 8.4 (33.6)	9.5 (29.8) - 9.9 (28.6)	250 - 261
Kombi 2.4L DuraTorq-TDCi 74kW (100 PS), Axle ratio: 4.27, 6-speed manual transmission, with DPF	12.2 (23.2) - 12.4 (22.8)	8.1 (34.9) - 8.3 (34.0)	9.6 (29.4) - 9.8 (28.8)	254 - 259

Fuel and refuelling

Variant	Urban	Extra-urban	Combined	CO2 emissions
	l/100 km (mpg)	l/100 km (mpg)	l/100 km (mpg)	g/km
Kombi 2.4L DuraTorq-TDCi 85kW (115 PS), Axle ratio: 3.73, 6-speed manual transmission, non DPF	10.6 (26.7) - 10.7 (26.4)	7.3 (38.7) - 7.4 (38.2)	8.5 (33.2) - 8.6 (32.8)	225 - 227
Kombi 2.4L DuraTorq-TDCi 85kW (115 PS), Axle ratio: 3.73, 6-speed manual transmission, with DPF	10.9 (25.8) - 11.1 (25.4)	7.1 (39.8) - 7.3 (38.7)	8.5 (33.2) - 8.7 (32.4)	225 - 230
Kombi 2.4L DuraTorq-TDCi 85kW (115 PS), Axle ratio: 4.27, 6-speed manual transmission, non DPF	12.6 (22.4) - 12.8 (22.1)	7.9 (35.8) - 8.0 (35.3)	9.6 (29.4) - 9.8 (28.8)	254 - 258
Kombi 2.4L DuraTorq-TDCi 85kW (115 PS), Axle ratio: 4.27, 6-speed manual transmission, with DPF	12.5 (22.6) - 12.7 (22.2)	7.9 (35.8) - 8.1 (34.9)	9.6 (29.4) - 9.8 (28.8)	253 - 259
Kombi 2.4L DuraTorq-TDCi 103kW (140 PS), Axle ratio: 3.73, 6-speed manual transmission, non DPF	11.4 (24.8) - 11.5 (24.6)	7.6 (37.2) - 7.8 (36.2)	9.0 (31.4) - 9.2 (30.8)	238 - 242
Kombi 2.4L DuraTorq-TDCi 103kW (140 PS), Axle ratio: 3.73, 6-speed manual transmission, with DPF	11.4 (24.8) - 11.6 (24.4)	7.6 (37.2) - 8.0 (35.3)	9.0 (31.4) - 9.3 (30.3)	238 - 246
Kombi 2.4L DuraTorq-TDCi 103kW (140 PS), Axle ratio: 4.27, 6-speed manual transmission, non DPF	12.8 (22.1) - 12.9 (21.9)	8.1 (34.9) - 8.3 (34.0)	9.8 (28.7) - 10.0 (28.3)	260 - 264
Kombi 2.4L DuraTorq-TDCi 103kW (140 PS), Axle ratio: 4.27, 6-speed manual transmission, with DPF	12.8 (22.1) - 13.1 (21.6)	8.1 (34.9) - 8.5 (33.2)	9.8 (28.7) - 10.2 (27.7)	260 - 269
Kombi 3.2L DuraTorq-TDCi, 147kW (200PS), Axle ratio: 3.58, 6-speed manual transmission	12.9 (21.9) - 13.0 (21.7)	7.9 (35.7) - 8.0 (35.2)	9.8 (29.0) - 9.9 (28.7)	258 - 260

Fuel and refuelling

Variant	Urban	Extra-urban	Combined	CO2 emissions
	l/100 km (mpg)	l/100 km (mpg)	l/100 km (mpg)	g/km
Kombi 3.2L DuraTorq-TDCi, 147kW (200PS), Axle ratio: 4.10, 6-speed manual transmission	14.4 (19.6) - 14.5 (19.5)	8.4 (33.6) - 8.5 (33.2)	10.6 (26.6) - 10.7 (26.4)	280 - 283

Transmission

MANUAL TRANSMISSION


All vehicles

CAUTIONS

- ⚠ Do not engage reverse gear when the vehicle is moving. This can cause damage to the transmission.
- ⚠ Do not apply any undue lateral force to the gear lever when changing from 5th to 4th gear. This could lead to the inadvertent selection of 2nd gear and can cause damage to the transmission.

Selecting reverse gear

On some vehicles it is necessary to raise the collar whilst selecting reverse gear.



E99067

ALL-WHEEL DRIVE (AWD)

CAUTION

- ⚠ A vehicle fitted with AWD must be recovered with either **ALL** wheels on the ground or **ALL** wheels off the ground. See **Vehicle recovery** (page 119).

If the AWD indicator flashes when you are driving, this indicates a malfunction. During a malfunction, the system switches off. Have the system checked by a properly trained technician.

Automatic mode

The AWD system, fitted to certain rear-wheel drive variants, will automatically provide driving torque to the front wheels when road conditions become slippery with rain, snow or ice etc.

When AWD is no longer required the system automatically disengages and normal rear-wheel drive functionality is resumed.

Manual mode

Note: *Your vehicle may exhibit some unusual driving characteristics if manual mode is left activated when driving on normal road surfaces.*

Note: *The manual mode will be automatically deactivated when you exceed a speed of 100 km/h (62 mph).*

If additional traction is required when moving off on an excessively slippery road surface press the AWD switch. For item location. See **Quick start** (page 6). The switch will illuminate.

Press the switch again to return to the automatic mode.

Brakes

PRINCIPLE OF OPERATION

Disc brakes

Wet brake discs result in reduced braking efficiency. Dab the brake pedal when driving from a car wash to remove the film of water.

ABS

WARNING



The ABS does not relieve you of your responsibility to drive with due care and attention.

The ABS helps you to maintain full steering and directional stability when you brake heavily in an emergency, by preventing the road wheels from locking.

HINTS ON DRIVING WITH ABS

When the ABS is operating, the brake pedal will pulse. This is normal. Maintain pressure on the brake pedal.

The ABS will not eliminate the dangers inherent when:

- you drive too close to the vehicle in front of you.
- the vehicle is aquaplaning.
- you take corners too fast.
- the road surface is poor.

PARKING BRAKE

All vehicles

WARNING



Vehicles with an automatic transmission should always be left with the selector lever in position **P**.

- Press the foot brake pedal firmly.
- Pull the parking brake lever up smartly to its fullest extent.
- Do not press the release button while pulling the lever up.
- If your vehicle is parked on a hill and facing uphill, select first gear and turn the steering wheel away from the kerb.
- If your vehicle is parked on a hill and facing downhill, select reverse gear and turn the steering wheel towards the kerb.

To release the parking brake, press the brake pedal firmly, pull the lever up slightly, depress the release button and push the lever down.

Stability control


PRINCIPLE OF OPERATION

Electronic stability programme (ESP)

WARNING



ESP does not relieve you of your responsibility to drive with due care and attention.



E72903

- A without ESP
- B with ESP

The ESP supports stability when the vehicle starts to slide away from your intended path. This is performed by braking individual wheels and reducing engine torque as needed.

The system also provides an enhanced traction control function by reducing engine torque if the wheels spin when you accelerate. This improves your ability to pull away on slippery roads or loose surfaces, and improves comfort by limiting wheel spin in hairpin bends.

Stability control (ESP) warning lamp

The ESP warning lamp will flash when the system is operating. See **Warning lamps and indicators** (page 48).

Emergency brake assist


WARNING



Emergency brake assist does not relieve you of your responsibility to drive with due care and attention.

Emergency brake assist will detect when you brake heavily by measuring the rate at which you press the brake pedal. It will provide maximum braking efficiency as long as you press the pedal. Emergency brake assist can reduce stopping distances in critical situations.

USING STABILITY CONTROL



E78085

With vehicle speed below 60 km/h (37 mph), press and hold the switch for one second. The switch will illuminate.

Note: If you turn the system off, the system will reactivate temporarily if the brakes are applied during a vehicle slide. The ESP warning lamp will flash in this instance.

Note: If you turn the system off, the system will automatically reactivate if your vehicle speed goes above 60 km/h (37 mph).

Stability control

Press the switch again to turn the system on. The system will be switched on automatically every time you switch the ignition on.

For item location: See **Quick start** (page 6).

Hill start assist

PRINCIPLE OF OPERATION

The system makes it easier to pull away when the vehicle is on a slope without the need to use the parking brake.

When the system is active, the vehicle will remain stationary on the slope for two to three seconds after you release the brake pedal. During this time, you have time to move your foot from the brake to the accelerator pedal and pull away. The brakes are released automatically once the engine has developed sufficient drive to prevent the vehicle from rolling down the slope. This is an advantage when pulling away on a slope, for example from a car park ramp, traffic lights or when reversing uphill into a parking space.

WARNING



The system does not replace the parking brake. When you leave the vehicle, always apply the parking brake and select first or reverse gear.

USING HILL START ASSIST

The system is activated automatically when the vehicle is stopped on a slope greater than 3%. The system operates with the vehicle facing downhill if reverse gear is selected and with the vehicle facing uphill if any forward gear is selected.

Activating the system

WARNINGS



You must remain in the vehicle once you have activated the system.



The system is active only if the green lamp illuminates in the instrument cluster. During all times you are responsible for controlling the vehicle, supervising the system and intervening, if required.

You can activate the system only if the following conditions have been met:

- The engine is running.
- All doors (including cargo doors) are fully closed.
- The parking brake is fully disengaged.
- No failure mode is present.

To activate the system:

1. Press the brake and clutch pedals to bring the vehicle to a complete standstill. Keep the brake and clutch pedals depressed.
2. If the sensors detect that the vehicle is on a slope the system will be activated automatically and the green lamp will illuminate in the instrument cluster.
3. When you remove your foot from the brake pedal, the vehicle will remain on the slope without rolling away for approximately two to three seconds. This hold time will automatically be extended if you are in the process of driving off.
4. Drive off in the normal manner. The brakes will be released automatically.

WARNING



If the engine is revved excessively, or if a malfunction is detected when the system is active, the system will be deactivated and the green lamp will go out.

Deactivating the system

To deactivate the system, perform **one** of the following:

- Apply the parking brake.
- Open any door (including cargo doors).
- Drive off uphill without re-applying the brake.

Hill start assist

- Wait for two to three seconds until the system deactivates automatically.
- If the system is active in a forward gear, select reverse gear.
- If the system is active in neutral, release the clutch pedal.
- If the system is active in reverse gear, select neutral.

The green lamp will go out.

Disabling the system

Your dealer can permanently disable this function if required.

Traction control

PRINCIPLE OF OPERATION

The traction control system improves traction when one wheel starts to spin at vehicle speeds up to 40 km/h (25 mph). If a wheel starts to spin, the traction control system varies the pressure to the brake of that wheel until it stops spinning.

USING TRACTION CONTROL

The traction control system is operational when you switch the ignition on.

The traction control indicator will flash when the system is operating. Slowly accelerate until the spinning wheel regains its traction.

The traction control system will stop working temporarily if used excessively within a short period of time. This is normal and has no effect on the brake system.

The traction control system will continue to operate when ESP is switched off. The warning lamp in the instrument cluster will **not** flash in this case.

Parking aid

PRINCIPLE OF OPERATION

WARNING



The parking aid does not relieve you of your responsibility to drive with due care and attention.

CAUTIONS



Vehicles fitted with a trailer tow module not approved by us may not correctly detect obstacles.



The sensors may not detect objects in heavy rain or other conditions that cause disruptive reflections.



The sensors may not detect objects with surfaces that absorb ultrasonic waves.



The parking aid does not detect obstacles moving away from the vehicle. They will only be detected shortly after they start to move towards the vehicle again.



Take particular care when reversing with a tow ball arm or rear fitted accessories e.g. a bicycle carrier, as the rear parking aid will only indicate the distance from the bumper to the obstacle.



If you use a high pressure spray to wash your vehicle, only spray the sensors briefly from a distance not less than 20 centimetres (8 inches).

Note: On vehicles fitted with a tow ball arm, the parking aid is deactivated automatically when any trailer lamps (or lighting boards) are connected to the 13-pin socket via a trailer tow module we have approved.

Note: Keep the sensors free from dirt, ice and snow. Do not clean with sharp objects.

Note: The parking aid may emit false tones if it detects a signal using the same frequency as the sensors or if the vehicle is fully laden.


Note: The outer sensors may detect the side walls of a garage. If the distance between the outer sensor and the side wall remains constant for three seconds, the tone will switch off. As you continue, the inner sensors will detect rearward objects.

USING THE PARKING AID

WARNING



The parking aid does not relieve you of your responsibility to drive with due care and attention.



E77927

The parking aid is automatically activated when you select reverse gear with the ignition switched on.

You will hear an intermittent tone at a distance of approximately 150 centimetres (59 inches) between the obstacle and rear bumper and approximately 50 centimetres (20 inches) to the side. Decreasing the distance accelerates the intermittent tone. A continuous tone will start at a distance of less than 30 centimetres (11 inches) to the rear bumper.

Parking aid

Note: *If a high pitch tone is heard for three seconds, this indicates a malfunction. The system will be disabled. Have the system checked by a properly trained technician.*

Rear view camera

PRINCIPLE OF OPERATION

The camera is a visual aid for use when reversing.

WARNING



The camera does not relieve you of your responsibility to drive with due care and attention.

CAUTIONS



If you use a high pressure spray to wash your vehicle, only spray the camera briefly from a distance not less than 20 centimetres (8 inches).



Do not apply pressure to the camera. The position and the angle of the camera automatically changes.

During operation, guide lines appear in the display which represent your vehicle's path and approximate distance from rearward objects.

USING THE REAR VIEW CAMERA

WARNINGS



The operation of the rear view camera may vary depending on the ambient temperature, vehicle and road conditions.




The distances shown in the display may differ from the actual distance.



Do not place objects in front of the camera.

Note: *Keep the camera free from dirt, ice and snow. Do not clean with sharp objects, degreaser, wax or organic products. Use only a soft cloth.*

Rear view camera



E95058

- A Rear view camera display
- B Rear view camera - liftgate
- C Rear view camera - cargo door

Activating the rear view camera

CAUTION

- ⚠ The camera may not detect objects that are close to the vehicle.

With the ignition switched on, engage the reverse gear. The image is displayed on the screen.

The camera may not operate correctly in the following conditions:

- Dark areas.
- Intense light.
- If the ambient temperature increases or decreases rapidly.
- If the camera is wet, for example in rain or high humidity.
- If the camera's view is obstructed, for example by mud.

Using the display

CAUTIONS

- ⚠ Obstacles above the camera position will not be shown. Inspect the area behind your vehicle if necessary.

Rear view camera

CAUTIONS

⚠ Marks are for general guidance only, and are calculated for vehicles in maximum load conditions on an even road surface.

Note: When reversing with a trailer, the lines on the screen show the vehicle direction and not the trailer.

The lines show a projected vehicle path and the distance from the exterior mirrors and rear bumper.




E100159

- A Exterior mirror clearance - 0.1 metre (4 inches)
- B 0.5 metre (20 inches)
- C 1 metre (39 inches)

Rear view camera

- D 2 metres (79 inches)
- E 3 metres (118 inches)

Switching the rear view camera on and off



E95059

- A On and off button

Press button **A** to manually switch the system off.

Note: The button will only function whilst the reverse gear is selected and the ignition is on.

Deactivating the rear view camera

Note: Disengage reverse gear. The display will stay on for a short period before switching off.

Cruise control

PRINCIPLE OF OPERATION

Cruise control allows you to control your speed using the switches on the steering wheel. You can use cruise control when you exceed 30 km/h (20 mph).

USING CRUISE CONTROL

WARNING



Do not use cruise control in heavy traffic, on twisty roads or when the road surface is slippery.


Switching cruise control on



E75456

Note: The system is ready for you to set a speed.

Setting a speed



E75452

Press to store and maintain your current speed. The cruise control indicator will illuminate. See **Warning lamps and indicators** (page 48).

Changing the set speed


WARNING



When you are going downhill, your speed may increase above the set speed. The system will not apply the brakes. Change down a gear and press the **SET-** switch to assist the system in maintaining the set speed.

Note: If you accelerate by pressing the accelerator pedal, the set speed will not change. When you release the accelerator pedal, you will return to the speed that you previously set.


Cruise control



E95393

- A Accelerate
- B Decelerate

Cancelling the set speed




E75453

Press the brake pedal or the **RES** switch.

Note: The system will no longer control your speed. The cruise control indicator will not illuminate but the system will retain the speed that you previously set.


Resuming the set speed



E75453

The cruise control indicator will illuminate and the system will attempt to resume the speed that you previously set.

Switching cruise control off



E75455

The system will not retain the speed that you previously set. The cruise control indicator will not illuminate.

Automatic speed limiter (ASL)

PRINCIPLE OF OPERATION

Engine speed limiter

Engine speed is limited to protect the engine.

Vehicle speed limiter

The vehicle speed limiter prevents you from driving faster than a programmed speed. See the label on the driver side sun visor for further information.

Vehicles with a diesel engine

You can have the maximum speed of your vehicle limited to a predefined value, providing it is within legal limits. Ask your dealer for further information.

Load carrying

GENERAL INFORMATION

WARNINGS



Use load securing straps to an approved standard, e.g. DIN.



Make sure that you secure all loose items properly.



Place luggage and other loads as low and as far forward as possible within the luggage or loadspace.



Do not drive with the tailgate or rear door open. Exhaust fumes may enter the vehicle.



Do not exceed the maximum front and rear axle loads for your vehicle. See **Vehicle identification** (page

164).

CAUTIONS



Do not allow items to contact the rear windows.



Do not use any abrasive materials to clean the interior of the rear windows.




Do not install stickers or labels to the interior of the rear windows.

LOAD RETAINING FIXTURES

Note: *The number of load retaining fixtures may vary depending on your vehicle model.*

Load carrying

Securing cargo




E75510

Load carrying

Supplementary retaining fixtures


Mid-height cargo rail



E77500

ROOF RACKS AND LOAD CARRIERS

Roof rack



E71359

WARNINGS

 No roof load is permitted on bus models with a long wheel base, single rear wheel, 13, 14 or 15 seats and a 200PS diesel engine.

 No roof load is permitted on bus models with a long wheel base, single rear wheel, 13, 14 or 15 seats and a 140PS diesel engine with all-wheel drive.

WARNINGS

 If you use a roof rack, the fuel consumption of your vehicle will be higher and you may experience different driving characteristics.

 Read and follow the manufacturer's instructions when you are fitting a roof rack.

CAUTIONS

 Do not exceed the maximum axle load for your vehicle. See **Vehicle identification** (page 164).

 Do not exceed the maximum permissible roof load of 100 kilogrammes, or 50 kilogrammes for Euroline and Nugget vehicles (including the roof rack).

Check the security of the roof rack and its fittings as follows:

- before starting
- after driving 50 kilometres (30 miles)
- at 1 000 kilometres (600 miles) intervals.

Vehicles with an emergency exit

See **Emergency exit** (page 106).

Towing

TOWING A TRAILER

WARNINGS



Do not exceed the maximum vehicle and trailer weight stated on the vehicle identification plate. See

Vehicle identification (page 164).



Do not exceed a speed of 90 km/h (55 mph) when towing with a laden weight greater than 2 000kg.

Note: *Not all vehicles are suitable or approved to have tow bars fitted. Check with your dealer first.*

Place loads as low and central to the axle(s) of the trailer as possible. If you are towing with an unladen vehicle, the load in the trailer should be placed toward the nose, within the maximum nose load, as this gives the best stability.

Note: *The maximum trailer nose weight can be found in the original vehicle documents (confirmation of conformity). Alternatively refer to your dealer.*

The stability of the vehicle to trailer combination is very much dependant on the quality of the trailer.

The maximum vehicle and trailer weights represent technically binding values for gradients up to 12 % and at an altitude of 1 000 metres above sea level. In high altitude regions, thinner atmosphere can reduce engine performance so the following restrictions will apply:

In high altitude regions above 1 000 metres (3 281 feet), the stipulated maximum permitted gross train weight must be reduced by 10% for every additional 1 000 metres (3 281 feet).

Steep gradients

WARNING



The overrun brake on a trailer is not controlled by ABS.

Change down a gear before you reach a steep downhill gradient.

Driving hints

RUNNING-IN

Tyres

WARNING



New tyres need to be run-in for approximately 500 kilometres (300 miles). During this time, you may experience different driving characteristics.

Brakes and clutch

WARNING



Avoid heavy use of the brakes and clutch if possible for the first 150 kilometres (100 miles) in town and for the first 1 500 kilometres (1 000 miles) on motorways.

Engine

CAUTION



Avoid driving too fast during the first 1 500 kilometres (1 000 miles). Vary your speed frequently and change up through the gears early. Do not labour the engine.

COLD WEATHER PRECAUTIONS

The functional operation of some components and systems can be affected at temperatures below -30°C (-22°F).

REDUCED ENGINE PERFORMANCE

Your vehicle can be driven briefly if the engine overheats, without damage to the engine. The engine will continue to operate with limited power. The distance you can travel depends on ambient temperature, vehicle load, and terrain.

If the needle moves to the upper limit position, the engine is overheating. See **Gauges** (page 46).

If the temperature continues to rise, the fuel supply to the engine will be reduced. The air conditioning (if fitted) will also be turned off and the engine cooling fan will operate.

CAUTION



Continued operation will increase the engine temperature, and cause the engine to shut down completely.

- Stop your vehicle as soon as possible.
- Immediately turn off the engine to prevent severe engine damage.
- Wait for the engine to cool down.
- Check the coolant level. See **Engine coolant check** (page 128).
- Have the vehicle checked by an expert immediately.

Emergency equipment

FIRST AID KIT

Bus

Space for a first aid kit is located underneath the second row seat.

Van, Kombi, Chassis cab, Flatbed truck

Space for a first aid kit is located in the driver's side door bin.

WARNING TRIANGLE

You will find a space for storing a warning triangle in driver side door bin.

EMERGENCY EXIT

WARNING




Make sure that the roof rack and its load do not obstruct the emergency exit. Ask your dealer for advice on roof racks suitable for your vehicle.

Break the glass with the hammer in an emergency.

Status after a collision

FUEL CUT-OFF SWITCH



E71360

If you have an accident or a minor collision (e.g. collision when parking), the fuel cut-off switch may stop the fuel supply. The switch is located on the side panel in front of the passenger side front door.

Resetting the fuel cut-off switch

WARNING



Do not reset the fuel cut-off switch if you see or smell fuel.

- Switch the ignition off.
- Check the fuel system for leaks.
- Press the top of the cut-off switch to reset.
- Switch the ignition on and, after a few seconds, turn the key to position **I**.
- Check the fuel system again for leaks.

INSPECTING SAFETY SYSTEM COMPONENTS


Seat belts

Belts subjected to strain, as a result of an accident, should be renewed and the anchorages checked by a properly trained technician.

Fuses


FUSE BOX LOCATIONS

Right-hand drive



E70864

Left-hand drive



E91162

- A Pre-fuse box
- B Standard relay box
- C Passenger compartment junction box
- D Engine compartment junction box


Pre-fuse box

Driver seat




E70866

Standard relay box




E70869

Fuses




E70868

Passenger junction box




E70869



E70870

Note: When refitting, make sure you hear a click when engaging both clips.

Engine junction box



E70867

For item location: See **Maintenance** (page 121).

Fuses

CHANGING A FUSE

WARNINGS



Do not modify the electrical system of your vehicle in any way. Have repairs to the electrical system and the replacement of relays and high current fuses carried out by properly trained technicians.



Switch the ignition and all electrical equipment off before touching or attempting to change a fuse.

CAUTION




Fit a replacement fuse with the same rating as the one you have removed.

Note: You can identify a blown fuse by a break in the filament.

Note: All fuses, except high current fuses, are a push fit.

FUSE SPECIFICATION CHART

Pre-fuse box



E70871


Fuse	Ampere rating	Colour	Circuits protected
1	350	grey	Starter motor and alternator
2	60	yellow	Passenger junction box power supply - start relevant

Fuses

Fuse	Ampere rating	Colour	Circuits protected
3	100	blue	Engine junction box power supply - non-start relevant
4	40	green	Heated front screen right-hand side
5	100	blue	Standard relay box power supply - non-start relevant
6	40	green	Heated front screen left-hand side
7	60	yellow	Passenger junction box power supply - non-start relevant
8	60	yellow	Customer connection point
9	60	yellow	Customer connection point
10	60	yellow	Customer connection point

Relay	Circuits switched
R1	Battery disconnect switch

Engine junction box



E70872

Fuses

Fuse	Ampere rating	Colour	Circuits protected
11	60	yellow	Engine cooling fan
12	30	pink	Trailer tow and trailer tow module power supply (KL30)
13	40	green	ABS and ESP pump
14	-	-	Not used
15	60	yellow	Glow plugs
16	60	yellow	Ignition relay (KL15 #3)
17	30	pink	Starter enable
18	40	green	Ignition feed (KL15) to Passenger junction box
19	-	-	Not used
20	10	red	ABS, ESP, steering angle sensor, YAW sensor supply (KL30)
21	25	natural	ABS and ESP valves and control unit
22	20	yellow	PCM power relay
23	20	yellow	Trailer tow power supply (KL15)
24 Diesel	20	yellow	Additional heater, programmable fuel-fired booster heater
24 Petrol	20	yellow	Fuel pump
25	5	tan	Battery-fed relay coils
26	15	blue	PCM Power
27	7.5	brown	Glow plug monitoring

Fuses


Fuse	Ampere rating	Colour	Circuits protected
28 Diesel	5	tan	T-MAF sensor
28 Petrol	15	blue	Catalyst monitoring system and HEGO sensors
29	5	tan	Water in fuel sensor (Diesel only) , power supply relay coils
30	10	red	Sonic purge valve, injector valves (Petrol only)
31	5	tan	Vehicle speed sensor
32 Diesel	20	yellow	Vaporiser glow plug
32 Petrol	20	yellow	Coil on plug ignition module
33	10	red	Reversing lamps
34	-	-	Not used
35	5	tan	Additional heater (KL15)
36	10	red	Air conditioning clutch
37	5	tan	Ignition-fed relay coils, PCM ignition run key sense

Relay	Circuits switched
R2	Glow plugs
R3	Trailer tow (KL15)
R4	Starter enable
R5	Power feed (KL15 #4)
R6	Power feed (KL15 #3)

Fuses

Relay	Circuits switched
R7 Diesel	Vaporiser glow plug
R7 Petrol	Fuel pump
R8	Powertrain control module power
R9	Not used
R10	Air conditioning clutch solenoid

Standard relay box



Fuse	Ampere rating	Colour	Circuits protected
38	20	yellow	Rear window wiper
39	10	red	Front and rear air conditioning control
40	5	tan	Relay coils supply

Fuses


Fuse	Ampere rating	Colour	Circuits protected
41	5	tan	Tachograph
42	5	tan	Headlamp levelling, master light switch (KL15)
43	20	yellow	Heated front seats
44	20	yellow	Horn
45	20	yellow	Auxiliary power point front
46	10	red	Heated door mirrors, if CAT 1 fitted
47	20	yellow	Cigar lighter
48	5	tan	Relay coils supply, power mirrors
49	20	yellow	Auxiliary power point rear
50	10	red	Main beam left-hand side
51	10	red	Main beam right-hand side
52	10	red	Dipped beam left-hand side
53	10	red	Dipped beam right-hand side
54	30	pink	Pre-fuse for dipped beam, main beam, daytime running lamps, tachograph, fuel-fired booster heater blower
55	40	green	Heater blower motor
56	20	yellow	Power windows
57	30	pink	Rear heater blower motor
58	30	pink	Front wiper motor
59	30	pink	Heated rear window, heated door mirrors
60	-	-	Not used
61	60	yellow	Ignition relay (KL15 #1)
62	60	yellow	Ignition relay (KL15 #2)

Fuses

Relay	Circuits switched
R11	Headlamp dip beam
R12	Heated door mirrors (if CAT 1 alarm is fitted)
R13	Headlamp main beam
R14	Horn
R15	Daytime running lamps
R16	Programmable fuel fired heater
R17	Heated rear windows and heated door mirrors (or heated rear window left-hand side if Cat 1 alarm is fitted)
R18	Heated rear window right-hand side if Cat 1 alarm is fitted
R19	Power feed (KL15 #2)
R20	Reserved for special vehicle operation use
R21	Power feed (KL15 #1)
R22	Heated windscreen right-hand side
R23	Windscreen wiper high and low function
R24	Rear window wiper
R25	Windscreen wiper on and off function
R26	Heated windscreen left-hand side

Fuses

Passenger junction box



E70874

Fuse	Ampere rating	Colour	Circuits protected
63	5	tan	Rear parking aid, rain sensor
64	2	grey	Acceleration pedal demand sensor
65	15	blue	Brake lamp switch
66	5	tan	Instrument cluster, PATS supply, tachograph, instrument panel switch illumination
67	15	blue	Washer pump
68	10	red	Restraints control module
69	20	yellow	Exterior lamp switch (KL15)
70	20	yellow	Battery backed sounder
71	5	tan	Exterior lamp switch (KL30)
72	10	red	Battery saver supply, OBDII (KL30)
73	15	blue	Radio, navigation unit and phone supply

Fuses


Fuse	Ampere rating	Colour	Circuits protected
74	5	tan	Instrument cluster, fuel-fired booster heater timer, remote keyless entry supply, interior motion sensor (KL30)
75	7.5	brown	Side lamps right-hand side
76	7.5	brown	Side lamps left-hand side
77	5	tan	Ignition switch supply, battery disconnect switch coils supply
78	15	blue	Central locking
79	7.5	brown	Number plate lamp, side markers
80	15	blue	Front fog lamps
81	10	red	Rear fog lamps
82	3	violet	Audio and instrument cluster ignition feed

Auxiliary fuses

Fuse	Ampere rating	Colour	Circuits protected	Location
83	10	red	Trailer tow module	Left-hand side foot-well
84	7.5	brown	DPF glow plug sensing	Below the engine compartment junction box

Vehicle recovery

TOWING POINTS



E71361

- A Front towing eye
- B Rear towing eye (Van, Bus and Kombi)
- C Rear towing eye (Chassis Cab and Flatbed truck)

TOWING THE VEHICLE ON FOUR WHEELS

All vehicles

WARNINGS

 Switch the ignition on when your vehicle is being towed. The steering lock will engage and the direction indicators and brake lamps will not work if you do not.

WARNINGS

 The brake servo and the power steering pump do not operate unless the engine is running. Press the brake pedal harder and allow for increased stopping distances and heavier steering.

CAUTIONS

-  Too much tension in the tow rope could cause damage to your vehicle or the vehicle that is towing.
-  Do not use a rigid tow bar on the front towing eye.

Drive off slowly and smoothly without jerking the vehicle that is towing.

Vehicles with automatic transmission

CAUTIONS

-  Do not tow your vehicle faster than 50 km/h (30 mph) or further than 50 kilometres (30 miles).
-  If a speed of 50 km/h (30 mph) and a distance of 50 kilometres (30 miles) is to be exceeded the drive wheels must be lifted clear of the ground.
-  In the event of a mechanical failure of the transmission the drive wheels must be lifted clear of the ground.
-  Do not tow your vehicle backwards.
-  Select neutral when your vehicle is being towed.

Vehicle recovery

TOWING THE VEHICLE ON FOUR WHEELS - AWD

WARNINGS



Switch the ignition on when your vehicle is being towed. The steering lock will engage and the direction indicators and brake lamps will not work if you do not.



The brake servo and the power steering pump do not operate unless the engine is running. Press the brake pedal harder and allow for increased stopping distances and heavier steering.

CAUTIONS



Too much tension in the tow rope could cause damage to your vehicle or the vehicle that is towing.



Do not use a rigid tow bar on the front towing eye.



In the event of a breakdown or a mechanical failure of the transmission your vehicle must be recovered with either **ALL** wheels on the ground or transported with **ALL** wheels off the ground.

Drive off slowly and smoothly without jerking the vehicle that is towing.

Maintenance

GENERAL INFORMATION

Have your vehicle serviced regularly to help maintain its roadworthiness and resale value. There is a large network of Ford Authorised Repairers that are there to help you with their professional servicing expertise. We believe that their specially trained technicians are best qualified to service your vehicle properly and expertly. They are supported by a wide range of highly specialised tools developed specifically for servicing your vehicle.

In addition to regular servicing, we recommend that you carry out the following additional checks.

WARNINGS



Switch the ignition off before touching or attempting adjustment of any kind.



Do not touch the electronic ignition system parts after you have switched the ignition on or when the engine is running. The system operates at high voltage.



Keep your hands and clothing clear of the engine cooling fan. Under certain conditions, the fan may continue to run for several minutes after you have switched the engine off.

- Washer fluid level. See **Washer fluid check** (page 131).
- Tyre pressures (when cold). See **Technical specifications** (page 157).
- Tyre condition. See **Tyre care** (page 155).

Monthly checks

- Engine coolant level (engine cold). See **Engine coolant check** (page 128).
- Pipes, hoses and reservoirs for leaks.
- Power steering fluid level. See **Power steering fluid check** (page 129).
- Air conditioning operation.
- Parking brake operation.
- Horn operation.
- Tightness of wheel nuts. See **Technical specifications** (page 157).
- Fuel filter service indicator check. See **Fuel filter service indicator check** (page 130).

Daily checks

- Exterior lamps.
- Interior lamps.
- Warning lamps and indicators.


Check when refuelling

- Engine oil level. See **Engine oil check** (page 127).
- Brake fluid level. See **Brake and clutch fluid check** (page 129).


Maintenance

OPENING AND CLOSING THE BONNET

Opening the bonnet



E72108



E72109


Closing the bonnet

Note: Make sure that the bonnet is closed properly.

Lower the bonnet and allow it to drop from under its own weight for the last 20–30 centimetres.

Maintenance

ENGINE COMPARTMENT OVERVIEW - 2.3L DURATEC-HE (MI4)



E70606

- A Brake and clutch fluid reservoir (right-hand drive). See **Brake and clutch fluid check** (page 129).
- B Engine oil filler cap¹. See **Engine oil check** (page 127).
- C Brake and clutch fluid reservoir (left-hand drive). See **Brake and clutch fluid check** (page 129).
- D Battery positive connection (for connecting booster cables). See **Vehicle battery** (page 136).
- E Engine coolant reservoir. See **Engine coolant check** (page 128).
- F Washer fluid reservoir. See **Washer fluid check** (page 131).
- G Engine junction box. See **Fuses** (page 108).


Maintenance

H Power steering fluid reservoir. See **Power steering fluid check** (page 129).

I Engine oil dipstick¹. See **Engine oil check** (page 127).

¹ The filler caps and the engine oil dipstick are coloured for easy identification.

ENGINE COMPARTMENT OVERVIEW - 2.2L DURATORQ-TDCI (PUMA) DIESEL



E70605

A Fuel filter water trap (left-hand drive). See **Draining the fuel filter water trap** (page 129).

A Brake and clutch fluid reservoir (right-hand drive). See **Brake and clutch fluid check** (page 129).


Maintenance

- B Engine oil filler cap¹. See **Engine oil check** (page 127).
- C Brake and clutch fluid reservoir (left-hand drive). See **Brake and clutch fluid check** (page 129).
- C Fuel filter water trap (right-hand drive). See **Draining the fuel filter water trap** (page 129).
- D Engine coolant reservoir. See **Engine coolant check** (page 128).
- E Washer fluid reservoir. See **Washer fluid check** (page 131).
- F Engine junction box. See **Fuses** (page 108).
- G Battery positive connection (for connecting booster cables). See **Vehicle battery** (page 136).
- H Engine oil dipstick¹. See **Engine oil check** (page 127).
- I Power steering fluid reservoir. See **Power steering fluid check** (page 129).

¹ The filler caps and the engine oil dipstick are coloured for easy identification.

Maintenance

ENGINE COMPARTMENT OVERVIEW - 3.2L DURATORQ-TDCI (PUMA) DIESEL/2.4L DURATORQ-TDCI (PUMA) DIESEL



E70607


- A Fuel filter water trap (left-hand drive). See **Draining the fuel filter water trap** (page 129).
- A Brake and clutch fluid reservoir (right-hand drive). See **Brake and clutch fluid check** (page 129).
- B Engine oil dipstick¹. See **Engine oil check** (page 127).
- C Engine oil filler cap¹. See **Engine oil check** (page 127).
- D Brake and clutch fluid reservoir (left-hand drive). See **Brake and clutch fluid check** (page 129).
- D Fuel filter water trap (right-hand drive). See **Draining the fuel filter water trap** (page 129).
- E Engine coolant reservoir. See **Engine coolant check** (page 128).

Maintenance


- F Washer fluid reservoir. See **Washer fluid check** (page 131).
- G Engine junction box. See **Changing a fuse** (page 110).
- H Battery positive connection (for connecting booster cables). See **Using booster cables** (page 136).
- I Power steering fluid reservoir. See **Power steering fluid check** (page 129).

¹ The filler caps and the engine oil dipstick are coloured for easy identification.


ENGINE OIL DIPSTICK - 2.3L DURATEC-HE (MI4)



ENGINE OIL DIPSTICK - 2.2L DURATORQ-TDCI (PUMA) DIESEL



ENGINE OIL DIPSTICK - 3.2L DURATORQ-TDCI (PUMA) DIESEL/2.4L DURATORQ-TDCI (PUMA) DIESEL



ENGINE OIL CHECK

CAUTION

⚠ Do not use oil additives or other engine treatments. Under certain conditions, they could damage the engine.

Note: The oil consumption of new engines reaches its normal level after approximately 5 000 kilometres (3 000 miles).

Maintenance

Checking the oil level

CAUTION

 Make sure that the level is between the **MIN** and the **MAX** marks.

Note: Check the level before starting the engine.

Note: Make sure that your vehicle is on level ground.

Note: Oil expands when it is hot. The level may therefore extend a few millimetres beyond the **MAX** mark.

Remove the dipstick and wipe it with a clean, lint free cloth. Replace the dipstick and remove it again to check the oil level.

If the level is at the **MIN** mark, top up immediately.

Topping up

WARNINGS

 Only top up when the engine is cold. If the engine is hot, wait 10 minutes for the engine to cool down.

 Do not remove the filler cap when the engine is running.

Remove the filler cap.

CAUTION

 Do not top up further than the **MAX** mark.

Top up with fluid that meets the Ford specification. See **Technical specifications** (page 131).

ENGINE COOLANT CHECK

Checking the coolant level

WARNING

 Do not allow the fluid to touch your skin or eyes. If this happens, rinse the affected areas immediately with plenty of water and contact your doctor.

CAUTION

 Make sure that the level is between the **MIN** and the **MAX** marks.

Note: Coolant expands when it is hot. The level may therefore extend beyond the **MAX** mark.

If the level is at the **MIN** mark, top up immediately.

Topping up

WARNINGS

 Only top up when the engine is cold. If the engine is hot, wait 10 minutes for the engine to cool down.

 Do not remove the filler cap when the engine is running.

 Do not remove the filler cap when the engine is hot. Wait for the engine to cool down.

Unscrew the cap **slowly**. Any pressure will escape slowly as you unscrew the cap.

CAUTIONS

 Do not spill coolant on any part of the engine.

 Do not top up further than the **MAX** mark.

Maintenance

Top up with fluid that meets the Ford specification. See **Technical specifications** (page 131).

BRAKE AND CLUTCH FLUID CHECK

WARNINGS



Do not allow the fluid to touch your skin or eyes. If this happens, rinse the affected areas immediately with plenty of water and contact your doctor.



If the level is at the **MIN** mark, have the system checked by a properly trained technician as soon as possible.

Note: *The brake and the clutch systems are supplied from the same reservoir.*

Top up with fluid that meets the Ford specification. See **Technical specifications** (page 131).

POWER STEERING FLUID CHECK

WARNING



Do not allow the fluid to touch your skin or eyes. If this happens, rinse the affected areas immediately with plenty of water and contact your doctor.

CAUTION



Make sure that the level is between the **MIN** and the **MAX** marks.

If the level is at the **MIN** mark, top up immediately.

Topping up

Remove the filler cap.

CAUTION



Do not top up further than the **MAX** mark.

Top up with fluid that meets the Ford specification. See **Technical specifications** (page 131).

DRAINING THE FUEL FILTER WATER TRAP

Vehicles with a diesel engine

WARNING





Do not dispose of diesel in household refuse or the public sewage system. Use your local authorised waste disposal facilities.

Note: *With the engine running, the water-in-fuel indicator lamp will go out after approximately 2 seconds.*

Note: *Only add fuel that meets the Ford specification. See **Fuel and refuelling** (page 79).*

Maintenance


FUEL FILTER SERVICE INDICATOR CHECK



E66659

- A green
- B clear
- C red

1. Switch the ignition off.
2. Press and hold the yellow button for three seconds.
3. Start the engine. Fully depress the accelerator pedal for five seconds.
4. Check the position of the plunger in the service indicator.



E77043

1. Disconnect the electrical connector.
2. Attach a suitable hose to the sensor drain and direct the hose into a suitable container.
3. Unscrew the sensor one to two turns and allow the water to drain.

Install in the reverse order.

Maintenance

- Green - no need to change the filter.
- Clear - replace the filter at the next service interval.
- Red - the filter **must** be replaced. Have this checked by a properly trained technician immediately.

WASHER FLUID CHECK

The front and rear washer systems are supplied from the same reservoir.

TECHNICAL SPECIFICATIONS

Vehicle fluids

CAUTION



Do not use oils which do not meet the specifications or requirements. Use of unsuitable oil may lead to engine damage which is not covered by your Warranty.

Part	Recommended fluid	Specification
Engine oil	Castrol Engine Oil ³	WSS-M2C913-C
Power assisted steering	Ford or Motorcraft Power Steering Fluid (green) ²	WSS-M2C204-A2
Power assisted steering	Ford or Motorcraft Power Steering Fluid (red) ²	WSA-M2C195-A
Coolant	Motorcraft SuperPlus Anti-freeze	WSS-M97B44-D
Brake fluid	Ford or Motorcraft Super DOT 4 Brake Fluid	ESD-M6C57-A
Rear axle ¹	Ford Hypoid Oil	WSS-M2C939A

¹ Under normal operating conditions the rear axle requires no maintenance. However, in the event the rear axle becomes submerged under water, have the fluid changed by your dealer.

² Always top up with the same colour fluid.

³ Providing it meets the specification defined by **WSS-M2C913-C**, you can also use Ford Engine Oil or an alternative engine oil.

Note: If you operate your vehicle in temperatures below -20°C, you must not use **SAE 10W-40** engine oil.

Maintenance

Topping up the oil: If you are unable to find an oil that meets the specification defined by **WSS-M2C913-C**, you must use **SAE 5W-30** (preferred), **SAE 5W-40** or **SAE 10W-40** that meets the specification defined by either **ACEA A5/B5** (preferred) or **ACEA A3/B3**. Using these oils can result in longer engine cranking periods, reduced engine performance, reduced fuel economy and increased emission levels.

Castrol engine oil recommended.



Capacities

Variant	Item	Capacity in litres (gallons)
All	Power assisted steering fluid	MAX-mark
All	Windscreen washer system	5.5 (1.2)
All - Normal capacity	Fuel tank	80 (17.6)
Increased capacity	Fuel tank	103 (22.7)
2.3L Duratec-HE	Engine oil – with filter	4.3 (1.0)
2.3L Duratec-HE	Engine oil – without filter	3.9 (0.9)
2.3L Duratec-HE	Cooling system with auxiliary heater	10.1 (2.2)
2.3L Duratec-HE	Cooling system with front heater only	7.8 (1.7)
2.2L DuraTorq-TDCi	Engine oil – with filter	6.2 (1.4)
2.2L DuraTorq-TDCi	Engine oil – without filter	5.9 (1.3)
2.4L DuraTorq-TDCi	Engine oil – with filter	6.9 (1.5)
2.4L DuraTorq-TDCi	Engine oil – without filter	6.5 (1.4)
2.2L and 2.4L DuraTorq-TDCi	Cooling system with fuel fired heater and auxiliary heater	13 (2.9)
2.2L and 2.4L DuraTorq-TDCi	Cooling system with auxiliary heater	12.8 (2.9)

Maintenance

Variant	Item	Capacity in litres (gallons)
2.2L and 2.4L DuraTorq-TDCi	Cooling system with fuel fired heater	11.5 (2.5)
2.2L and 2.4L DuraTorq-TDCi	Cooling system with front heater only	10 (2.2)
3.2L DuraTorq-TDCi	Engine oil – with filter	11.4 (2.5)
3.2L DuraTorq-TDCi	Engine oil – without filter	11 (2.4)
3.2L DuraTorq-TDCi	Cooling system	7.3 (1.6)

Engine oil top up capacities

Engine	Capacity in litres (gallons)
2.3L Duratec-HE	0.7 (0.2)
2.2L DuraTorq-TDCi	1.5 (0.3)
2.4L DuraTorq-TDCi	2 (0.4)
3.2L DuraTorq-TDCi	2.5 (0.6)

Vehicle care

CLEANING THE EXTERIOR

WARNING



If you use a car wash with a waxing cycle, make sure that you remove the wax from the windscreen.

CAUTIONS



Some car wash installations use water at high pressure. This could damage certain parts of your vehicle.



Remove the aerial before using an automatic car wash.



Switch the heater blower off to prevent contamination of the fresh air filter.

We recommend that you wash your vehicle with a sponge and lukewarm water containing a car shampoo.

Cleaning the headlamps

CAUTIONS



Do not scrape the headlamp lenses or use abrasives, alcoholic solvents or chemical solvents to clean them.



Do not wipe the headlamps when they are dry.

Cleaning the rear window

CAUTION



Do not scrape the inside of the rear window or use abrasives or chemical solvents to clean it.

Use a clean, lint free cloth or a damp chamois leather to clean the inside of the rear window.

Cleaning the chrome trim

CAUTION



Do not use abrasives or chemical solvents. Use soapy water.

Body paintwork preservation

CAUTIONS



Do not polish your vehicle in strong sunshine.



Do not allow polish to touch plastic surfaces. It could be difficult to remove.



Do not apply polish to the windscreen or rear window. This could cause the wipers to become noisy and they may not clear the window properly.

We recommend that you wax the paintwork once or twice a year.

CLEANING THE INTERIOR

Seat belts

WARNINGS



Do not use abrasives, or chemical solvents to clean them.



Do not allow moisture to penetrate the seat belt retractor mechanism.

Clean the seat belts with interior cleaner or water applied with a soft sponge. Let the seat belts dry naturally, away from artificial heat.

Instrument cluster screens, LCD screens, radio screens

WARNING



Do not use abrasives, alcoholic solvents or chemical solvents to clean them.

REPAIRING MINOR PAINT DAMAGE

CAUTION



Remove apparently harmless looking substances from the paintwork immediately (e.g. bird droppings, tree resins, insect remains, tar spots, road salt and industrial fall out).

You should repair paintwork damage caused by stones from the road or minor scratches as soon as possible. A choice of products is available from your Ford Dealer. Read and follow the manufacturer's instructions.


Vehicle battery

USING BOOSTER CABLES

CAUTIONS

- ❗ Connect batteries with only the same nominal voltage.
- ❗ Always use booster cables with insulated clamps and adequate size cable.
- ❗ Do not disconnect the battery from the vehicle's electrical system.


To connect the booster cables



E75524

- A Flat battery vehicle
- B Booster battery vehicle
- 1 Positive connection cable
- 2 Negative connection cable

1. Position the vehicles so that they do not touch one another.
2. Switch off the engine and any electrical equipment.



E71368

3. Lift up the battery positive connection point cover. For item location, refer to the appropriate engine compartment overview. See **Maintenance** (page 121).
4. Connect the positive (+) terminal of vehicle **A** with the positive (+) terminal of vehicle **B** (cable **1**).
5. Connect the negative (-) terminal of vehicle **B** to the engine block or the engine mount of vehicle **A** (cable **2**).

CAUTIONS

- ❗ **Do not connect to the negative (-) terminal of the flat battery.**
- ❗ Make sure that the cables are clear of any moving parts.

To start the engine

1. Run the engine of vehicle **B** at moderately high speed.
2. Start the engine of vehicle **A**.
3. Run both vehicles for a minimum of three minutes before disconnecting the cables.

Vehicle battery

CAUTION

- ⚠ Do not switch on the headlamps when disconnecting the cables. The peak voltage could blow the bulbs.

Disconnect the cables in the reverse order.


CHANGING THE VEHICLE BATTERY

CAUTION

- ⚠ Make sure the battery box is correctly sealed.

Note: The battery is located inside the vehicle under the driver's seat.

Note: Where applicable, the audio system must be reprogrammed with the keycode.




E66643

1. Turn the safety pin anti-clockwise and take it out.
2. Remove the battery cover.
3. Slide the seat fully forwards. See **Front seats** (page 67).

Install in the reverse order.

BATTERY CONNECTION POINTS



E75702

CAUTION

- ⚠ Do not connect any electrical items directly to the vehicle batteries.

There are three connection points available, each provides a maximum of 60A current. Ask your dealer for advice on accessories suitable for your vehicle.

1. Release the clips.
2. Raise the cover.

Child safety

CHILD SEATS



E68916

WARNINGS

 Secure children that are less than 150 centimetres tall or less than 12 years of age in a suitable, approved child restraint, in the rear seat.

 Original text according to ECE R94.01: Extreme Hazard! Do not use a rearward facing child restraint on a seat protected by an air bag in front of it!

 Read and follow the manufacturer's instructions when you are fitting a child restraint.

 Do not modify child restraints in any way.

 Do not hold a child on your lap when the vehicle is moving.

 Do not leave unattended children in your vehicle.

 If your vehicle has been involved in an accident, have the child restraints checked by properly trained technicians.

Note: *Mandatory use of child restraints varies from country to country.*

Only child restraints certified to ECE-R44.03 (or later) have been tested and approved for use in your vehicle. A choice of these are available from your Dealer.

Child restraints for different mass groups

Use the correct child restraint as follows:

Baby safety seat



E68918

Secure children that weigh less than 13 kilograms in a rearward facing baby safety seat (Group 0+) in the rear seat.

Child safety

Child safety seat



E68920

Secure children that weigh between 13 and 18 kilograms in a child safety seat (Group 1) in the rear seat.

CHILD SEAT POSITIONING

Child seat positions

WARNING



When fitting a child seat using the vehicle seat belts make sure the belts are not slack.

Seating positions	Mass group categories				
	0	0+	1	2	3
	Up to 10 kg	Up to 13 kg	9 - 18 kg	15 - 25 kg	22 - 36 kg
	Baby safety seat	Baby safety seat	Child safety seat	Booster seat or cushion	Booster seat or cushion
Front passenger seat with airbag	X	X	X	X	X
Front passenger seat without airbag	U ¹	U ¹	U ¹	U ¹	U ¹
Rear seats	U	U	U	U	U
Rear ISOFIX 2nd row	IU	IU	IU	X	X

Child safety

Seating positions	Mass group categories				
	0	0+	1	2	3
	Up to 10 kg	Up to 13 kg	9 - 18 kg	15 - 25 kg	22 - 36 kg
	Baby safety seat	Baby safety seat	Child safety seat	Booster seat or cushion	Booster seat or cushion
ISOFIX size class*	E	C, D, E	A, B, B1, C, D	X	X

X Not suitable for children in this mass group.

U Suitable for universal category child restraints approved for use in this mass group.

IU Suitable for universal category ISOFIX child restraints approved for use in this mass group.

U¹ Suitable for universal category child restraints approved for use in this mass group.

* As defined by ECE 16.

Child safety

BOOSTER CUSHIONS

WARNINGS

-  Do not install a booster seat or a booster cushion with only the lap strap of the seat belt.
-  Do not install a booster seat or a booster cushion with a seat belt that is slack or twisted.
-  Do not put the seat belt under your child's arm or behind its back.
-  Do not use pillows, books or towels to boost your child's height.
-  Make sure that your children sit in an upright position.
-  Secure children that weigh more than 15 kilograms but are less than 150 centimetres tall in a booster seat or a booster cushion.

CAUTION

-  When using a child seat on a rear seat, make sure that the child seat rests tightly against the vehicle seat. It may be necessary to lift or remove the head restraint. See **Head restraints** (page 70).

Booster seat (Group 2)



E70710

We recommend that you use a booster seat that combines a cushion with a backrest instead of a booster cushion only. The raised seating position will allow you to position the shoulder strap of the adult seat belt over the centre of your child's shoulder and the lap strap tightly across its hips.


Booster cushion (Group 3)



E68924

Child safety

ISOFIX ANCHOR POINTS



E68945

WARNING


 Use an anti-rotation device when using the ISOFIX system. We recommend that you use a top tether or a support leg.

Note: When you are purchasing an ISOFIX restraint, make sure that you know the correct mass group and ISOFIX size class for the intended seating locations. See **Child seat positioning** (page 139).

Your vehicle is fitted with ISOFIX anchor points that accommodate universally approved ISOFIX child restraints.

The ISOFIX system comprises two rigid attachment arms on the child restraint that attach to anchor points on the 2nd row seats, where the cushion and backrest meet. Tether anchor points are fitted to the rear of the 2nd row seats for child restraints with a top tether.

Attaching a child restraint with a top tether



E68946


WARNING

 Do not attach a tether strap to anything other than the correct tether anchor point.

CHILD SAFETY LOCKS

WARNING

 You cannot open the doors from inside if you have put the child safety locks on.



E74584

Left-hand side

Turn clockwise to lock and anti-clockwise to unlock.

Right-hand side

Turn anti-clockwise to lock and clockwise to unlock.

Wheels and tyres

GENERAL INFORMATION

CAUTIONS

❗ Use only approved wheel and tyre sizes. Using other sizes could damage the vehicle and will make the National Type Approval invalid.

❗ If you change the diameter of the tyres from that fitted at the factory, the speedometer may not display the correct speed. Take the vehicle to your dealer to have the engine management system reprogrammed.

A decal with tyre pressure data is located in the driver's door opening at the B-pillar.

Check and set the tyre pressure at the ambient temperature in which you are intending to drive the vehicle and when the tyres are cold.

Set the pressure for your spare tyre to the highest value given for your vehicle and tyre size combination.

Data about tyres, rims and tyre pressures for special vehicle model variants is only given on the tyre pressure decal on these vehicles.

CHANGING A ROAD WHEEL

Locking wheel nuts

You can obtain a replacement locking wheel nut key and replacement locking wheel nuts from your dealer using the reference number certificate.

Spare wheel


The spare wheel is located underneath the rear of the vehicle.

Single rear wheel vehicles



E70947

Double rear wheel vehicles




E70948

If your vehicle has a security bolt, remove it by turning anti-clockwise.

Fully insert the flat end of the wheel brace (Bus, Van and Kombi) or the short arm of the jack handle (Chassis cab and Flatbed truck) into the guide hole. Turn anti-clockwise until the wheel rests on the ground, and there is slack in the cable.

Wheels and tyres



E70949

1. Remove the wing nut(s).
2. Pass the bracket and cable through the wheel opening.

Vehicle jack

WARNINGS



The vehicle jack supplied with your vehicle should only be used when changing a wheel in emergency situations.



Before using the vehicle jack, check that it is not damaged or deformed and that the thread is lubricated and free from foreign matter.




Never place anything between the jack and the ground, or the jack and the vehicle.

Note: Vehicles with a tyre repair kit are not equipped with a vehicle jack or a wheel brace.

The jack, wheel brace and jack handle are located in a storage compartment in the front right stepwell.

430 and 460 series vehicles



E70959

- Assemble the jack handle.
- Slide the flat end of the jack handle over the locking valve. Turn the handle fully clockwise. Insert the handle into the pump, and lift the vehicle using a pumping motion.

All except 430 and 460 series vehicles




E70957

- Unfold the jack handle.

Wheels and tyres

430 and 460 series vehicles




E70958

- Insert the hook of the handle into the ring on the jack. Insert the wheel brace into the other end of the handle and rotate clockwise.

Front jacking points

CAUTIONS

- ⚠ Use only the specified jacking points. If you use other positions, you may damage the body, steering, suspension, engine, braking system or the fuel lines.
- ⚠ Make sure that when positioning the jack, on a vehicle fitted with rear air conditioning (A/C), that it does not come in contact with the A/C lines or the fuel tank support strap.




E70951

Position the jack under the protrusions at the rear of the sub-frame.

Wheels and tyres

All except 430 and 460 series vehicles



E70952


Close the flap on the top of the jack (storage position). The front sub-frame rear bolts fit into a recess on the flap of the jack.

Rear jacking points

CAUTION

 Use only the specified jacking points. If you use other positions, you may damage the body, steering, suspension, engine, braking system or the fuel lines.

Front-wheel drive Bus, Van and Kombi (260, 280 and 300 series vehicles)




E70953

Open the flap on top of the jack. Position under the rear leaf spring directly in front of the rear wheel.

Front-wheel drive Bus, Van and Kombi (330 and 350 series vehicles)

Note: An additional block is located inside the spare wheel.

Wheels and tyres




E70954

Open the flap on top of the jack. Place the jack onto the block.

430 and 460 series vehicles

Note: Position the jack under the axle, as near the wheel being jacked as possible.




E74136

All Chassis Cab and all rear-wheel drive Bus, Van and Kombi (All except 430 and 460 series vehicles)

Note: Position the jack under the axle, as near the wheel being jacked as possible.

Wheels and tyres



E70955

Open the flap on the top of the jack.

Removing a road wheel

WARNINGS

-  Park your vehicle in such a position that neither the traffic nor you are hindered or endangered.
-  Set up a warning triangle.
-  Make sure that the vehicle is on firm, level ground with the wheels pointing straight ahead.
-  Switch off the ignition and apply the parking brake.


WARNINGS

-  If your vehicle has a manual transmission, select first or reverse gear. If it has an automatic transmission, select park.
-  Have the passengers leave the vehicle.
-  Secure the diagonally opposite wheel with an appropriate block or wheel chock.
-  Make sure that the arrows on directional tyres point in the direction of rotation when the vehicle is moving forwards. If you have to fit a spare wheel with the arrows pointing in the opposite direction, have the tyre refitted in the correct direction by a properly trained technician.
-  Do not work underneath the vehicle when it is supported only by a jack.
-  Make sure that the jack is vertical to the jacking point and the base is flat on the ground.

CAUTION

-  Do not lay alloy wheels face down on the ground, this will damage the paint.
1. Insert the flat end of the wheel brace between the rim and the hub cover and carefully remove the hub cap or cover.

Wheels and tyres



E70956

2. Remove the nut caps.
3. Install the locking wheel nut key.
4. Slacken the wheel nuts.
5. Jack up the vehicle until the tyre is clear of the ground.
6. Remove the wheel nuts and the wheel.

Installing a road wheel

WARNINGS

 Use only approved wheel and tyre sizes. Using other sizes could damage the vehicle and will make the National Type Approval invalid. See **Technical specifications** (page 157).


 Make sure that there is no lubrication (grease or oil) on the threads or the interface between wheel studs and nuts.

Note: Make sure the wheel and hub contact surfaces are free from foreign matter.

Note: Make sure that the cones on the wheel nuts are against the wheel.

Note: The wheel nuts of alloy wheels can also be used for the steel spare wheel.

1. Install the wheel.
2. Install the wheel nuts finger tight.
3. Install the locking wheel nut key.



E70961

4. Partially tighten the wheel nuts in the sequence shown.
5. Lower the vehicle and remove the jack.
6. Fully tighten the wheel nuts in the sequence shown. See **Technical specifications** (page 157).
7. Install the hub cap or cover using the ball of your hand.
8. Install the nut caps.

WARNING

 Have the wheel nuts checked for tightness and the tyre pressure checked as soon as possible.

Note: If the spare wheel is different in size or construction to the road wheels, have this replaced as soon as possible.

Wheels and tyres

Stowing the wheel

CAUTION

-  Do not raise the spare wheel carrier without the wheel attached. Damage can occur to the winch mechanism if lowered without a wheel attached.

Note: *Only when the winch mechanism slips is the wheel fully raised.*

- Place the wheel flat on the ground, so the outside of the wheel faces down. Tilt the bracket, and pass it and the cable through the centre opening in the wheel. Tighten the wing nut(s).
- Fully insert the flat end of the wheel brace into the guide hole and turn clockwise. On vehicles with a security bolt, re-install it by turning clockwise.
- Stow the wheel brace, jack, and jack handle away.

TYRE REPAIR KIT

WARNING

-  Camper vans must follow separate instructions issued with the tyre repair kit.

Your vehicle may not have a spare tyre. In this case it will have an emergency tyre repair kit that can be used to repair **one** flat tyre.

The tyre repair kit is located in the glove box.

General information

WARNINGS

-  Depending on the type and extent of tyre damage, some tyres can only be partially sealed or not sealed at all. Loss of tyre pressure can affect vehicle handling, leading to loss of vehicle control.
-  Do not use the tyre repair kit if the tyre has already been damaged as a result of being driven under inflated.
-  Do not try to seal damage other than that located within the visible tread of the tyre.
-  Do not try to seal damage to the tyre's sidewall.

The tyre repair kit seals most tyre punctures [with a diameter of up to six millimetres (1/4 inch)] to temporarily restore mobility.

Observe the following rules when using the kit:

- Drive with caution and avoid making sudden steering or driving manoeuvres**, especially if the vehicle is heavily loaded or you are towing a trailer.
- The kit will provide you with an emergency temporary repair, enabling you to continue your journey to the next vehicle or tyre dealer, or to drive a maximum distance of 200 kilometres (125 miles).
- Do not exceed a **maximum speed of 80 km/h (50 mph)**.
- Keep the kit out of the reach of children.
- Only use the kit when the ambient temperature is between -30°C (-22°F) and +70°C (+158°F).

Wheels and tyres

Using the tyre repair kit

WARNINGS

 Compressed air can act as an explosive or propellant.

 Never leave the tyre repair kit unattended while in use.

CAUTION

 Do not keep the compressor operating for more than 10 minutes.

Note: Use the tyre repair kit only for the vehicle with which it was supplied.

- Park your vehicle at the roadside so that you do not obstruct the flow of traffic and so that you are able to use the kit without being in danger.
- Apply the parking brake, even if you have parked on a level road, to make sure that the vehicle will not move.
- Do not attempt to remove foreign objects like nails or screws penetrating the tyre.
- Leave the engine running while the kit is in use, but not if the vehicle is in an enclosed or poorly ventilated area (for example, inside a building). In these circumstances, switch the compressor on with the engine turned off.
- Replace the sealant bottle with a new one before the expiry date (see top of bottle) is reached.
- Inform all other users of the vehicle that the tyre has been temporarily sealed with the tyre repair kit and make them aware of the special driving conditions to be observed.

Inflating the tyre

WARNINGS

 Check the sidewall of the tyre prior to inflation. If there are any cracks, bumps or similar damage, do not attempt to inflate the tyre.

 Do not stand directly beside the tyre while the compressor is pumping.

 Watch the sidewall of the tyre. If any cracks, bumps or similar damage appear, turn off the compressor and let the air out by means of the pressure relief valve **B**. Do not continue driving with this tyre.


 The sealant contains natural rubber latex. Avoid contact with skin and clothing. If this happens, rinse the affected areas immediately with plenty of water and contact your doctor.

 If the tyre inflation pressure does not reach 1.8 bar (26 psi) within seven minutes, the tyre may have suffered excessive damage, making a temporary repair impossible. In this case, do not continue driving with this tyre.

CAUTION

 Screwing the bottle onto the bottle holder will pierce the seal of the bottle. Do not unscrew the bottle from the holder as the sealant will escape.

Wheels and tyres



E94973

- A Protective cap
- B Pressure relief valve
- C Hose
- D Orange cap

Wheels and tyres

- E Bottle holder
- F Pressure gauge
- G Power plug with cable
- H Compressor switch
- I Label
- J Bottle lid
- K Sealant bottle

1. Open the lid of the tyre repair kit.
2. Peel off the label **I** showing the maximum permissible speed of 80 km/h (50 mph) from the casing and attach it to the instrument panel in the driver's field of view. Make sure the label does not obscure anything important.
3. Take the hose **C** and the power plug with cable **G** out of the kit.
4. Unscrew the orange cap **D** and the bottle lid **J**.
5. Screw the sealant bottle **K** clockwise into the bottle holder **E** fully tight.
6. Remove the valve cap from the damaged tyre.
7. Detach the protective cap **A** from the hose **C** and screw the hose **C** firmly onto the valve of the damaged tyre.
8. Make sure that the compressor switch **H** is in position **O**.
9. Insert the power plug **G** into the cigar lighter socket or auxiliary power socket. See **Cigar lighter** (page 72). See **Auxiliary power sockets** (page 73).
10. Start the engine.
11. Move the compressor switch **H** to position **1**.
12. Inflate the tyre for no longer than seven minutes to an inflation pressure of minimum 1.8 bar (26 psi) and a maximum of 3.5 bar (51 psi). Move the compressor switch **H** to position **O** and check the current tyre pressure with pressure gauge **F**.
13. Remove the power plug **G** from the cigar lighter socket or auxiliary power socket.
14. Quickly unscrew the hose **C** from the tyre valve and replace the protective cap **A**. Fasten the valve cap again.
15. Leave the sealant bottle **K** in the bottle holder **E**.
16. Make sure the kit, the bottle lid and the orange cap are stored safely, but still easily accessible in the vehicle. The kit will be required again when you check the tyre pressure.
17. Immediately drive approximately three kilometres (two miles) so that the sealant can seal the damaged area.

Note: When pumping in the sealant through the tyre valve, the pressure may rise up to 6 bar (87 psi) but will drop again after about 30 seconds.

Wheels and tyres

WARNING



If you experience heavy vibrations, unsteady steering behaviour or noises while driving, reduce your speed and drive with caution to a place where it is safe for you to stop the vehicle. Recheck the tyre and its pressure. If the tyre pressure is less than 1.3 bar (19 psi) or if there are any cracks, bumps or similar damage visible, do not continue driving with this tyre.

Checking the tyre pressure

1. Stop the vehicle after driving approximately three kilometres (two miles). Check, and where necessary, adjust the pressure of the damaged tyre.
2. Attach the kit and read the tyre pressure from the pressure gauge **F**.
3. If the pressure of the sealant-filled tyre is 1.3 bar (19 psi) or more, adjust it to the specified pressure. See **Technical specifications** (page 157).
4. Follow the inflation procedure once again to top up the tyre.
5. Check the tyre pressure again from the pressure gauge **F**. If the tyre pressure is too high, deflate the tyre to the specified pressure using the pressure relief valve **B**.
6. Once you have inflated the tyre to its correct tyre pressure, move the compressor switch **H** to position **O**, remove the power plug **G** from the socket, unscrew the hose **C**, fasten the valve cap and replace the protective cap **A**.
7. Leave the sealant bottle **K** in the bottle holder **E** and store the kit away safely in its original location.

8. Drive to the nearest tyre specialist to get the damaged tyre replaced. Before the tyre is removed from the rim, inform your tyre dealer that the tyre contains sealant. Renew the kit as soon as possible after it has been used once.

Note: Remember that emergency roadside tyre repair kits only provide temporary mobility. Regulations concerning tyre repair after usage of tyre repair kit may differ from country to country. You should consult a tyre specialist for advice.

WARNING



Before driving, make sure the tyre is adjusted to the recommended inflation pressure. See **Technical specifications** (page 157). Monitor the tyre pressure until the sealed tyre is replaced.

Empty sealant bottles can be disposed of together with normal household waste. Return remains of sealant to your dealer or dispose of it in compliance with local waste disposal regulations.

TYRE CARE



E70415

Wheels and tyres

To make sure the front and rear tyres of your vehicle wear evenly and last longer, we recommend that you swap the tyres from front to rear and vice versa at regular intervals of 15 000 to 20 000 km (9 000 to 12 000 miles).

CAUTION

 Do not scrub the sidewalls of the tyres when you are parking.

If you have to mount a kerb, do so slowly and approach it with the wheels at right-angles to the kerb.

Examine the tyres regularly for cuts, foreign objects and uneven wear of the tread. Uneven wear could mean that the wheel alignment is outside specification.

USING WINTER TYRES

CAUTION

 Make sure that you use the correct wheel nuts for the type of wheel the winter tyres are fitted to.

If winter tyres are used, make sure that the tyre pressures are correct. See **Technical specifications** (page 157).

USING SNOW CHAINS

All vehicles

WARNINGS

 Do not exceed 50 km/h (30 mph).

WARNINGS

 Do not use snow chains on snow-free roads.

CAUTION

 If your vehicle is fitted with wheel trims, remove them before fitting snow chains.

Note: *The ABS will continue to operate normally.*

Only use small link snow chains.

Only use snow chains on the driven wheels.

Front wheel drive vehicles

Note: *195/75 R 16 C tyres are only covered in the vehicle registration documents for use on the front axle.*

If your vehicle is fitted with 215/75 R 16 C tyres, fit 195/75 R 16 C (M+S) tyres to the front wheels. Inflate the tyres to the maximum pressure permissible.

Vehicles with stability control (ESP)

Vehicles with stability control (ESP) may exhibit some unusual driving characteristics which can be avoided by switching the system off. See **Using stability control** (page 87).

Wheels and tyres

TECHNICAL SPECIFICATIONS

Wheel nut torque

Wheel type	Nm (lb-ft)
All	200 (147.5)

Tyre pressures (cold tyres)

Bus

Tyre pressures

Variant	Tyre size	Normal load		Full load	
		Front	Rear	Front	Rear
		bar (lbf/in ²)	bar (lbf/in ²)	bar (lbf/in ²)	bar (lbf/in ²)
280S	185/75 R 16 C	3 (44)	3 (44)	3.8 (55)	4.1 (60)
280S	195/70 R 15 C	3 (44)	3 (44)	3.6 (52)	3.9 (57)
280S	205/65 R 16 C	2.8 (41)	2.8 (41)	3.4 (49)	3.7 (54)
350L - Maximum front axle weight 1 750 kilograms (3 868 pounds)	215/75 R 16 C	3.5 (51)	4.8 (70)	3.5 (51)	4.8 (70)
350L - Maximum front axle weight 1 850 kilograms (4 079 pounds)	215/75 R 16 C	3.8 (55)	4.8 (70)	3.8 (55)	4.8 (70)
410EF/M2	185/75 R 16 C	4.7 (68)	4.1 (60)	4.7 (68)	4.1 (60)
410EF/M2	195/70 R 15 C	4.6 (67)	3.7 (54)	4.6 (67)	3.7 (54)

Wheels and tyres

Van and Kombi - Rear wheel drive

Tyre pressures

Variant	Tyre size	Normal load		Full load	
		Front	Rear	Front	Rear
		bar (lbf/in ²)	bar (lbf/in ²)	bar (lbf/in ²)	bar (lbf/in ²)
300S/M/L	205/75 R 16 C	3.5 (51)	4.2 (61)	3.5 (51)	4.2 (61)
330S/M/L	205/75 R 16 C	3.5 (51)	4.2 (61)	3.5 (51)	4.2 (61)
330S/M/L	215/75 R 16 C	3.4 (49)	4.5 (65)	3.4 (49)	4.5 (65)
350M/L - Maximum front axle weight 1 750 kilograms (3 868 pounds)	215/75 R 16 C	3.5 (51)	4.8 (70)	3.5 (51)	4.8 (70)
350M/L - Maximum front axle weight 1 850 kilograms (4 079 pounds)	215/75 R 16 C	3.8 (55)	4.8 (70)	3.8 (55)	4.8 (70)
350M/EF - Maximum front axle weight 1 750 kilograms (3 868 pounds)	215/75 R 16 C	3.5 (51)	4.9 (71)	3.5 (51)	4.9 (71)
350M/L/EF - Maximum front axle weight 1 850 kilograms (4 079 pounds)	215/75 R 16 C	3.8 (55)	4.9 (71)	3.8 (55)	4.9 (71)
430EF - Maximum front axle weight 1 750 kilograms (3 868 pounds)	185/75 R16 C	4.7 (68)	3.5 (51)	4.7 (68)	3.5 (51)
430EF - Maximum front axle weight 1 850 kilograms (4 079 pounds)	185/75 R16 C	4.7 (68)	4.1 (60)	4.7 (68)	4.1 (60)
430EF	195/75 R 16 C	4.6 (67)	3.7 (54)	4.6 (67)	3.7 (54)

Wheels and tyres

Variant	Tyre size	Normal load		Full load	
		Front	Rear	Front	Rear
		bar (lbf/in ²)	bar (lbf/in ²)	bar (lbf/in ²)	bar (lbf/in ²)
460M/L/EF - Maximum rear axle weight 2 600 kilo- grams (5 732 pounds)	195/75 R 16 C	4.6 (67)	3.2 (46)	4.6 (67)	3.2 (46)
460M/L/EF - Maximum rear axle weight 3 300 kilo- grams (7 275 pounds)	195/75 R 16 C	4.6 (67)	4.3 (62)	4.6 (67)	4.3 (62)

Van and Kombi - Front wheel drive

Tyre pressures

Variant	Tyre size	Normal load		Full load	
		Front	Rear	Front	Rear
		bar (lbf/in ²)	bar (lbf/in ²)	bar (lbf/in ²)	bar (lbf/in ²)
260S	185/75 R 16 C	3.8 (55)	3.8 (55)	3.8 (55)	3.8 (55)
260S - GVM 2 350 kilograms (5 181 pounds)	195/70 R 15 C	3.3 (48)	3.3 (48)	3.3 (48)	3.3 (48)
260S - Maximum front axle weight 1 450 kilograms (3 197 pounds) - Maximum rear axle weight 1 475 kilograms (3 252 pounds)	195/70 R 15 C	3.4 (49)	3.5 (51)	3.4 (49)	3.5 (51)
260S	205/65 R 16 C	3.4 (49)	3.5 (51)	3.4 (49)	3.5 (51)
260S - Sportvan	195/70 R 15 C	3.4 (49)	3.5 (51)	3.4 (49)	3.5 (51)
260S - Sportvan	235/45 R18	2.8 (41)	2.9 (42)	2.8 (40)	2.9 (42)

Wheels and tyres

Variant	Tyre size	Normal load		Full load	
		Front	Rear	Front	Rear
		bar (lbf/in ²)	bar (lbf/in ²)	bar (lbf/in ²)	bar (lbf/in ²)
280S	185/75 R 16 C	3.8 (55)	4.4 (64)	3.8 (55)	4.4 (64)
280S	195/70 R 15 C	3.6 (52)	4.2 (61)	3.6 (52)	4.2 (61)
280S	205/65 R 16 C	3.4 (49)	4 (58)	3.4 (49)	4 (58)
280M - Reduced GVM - UK only	185/75 R 16 C	3.8 (55)	4.1 (60)	3.8 (55)	4.1 (60)
280M - Reduced GVM - Italy only	185/75 R 16 C	3.9 (57)	4.4 (64)	3.9 (57)	4.4 (64)
280M - Reduced GVM - UK only	195/70 R 15 C	3.4 (49)	3.8 (55)	3.4 (49)	3.8 (55)
280M - Reduced GVM - Italy only	195/70 R 15 C	3.7 (54)	4.2 (61)	3.7 (54)	4.2 (61)
280M	205/65 R 16 C	3.4 (49)	3.7 (54)	3.4 (49)	3.7 (54)
280M	205/65 R 16 C	3.6 (52)	4 (58)	3.6 (52)	4 (58)
300S/M/L	185/75 R 16 C	4.2 (61)	4.7 (68)	4.2 (61)	4.7 (68)
300S/M/L	195/70 R 15 C	4 (58)	4.5 (65)	4 (58)	4.5 (65)
300S/M/L	205/65 R 16 C	3.8 (55)	4.3 (62)	3.8 (55)	4.3 (62)
300L	185/75 R 16 C	4.1 (60)	4.4 (64)	4.1 (60)	4.4 (64)
300L	195/70 R 15 C	3.7 (54)	4.2 (61)	3.7 (54)	4.2 (61)
300L	205/65 R 16 C	3.7 (54)	4 (58)	3.7 (54)	4 (58)
330S/M/L	195/70 R 15 C	4.1 (60)	N/A	4.1 (60)	N/A
330S/M/L	215/75 R 16 C	3.4 (49)	4.5 (65)	3.4 (49)	4.5 (65)
350M/L	195/70 R 15 C	4.3 (62)	N/A	4.3 (62)	N/A
350M/L	215/75 R 16 C	3.5 (51)	4.8 (70)	3.5 (51)	4.8 (70)

Wheels and tyres

Chassis cab and Flatbed truck - Rear wheel drive

Tyre pressures

Variant	Tyre size	Normal load		Full load	
		Front	Rear	Front	Rear
		bar (lbf/in ²)	bar (lbf/in ²)	bar (lbf/in ²)	bar (lbf/in ²)
300S/M	205/75 R 16 C	3.5 (51)	4.2 (61)	3.5 (51)	4.2 (61)
330S/M/L	215/75 R 16 C	3.4 (49)	4.5 (65)	3.4 (49)	4.5 (65)
350S/M/L/EF - Maximum rear axle weight 2 450 kilo- grams (5 401 pounds)	185/75 R 16 C	4.7 (68)	3.3 (48)	4.7 (68)	3.3 (48)
350L/EF - Maximum rear axle weight 2 600 kilograms (5 732 pounds)	185/75 R 16 C	4.7 (68)	3.5 (51)	4.7 (68)	3.5 (51)
350S/M/L/EF - Maximum rear axle weight 2 450 kilo- grams (5 401 pounds)	195/75 R 16 C	4.6 (67)	3.3 (48)	4.6 (67)	3.3 (48)
350L/EF - Maximum rear axle weight 2 600 kilograms (5 732 pounds)	195/75 R 16 C	4.6 (67)	3.2 (46)	4.6 (67)	3.2 (46)
350S/M/L - Maximum front axle weight 1 750 kilograms (3 868 pounds)	215/75 R 16 C	3.5 (51)	4.8 (70)	3.5 (51)	4.8 (70)
350S/M/L - Maximum front axle weight 1 850 kilograms (4 079 pounds)	215/75 R 16 C	3.8 (55)	4.8 (70)	3.8 (55)	4.8 (70)
350EF - Maximum front axle weight 1 750 kilograms (3 868 pounds)	215/75 R 16 C	3.5 (51)	4.9 (71)	3.5 (51)	4.9 (71)

Wheels and tyres

Variant	Tyre size	Normal load		Full load	
		Front	Rear	Front	Rear
		bar (lbf/in ²)	bar (lbf/in ²)	bar (lbf/in ²)	bar (lbf/in ²)
350EF - Maximum front axle weight 1 850 kilograms (4 079 pounds)	215/75 R 16 C	3.8 (55)	4.9 (71)	3.8 (55)	4.9 (71)
430EF - Maximum rear axle weight 2 600 kilograms (5 732 pounds)	185/75 R 16 C	4.7 (68)	3.5 (51)	4.7 (68)	3.5 (51)
430M/L/EF - Maximum rear axle weight 2 950 kilograms (6 504 pounds)	185/75 R 16 C	4.7 (68)	4.1 (60)	4.7 (68)	4.1 (60)
430M/L/EF	195/75 R 16 C	4.6 (67)	3.7 (54)	4.6 (67)	3.7 (54)
460M/L/EF - Maximum rear axle weight 2 600 kilograms (5 732 pounds)	195/75 R 16 C	4.6 (67)	3.2 (46)	4.6 (67)	3.2 (46)
460M/L/EF - Maximum rear axle weight 3 300 kilograms (7 275 pounds)	195/75 R 16 C	4.6 (67)	4.3 (62)	4.6 (67)	4.3 (62)

Chassis cab and Flatbed truck - Front wheel drive

Tyre pressures

Variant	Tyre size	Normal load		Full load	
		Front	Rear	Front	Rear
		bar (lbf/in ²)	bar (lbf/in ²)	bar (lbf/in ²)	bar (lbf/in ²)
300S/M	185/75 R 16 C	4.2 (61)	4.7 (68)	4.2 (61)	4.7 (68)

Wheels and tyres

Variant	Tyre size	Normal load		Full load	
		Front	Rear	Front	Rear
		bar (lbf/in ²)	bar (lbf/in ²)	bar (lbf/in ²)	bar (lbf/in ²)
300S/M	195/70 R 15 C	4 (58)	4.5 (65)	4 (58)	4.5 (65)
300S/M	205/65 R 16 C	3.8 (55)	4.3 (62)	3.8 (55)	4.3 (62)
330S/M/L	195/70 R 15 C	4.1 (60)	N/A	4.1 (60)	N/A
330S/M/L	215/75 R 16 C	3.4 (49)	4.5 (65)	3.4 (49)	4.5 (65)
350M/L/EF	195/70 R 15 C	4.3 (62)	N/A	4.3 (62)	N/A
350M/L/EF	215/75 R 16 C	3.5 (51)	4.8(70)	3.5 (51)	4.8 (70)


ECOnetic

Tyre pressures

Variant	Tyre size	Normal load		Full load	
		Front	Rear	Front	Rear
		bar (lbf/in ²)	bar (lbf/in ²)	bar (lbf/in ²)	bar (lbf/in ²)
ECOnetic	215/75 R 16 C	3 (43)	3.4 (49)	3 (43)	3.4 (49)

Vehicle identification

VEHICLE IDENTIFICATION PLATE



E85610

- A Vehicle identification number
- B Gross vehicle weight
- C Gross train weight
- D Maximum front axle weight
- E Maximum rear axle weight

The vehicle identification number and maximum weights are shown on a plate located on the lock side of the passenger door aperture at the bottom.

VEHICLE IDENTIFICATION NUMBER (VIN)



E71369



The vehicle identification number is stamped into the right-hand front wheelhouse. It is also shown on the left-hand side of the instrument panel.

Technical specifications

TECHNICAL SPECIFICATIONS


Vehicle dimensions

Short wheelbase



E71261

Technical specifications



E71262


Item	Dimension description	Dimension in mm (inches)
A	Maximum length - without rear step (Van and Kombi)	4863 (191.5)
A	Maximum length (Chassis cab and Flatbed truck with flatbed)	5254 (206.9)
A	Maximum length with rear step (Van and Kombi)	4965 (195.5)
A	Maximum length with towing equipment (Van and Kombi)	5070 (199.6)
A	Maximum length with towing equipment (Chassis cab and Flatbed truck with flatbed)	5254 (206.9)
B	Overall width excluding exterior mirrors (Van and Kombi)	1974 (77.7)
B	Overall width excluding exterior mirrors (Chassis cab and Flatbed truck - Narrow float)	1998 (78.6)
B	Overall width excluding exterior mirrors (Chassis cab and Flatbed truck - Wide float)	2198 (86.5)
C1	Overall height - Low roof (Van and Kombi)	1997 - 2089 (78.6 - 82.2)
C1	Overall height - Low roof (Chassis cab and Flatbed truck)	1974 - 2037 (77.7 - 80.1)

Technical specifications


Item	Dimension description	Dimension in mm (inches)
C2	Overall height - Semi high roof (Van and Kombi)	2313 - 2405 (91.1 - 94.7)
C3	Overall height - Extra high roof	-
D	Wheelbase (Van and Kombi)	2933 (115.5)
D	Wheelbase (Chassis cab and Flatbed truck)	3137 (123.5)
E	Track - Front	1737 - 1757 (68.4 - 69.2)
E	Track - Rear	1642 - 1720 (64.6 - 67.7)

Technical specifications

Medium wheelbase



Technical specifications




Item	Dimension description	Dimension in mm (inches)
A	Maximum length - Semi high roof (Van and Kombi)	5301 (208.7)
A	Maximum length without rear step (Double chassis cab and Flatbed truck with flatbed)	5792 (228)
A	Maximum length without rear step (Single chassis cab and Flatbed truck with flatbed)	5775 (227.4)
A	Maximum length with rear step (Van and Kombi)	5403 (212.7)
A	Maximum length with towing equipment (Van and Kombi)	5444 (214.3)
A	Maximum length with towing equipment (Chassis cab and Flatbed truck without flatbed)	5616 (221.1)
A	Maximum length with towing equipment (Double chassis cab and Flatbed truck with flatbed)	5775 (227.4)
A	Maximum length with towing equipment (Single chassis cab and Flatbed truck with flatbed)	5792 (228)
B	Overall width excluding exterior mirrors (Van and Kombi)	1974 (77.7)
B	Overall width excluding exterior mirrors (Chassis cab and Flatbed truck - Narrow float)	1998 (78.6)

Technical specifications

Item	Dimension description	Dimension in mm (inches)
B	Overall width excluding exterior mirrors (Chassis cab and Flatbed truck - Wide float)	2198 (86.5)
C1	Overall height - Low roof (Van and Kombi)	1995 - 2056 (78.6 - 80.9)
C1	Overall height - Low roof (Single chassis cab and Flatbed truck)	1969 - 2057 (77.5 - 81)
C1	Overall height - Low roof (Double chassis cab and Flatbed truck)	2031 - 2069 (80 - 81.5)
C2	Overall height - Semi high roof (Van and Kombi)	2302 - 2390 (90.6 - 94.1)
C3	Overall height - Extra high roof (Van and Kombi)	2616 (103)
D	Wheelbase (Van and Kombi)	3300 (129.9)
D	Wheelbase (Chassis cab and Flatbed truck)	3504 (138)
E	Track - Front	1737 - 1757 (68.4 - 69.2)
E	Track - Rear (All with single rear wheels)	1710 - 1720 (67.3 - 67.7)
E	Track - Rear (Chassis cab and Flatbed truck - double rear wheels)	1642 (64.6)


Technical specifications

Long wheelbase



E71265

Technical specifications



Item	Dimension description	Dimension in mm (inches)
A	Maximum length - Semi high roof (Van and Kombi)	5751 (226.4)
A	Maximum length - Extra high roof (Van and Kombi)	5751 (226.4)
A	Maximum length - Extra high roof (Extended Frame Van and Kombi)	6474 (254.9)
A	Maximum length (Single chassis cab and Flatbed truck with flatbed)	6175 (243.1)
A	Maximum length (Double chassis cab and Flatbed truck with flatbed) extended frame	6142 (241.8)
A	Maximum length with rear step (Van and Kombi)	5853 (230.4)
A	Maximum length with rear step (Extended Frame Van and Kombi)	6576 (258.9)
A	Maximum length with rear step (Single chassis cab extended Frame with flatbed)	6675 (262.8)
A	Maximum length with rear step (Double chassis cab extended Frame with flatbed)	6592 (259.5)
A	Maximum length with towing equipment (Van and Kombi)	5869 (231)
A	Maximum length with towing equipment (Extended Frame Van and Kombi)	6593 (257.7)

Technical specifications


Item	Dimension description	Dimension in mm (inches)
A	Maximum length with towing equipment (Chassis cab and Flatbed truck with flatbed)	6175 (240.5)
A	Maximum length with towing equipment (Chassis cab and Flatbed truck with flatbed) extended frame	6675 (260.2)
B	Overall width excluding exterior mirrors (Van and Kombi single rear wheel)	1974 (77.7)
B	Overall width excluding exterior mirrors (Van and Kombi single rear wheel with magnetic door retention)	1999 (78.7)
B	Overall width excluding exterior mirrors (Van and Kombi dual rear wheel)	2084 (82)
B	Overall width excluding exterior mirrors (Chassis cab and Flatbed truck - Narrow float)	1998 (78.6)
B	Overall width excluding exterior mirrors (Chassis cab and Flatbed truck - Wide float)	2198 (86.5)
C1	Overall height - Low roof (Single chassis cab and Flatbed truck)	2017 - 2049 (79.4 - 80.7)
C1	Overall height - Low roof (Double chassis cab and Flatbed truck)	2024 - 2047 (79.7 - 80.6)
C2	Overall height - Semi high roof (Van and Kombi)	2325 - 2402 (91.5 - 95.6)
C2	Overall height - Semi high roof (Extended Frame Van and Kombi)	2383 (93.8)
C2	Overall height - Extra high roof (Extended Frame Van and Kombi)	2608 - 2629 (102.7 - 103.5)
C3	Overall height - Extra high roof (Van and Kombi)	2543 - 2619 (100.1 - 103.1)
C3	Overall height - Extended Frame (Single chassis cab)	2012 - 2052 (79.2 - 80.8)
C3	Overall height - Extended Frame (Double chassis cab)	2012 - 2055 (79.2 - 80.9)
D	Wheelbase (Van and Kombi)	3750 (147.6)
D	Wheelbase (Chassis cab and Flatbed truck)	3954 (155.7)

Technical specifications

Item	Dimension description	Dimension in mm (inches)
E	Track - Front	1737 - 1757 (68.4 - 69.1)
E	Track - Rear (Van and Kombi)	1710 - 1720 (67.3 - 67.7)
E	Track - Rear (Chassis cab and Flatbed truck - double rear wheels)	1642 (64.6)

Towing equipment dimensions

Van and Kombi




E71267

Technical specifications

Item	Dimension description	Dimension in mm (inches)
A	Wheel centre - end of towball (Standard Frame)	1140 (44.9)
A	Wheel centre - end of towball (Extended Frame)	1863 (73.3)
B	Centre of towball - side member	416 (16.4)
C	Inner side of side member	832 (32.8)
D	Centre of towball - centre 1. attachment point	334 (13.1)
E	Centre of towball - centre 2. attachment point	403.5 (15.9)
F	Centre of towball - centre 3. attachment point	473 (18.6)

Technical specifications

Chassis cab and Flatbed truck



E71268

Item	Dimension description	Dimension in mm (inches)
A	Wheel centre - end of towball (Standard Frame)	1180 (46.5)
A	Wheel centre - end of towball (Extended Frame)	1562 (61.5)
B	Centre of towball - side member	418 (16.5)
C	Inner side of side member	836 (32.9)

Technical specifications

Item	Dimension description	Dimension in mm (inches)
D	Centre of towball - centre 1. attachment point	237 (9.3)
E	Centre of towball - centre 2. attachment point	343.5 (13.5)

Telephone

GENERAL INFORMATION

CAUTION

 Using the system with the engine off will drain the battery.

This section describes the functions and features of the Bluetooth mobile phone hands free system.

The Bluetooth mobile phone part of the system provides interaction with the audio or navigation system and your mobile phone. It allows you to use the audio or navigation system to make and receive calls without having to use your mobile phone.

Compatibility of phones

CAUTION

 As no common agreement exists, mobile phone manufacturers are able to implement a variety of profiles in their Bluetooth devices. Because of this, an incompatibility can occur between the phone and hands-free system, which in some cases may significantly degrade the system performance. To avoid this situation, only recommended phones should be used.

Please visit the website **www.ford-mobile-connectivity.com** for full details.

Phones with Symbian operating system

Note: *Certain phones require a special file to be installed to enable full phonebook access via Bluetooth.*

*This is referred to as a SIS file and will be available to download via the Ford website **www.ford-mobile-connectivity.com**.*

TELEPHONE SETUP

Phonebook

Note: *It may be necessary to confirm phonebook access to the Bluetooth system via the mobile phone.*

After start up access to the phonebook list can be delayed for several minutes, depending upon the size.

Phonebook categories

Depending on your phonebook entry, different categories can be displayed in the audio unit.

For example:

M	Mobile
O	Office
H	Home
F	Fax

Note: *Entries may be displayed without a category attachment.*

The category can also be indicated as an icon:



Phone



Mobile



Home



Office



Fax

Telephone

Making a phone an active phone

When using the system for the first time, no phone is connected to the system.

After switching on the ignition and the audio unit, the Bluetooth phone must be bonded to the system.

Bluetooth phone

After bonding a Bluetooth phone to the system, this becomes the active phone. For further information refer to the phone menu.

Select the phone from the active phone menu.

Turning the ignition and radio or navigation unit back on again, the last active phone is picked up by the system.

Note: *In some cases the Bluetooth connection must also be confirmed on the phone.*

Bond another Bluetooth phone

Bond a new Bluetooth phone as described in the requirements for a Bluetooth connection.

Phones stored in the system are accessible by using the phone list on the audio unit.

Note: *A maximum of six devices may be bonded. If six Bluetooth devices have already been bonded, one of these has to be debonded in order to bond a new device.*

BLUETOOTH SETUP

Before you can use your telephone with your vehicle it must be bonded to the vehicle telephone system.

Handling of phones

Up to six Bluetooth devices can be bonded to the vehicle system.

Note: *If there is an ongoing call when the phone in use is selected as the new active phone, the call is transferred to the vehicle audio system.*

Note: *Even if connected to the car system, your phone can still be used in the usual way.*

Requirements for Bluetooth connection

The following are required before a Bluetooth phone connection can be made.

1. The Bluetooth feature must be activated on the phone and on the audio unit. Make sure the Bluetooth menu option in the audio unit is set to **ON**. For information on phone settings, refer to your phone user guide.
2. The private mode must not be activated on the Bluetooth phone.
3. Search for audio device.
4. Select **Ford Audio**.
5. Enter the code number shown on the vehicle display using the phone keypad. If no code number is shown on the display, enter the Bluetooth PIN number 0000 using the phone keypad. Now enter the Bluetooth PIN number shown on the vehicle display.


Note: *A phone call will be disconnected if the audio unit is switched off. If the ignition key is turned to the off position the phone call will remain in progress.*

Telephone

TELEPHONE CONTROLS

Remote control

Voice and mode button



E87661

- 1 Voice button
- 2 Mode button

Incoming calls can be accepted by pressing the MODE button once. Press the button again to end the call.

USING THE TELEPHONE - VEHICLES WITHOUT: NAVIGATION SYSTEM

This chapter describes the phone functions of the audio unit.

Note: Refer to your audio guide for details of the controls.

An active phone must be present.

Even if connected to the audio unit, your phone can still be used in the usual way.

Note: You can exit the phone menu by pressing any source button **CD**, **AM/FM** or **AUX**.

Making a call

Dialling a number using voice control

Phone numbers can be dialled using voice control. See **Telephone commands** (page 192).

Dialling a number using the address book

You can access your phone address book via Bluetooth. The entries will appear in the unit display.

1. Press the **PHONE** or the call accept button.
2. Press the **MENU** button.
3. Keep pressing the **MENU** button until **PHONEBOOK** appears.
4. Press the seek buttons to select the desired phone number.

Note: Press and hold the seek button to skip to the next letter in the alphabet.

5. Press the **PHONE** or the call accept button to dial the selected phone number.

Dialling a number using the address book - Sony radio

You can access your phone address book via Bluetooth. The entries will appear in the unit display.

1. Press the **PHONE** button.
2. Press the seek button until the phone book is shown.
3. Press the up/down arrow buttons to select the desired phone number.

Note: Press and hold the up/down arrow buttons to skip to the next letter in the alphabet.

4. Press the **PHONE** or the call accept button to dial the selected phone number.

Telephone

Dialling a number using the telephone keypad

If you have an audio unit with a telephone keypad (buttons 0-9, * and #):

1. Press the call accept button. Press the **PHONE** button if you have a Sony radio.
2. Dial the number using the telephone keypad on the audio unit.
3. Press the call accept button.

Note: If you enter an incorrect digit whilst entering a phone number, press the seek left button to erase the last digit. A long press will erase the complete string of digits.

Press and hold **0** to enter a + digit.

Ending a call

Calls can be ended by pressing the call reject button.

Audio units without a telephone keypad can also end a call by pressing either **PHONE**, **CD**, **AM/FM** or **ON/OFF**, or by pressing the **MODE** button on the remote control

Redialling a number

1. Press the **PHONE** or the call accept button.
2. Press the **MENU** button.
3. Select the **CALL OUT** list or the **CALL IN** list. On some audio units, select the **MISSED**, **INCOMING** or **OUTGOING** calls list.

Note: If the active phone does not provide a call out list, the last outgoing call number/entry can be redialled.

4. Press the seek button on the audio unit.
5. Press the **PHONE** or the call accept button to dial the desired phone number.

Redialling a number - Sony radio

1. Press the **PHONE** or the call accept button.
2. Press the seek button until the desired list is displayed.

Note: If the active phone does not provide a call out list, the last outgoing call number/entry can be redialled.

3. Press the up/down buttons to select the desired phone number.
4. Press the **PHONE** or the call accept button to dial the phone number.

Redialling the last dialled number - Sony radio

1. Press the call accept button.
2. Press the call accept button a second time to dial the number.

Receiving an incoming call

Accepting an incoming call

Incoming calls can be accepted by pressing either the call accept button, the **PHONE** button or the **MODE** button on the remote control.

Rejecting an incoming call

Incoming calls can be rejected by pressing the call reject button.

Audio units without a telephone keypad can also reject a call by pressing either **PHONE**, **CD**, **AM/FM** or **ON/OFF**.

Receiving a second incoming call

Note: The second incoming call function must be activated in your phone.

If there is an incoming call whilst there is an ongoing call, a beep will be heard and you will have the option to end the active call and to accept the incoming call.

Telephone

Accepting a second incoming call

Second incoming calls can be accepted by pressing either the call accept button, the **PHONE** button, or the **MODE** button on the remote control.

Rejecting a second incoming call

Second incoming calls can be rejected by pressing the call reject button. Units without a telephone keypad can also reject a second incoming call by pressing the **CD** button, or the **AM/FM** button.

Muting the microphone

During a call, it is possible to mute the microphone. Whilst muted, confirmation will appear in the display.

Audio units with green call accept button

Press the call accept button. Press the button once again to turn this function off.

Audio units without green call accept button

Press the seek up or down button. Press the button once again to turn this function off.

Changing the active phone

Note: *Phones must be bonded to the system before they can be made active.*

Using the station storage button

Note: *This process is only for audio units without a telephone keypad.*

1. Press the **PHONE** button on the audio unit.
2. Press the preset number required (using the station preset buttons 1 - 6).

Using the audio unit menu

Note: *After bonding a phone to the system, this becomes the active phone.*

1. Press the **PHONE** or call accept button.
2. Press the **MENU** button on the audio unit.
3. Select the **ACTIVE PHONE** option on the audio unit.
4. Scroll through the different stored phones by using the seek buttons to display the bonded phones.
5. Press the **MENU** button to select the phone which is to be the active phone.

Debonding a bonded phone

A bonded phone can be deleted from the system at any time, unless a phone call is in progress.

1. Press the **PHONE** or call accept button.
2. Press the **MENU** button on the audio unit.
3. Select the **DEBOND** option on the audio unit.
4. Scroll through the different phones by using the seek buttons and display the phone to be debonded.
5. Press the **MENU** button to select the phone which is to be debonded.

Debonding a bonded phone - Sony radio

A bonded phone can be deleted from the system at any time, unless a phone call is in progress.

1. Press the **PHONE** button.
2. Press the up/down arrow buttons until you reach the **DEBOND** option.

Telephone

3. Scroll through the different phones by using the seek buttons and display the phone to be debonded.
4. Press the OK button to be debond.

USING THE TELEPHONE - VEHICLES WITH: NAVIGATION SYSTEM

This chapter describes the phone functions of the Navigation System.

Note: Refer to your *Navigation System guide* for details of the controls.

An active phone must be present.

Even if connected to the Navigation System, your phone can still be used in the usual way.

Making a call

Dialling a number

Phone numbers can be dialled using voice control. See **Voice control** (page 185).

Ending a call

Calls can be ended by pressing either the **END** button, the **MODE** button on the remote switch or the **ON/OFF** button on the navigation system.

Redialling a number

1. Press the **PHONE** button on the unit.
2. Select **REDIAL**.

Receiving an incoming call

Accepting an incoming call

Incoming calls can be accepted by pressing either the call accept button, the **MODE** button on the remote control, the **PHONE** button on the unit or by using the **ACCEPT** option in the menu.

Rejecting an incoming call

Incoming calls can be rejected by pressing either the call reject button, the **CD** or **AM/FM** buttons on the unit, or by using the **REJECT** option in the menu.

Receiving a second incoming call

Note: The second incoming call function must be activated in your phone.

If there is an incoming call, whilst there is an ongoing call, a beep will be heard and you will have the option to end the active call and to accept the incoming call.

Accepting a second incoming call

Second incoming calls can be accepted by pressing either the call accept button, the **MODE** button on the remote control, the **PHONE** button on the unit or by using the **ACCEPT** option in the menu.

Note: This will cancel the ongoing call.

Rejecting a second incoming call

Second incoming calls can be rejected by pressing either the call reject button, or one of the following buttons on the unit: **CD, AM/FM**.

Muting the microphone

During a call, it is possible to mute the microphone. Whilst muted, confirmation will appear in the display.

DVD navigation units

Press the mute button (symbol of a microphone with a line through it). Press the button once again to turn this function off.

Telephone

CD navigation units

Press the microphone mute button. Press the button once again to turn this function off.

Changing the active phone

Note: *Phones must be bonded to the system before they can be made active.*

Note: *After bonding a phone to the system, this becomes the active phone.*

1. Press the **PHONE** button on the unit.
2. Using the **BT SETTINGS** option in the menu, select the active phone from the list.

Debonding a bonded phone

A bonded phone can be deleted from the system at any time, unless a phone call is in progress.

1. Press the **PHONE** button on the unit.
2. Select the **BT SETTINGS** option in the menu.
3. Select the **DEBOND** option in the menu.
4. Select the phone from the list.

Voice control

PRINCIPLE OF OPERATION

CAUTION

 Using the system with the engine off will drain the battery.

Voice recognition enables operation of the system without the need to divert your attention from the road ahead in order to change settings, or receive feedback from the system.

Whenever you issue one of the defined commands with the system active, the voice recognition system converts your command into a control signal for the system. Your inputs take the form of dialogues or commands. You are guided through these dialogues by announcements or questions.

Please familiarise yourself with the functions of the system before using voice recognition.

Supported commands

The voice control system allows you to control the following vehicle functions:

- Bluetooth phone
- radio
- CD Player/CD Changer
- SD card
- navigation system (DVD units only - refer to separate DVD navigation handbook).

Note: *The voice control system is language specific. If you require the system to operate in another language please consult your dealer.*

System response

As you work through a voice session the system will prompt you with a beep tone each time the system is ready to proceed.

Do not try to give any commands until the beep tone has been heard. The voice control system will repeat each spoken command back to you.

If you are not sure how to continue say "HELP" for assistance or "CANCEL" if you do not wish to continue.

The "HELP" function provides only a subset of the available voice commands. Detailed explanations of all possible voice commands can be found on the following pages.

Voice commands

All voice commands should be given using a natural speaking voice, as if speaking to a passenger or on the phone. Your voice level should be dependant on the surrounding noise level inside or outside the vehicle but do not shout.

USING VOICE CONTROL

System operation

The order and content of the voice controls are given in the following lists. The tables show the sequence of user voice commands and system responses for each available function.

<> indicates a number or stored name tag to be inserted by the user.

Short cuts

There are a number of voice command short cuts available, which allow you to control some vehicle features without having to follow the complete command menu. These are:

- phone: "MOBILE NAME", "DIAL NUMBER", "DIAL NAME", and "REDIAL"
- CD player/CD changer: "DISC" and "TRACK"

Voice control

- radio: "TUNE NAME"
- SD card: "TRACK".

Start communicating with the system

Before you can start talking to the system you first have to press the **VOICE** or **MODE** button for each operation and wait until the system answers with a beep. See **Voice control** (page 27).

Press the button again to cancel the voice session.

Name tag

The name tag functionality can support the phone, audio and navigation features by using the "STORE NAME" function. You can assign name tags to items such as favourite radio stations and personal phone contacts. See **Audio unit commands** (page 186). See **Telephone commands** (page 192). See **Navigation system commands** (page 196).

- Store up to 20 name tags per function.
- The average recording time for each name tag is approximately 2-3 seconds.

AUDIO UNIT COMMANDS

CD Player

You can control playback directly by voice control.

Overview

The overview below shows the available voice commands. The following lists will give further information about the complete command menu in selected examples.

"CD PLAYER"
"HELP"
"PLAY"
"TRACK"*
"SHUFFLE ALL "
"SHUFFLE FOLDER" **
"SHUFFLE OFF"
"REPEAT FOLDER" **
"REPEAT TRACK"
"REPEAT OFF"

* Can be used as a shortcut.

** Only available if the CD contains audio data files like MP3 or WMA.

Voice control

Track

You can choose a track on your CD directly.

Steps	User says	System answer
1	"CD PLAYER"	"CD PLAYER"
2	"TRACK"*	"TRACK NUMBER PLEASE"
3	"<a number between 1 and 99>"**	"TRACK <number>"

* Can be used as a shortcut.

** Additionally, numbers can be spoken as up to four single digits (for example "2", "4", "5" for track 245)

Shuffle all

To set random playback.

Steps	User says	System answer
1	"CD PLAYER"	"CD PLAYER"
2	"SHUFFLE ALL "	

Radio

The radio voice commands support the functionality of the radio and allow you to tune radio stations by voice control.

Overview

The overview below shows the available voice commands. The following lists will give further information about the complete command menu.

" RADIO "
"HELP"
"AM"
"FM"
"TUNE NAME"*
"DELETE NAME"
"DELETE DIRECTORY"

Voice control

"RADIO"
"PLAY DIRECTORY"
"STORE NAME"
"PLAY"

* Can be used as a shortcut.

Tune frequency

This function allows you to tune your radio by voice commands.

Steps	User says	System answer
1	"RADIO"	"RADIO"
2	"AM"	"AM FREQUENCY PLEASE"
	"FM"	"FM FREQUENCY PLEASE"
3	"<frequency>"*	"TUNE <frequency>"

* The frequency may be entered in a variety of ways. Refer below for representative examples.

FM band: 87.5 - 108.0 in increments of 0.1

- "Eighty nine point nine" (89.9)
- "Ninety" (90.0)
- "One hundred point five" (100.5)
- "One zero one point one" (101.1)
- "One zero eight" (108.0)

AM/MW band: 531 - 1602 in increments of 9

AM/LW band: 153 - 281 in increments of 1

- "Five thirty one" (531)
- "Nine hundred" (900)
- "Fourteen forty" (1440)
- "Fifteen zero three" (1503)
- "Ten eighty" (1080)

Store name

If you have tuned a radio station, you can store it with a name in the directory.

Steps	User says	System answer
1	"RADIO"	"RADIO"
2	"STORE NAME"	"STORE NAME" "NAME PLEASE"

Voice control

Steps	User says	System answer
3	"<name>"	"REPEAT NAME PLEASE"
4	"<name>"	"STORING NAME" "<name> STORED"

Tune name

This function allows you to call up a stored radio station.

Steps	User says	System answer
1	"RADIO"	"RADIO"
2	"TUNE NAME" *	"NAME PLEASE"
3	"<name>"	"TUNE <name>"

* Can be used as a shortcut.

Delete name

This function allows you to delete a stored radio station.

Steps	User says	System answer
1	"RADIO"	"RADIO"
2	"DELETE NAME"	"NAME PLEASE"
3	"<name>"	"DELETE <name>" "CONFIRM YES OR NO"
4	"YES"	"DELETED"
	"NO"	"COMMAND CANCELLED"

Play directory

This function allows you to let the system tell you all of the stored radio stations.

Voice control

Steps	User says	System answer
1	"RADIO"	"RADIO"
2	"PLAY DIRECTORY"	"PLAY <DIRECTORY>"

Delete directory

This function allows you to delete all stored radio stations at once.

Steps	User says	System answer
1	"RADIO"	"RADIO"
2	"DELETE DIRECTORY"	"DELETE DIRECTORY" "CONFIRM YES OR NO"
3	"YES"	"RADIO DIRECTORY DELETED"
	"NO"	"COMMAND CANCELLED"

Play

This function switches the audio source to the radio mode.

Steps	User says	System answer
1	"RADIO"	"RADIO"
2	"PLAY"	

Auxiliary input

This function allows you to switch the audio source to the attached auxiliary input device.

Steps	User says	System answer
1	"EXTERNAL DEVICE"	"EXTERNAL DEVICE"
2	"LINE IN"	"LINE IN"

Voice control

SD Card

These voice commands support the functionality of an SD card which has suitable audio files written to it.

Overview

The overview below shows the available voice commands. The following lists will give further information about the complete command menu in selected examples.

"SD CARD"
"HELP"
"PLAY"
"TRACK"*
"SHUFFLE ALL "
"SHUFFLE FOLDER"
"SHUFFLE OFF"
"REPEAT TRACK"
"REPEAT FOLDER"
"REPEAT OFF"

* Can be used as a shortcut.

SD card play

This function allows you to switch the audio source to the SD card audio files.

Steps	User says	System answer
1	"SD CARD"	"SD CARD"
2	"PLAY"	

SD card track

You can choose a track on your SD card directly.

Steps	User says	System answer
1	"SD CARD"	"SD CARD"

Voice control

Steps	User says	System answer
2	"TRACK"*	"TRACK NUMBER PLEASE"
3	"<a number between 1 and 99>"**	"TRACK <number>"

* Can be used as a shortcut.

** Additionally, numbers can be spoken as up to four single digits (for example "2", "4", "5" for track 245).

TELEPHONE COMMANDS

Phone

Your phone system allows you to create an additional phonebook. The stored entries can be dialled by voice control. Phone numbers stored by using voice control are stored on the vehicle system and not in your phone.

Overview

The overview below shows the available voice commands. The following lists will give further information about the complete command menu in selected examples.

"PHONE"
"HELP"
"MOBILE NAME"*
"DIAL NUMBER"*
"DIAL NAME"*
"DELETE NAME"
"DELETE DIRECTORY"
"PLAY DIRECTORY"
"STORE NAME"
"REDIAL"*
"ACCEPT CALLS"
"REJECT CALLS"

* Can be used as a shortcut.

Voice control

Create a phonebook

Store name

New entries can be stored with the "STORE NAME" command. This feature can be used to dial a number by calling up the name instead of the full phone number.

Steps	User says	System answer
1	"PHONE"	"PHONE"
2	"STORE NAME"	"STORE NAME" "NAME PLEASE"
3	"<name>"	"REPEAT NAME PLEASE"
4	"<name>"	"STORING NAME" "<name> STORED" "NUMBER PLEASE"
5	"<phone number>"	"<phone number>"
6	"STORE"	"STORING NUMBER" "<phone number>" "NUMBER STORED"

Delete name

Stored names can also be deleted from the directory.

Steps	User says	System answer
1	"PHONE"	"PHONE"
2	"DELETE NAME"	"NAME PLEASE"
3	"<name>"	"DELETE <name>" "CONFIRM YES OR NO"
4	"YES"	"<name> DELETED"
	"NO"	"COMMAND CANCELLED"

Play directory

Use this function to let the system tell you all stored entries.

Voice control

Steps	User says	System answer
1	"PHONE"	"PHONE"
2	"PLAY DIRECTORY"	"PLAY DIRECTORY"

Delete directory

This function allows you to delete all entries in one go.

Steps	User says	System answer
1	"PHONE"	"PHONE"
2	"DELETE DIRECTORY"	"DELETE DIRECTORY" "CONFIRM YES OR NO"
3	"YES"	"DIRECTORY DELETED"
	"NO"	"COMMAND CANCELLED"

Phone functions

Mobile name

This function allows you to access phone numbers stored with a name tag in your mobile phone.

Steps	User says	System answer
1	"PHONE"	"PHONE"
2	"MOBILE NAME"*	"MOBILE NAME" "<phone dependent dialogue>"

* Can be used as a shortcut.

Dial number

Phone numbers can be dialled after giving the name tag voice command.

Steps	User says	System answer
1	"PHONE"	"PHONE"

Voice control

Steps	User says	System answer
2	"DIAL NUMBER"*	"NUMBER PLEASE"
3	"<phone number>"	"<phone number> CONTINUE?"
4	"DIAL"	"DIALLING"
	"CORRECTION"	"<repeat last part of number> CONTINUE?"

* Can be used as a shortcut.

Dial name

Phone numbers can be dialled after giving the name tag voice command.

Steps	User says	System answer
1	"PHONE"	"PHONE"
2	"DIAL NAME"*	"NAME PLEASE"
3	"<name>"	"DIAL <name>" "CONFIRM YES OR NO"
4	"YES"	"DIALLING"
	"NO"	"COMMAND CANCELLED"

* Can be used as a shortcut.

Redial

This function allows you to redial the last dialled phone number.

Steps	User says	System answer
1	"PHONE"	"PHONE"
2	"REDIAL"*	"REDIAL" "CONFIRM YES OR NO"
3	"YES"	"DIALLING"

Voice control

Steps	User says	System answer
	"NO"	"COMMAND CANCELLED"

* Can be used as a shortcut.

DTMF (Tone dialling)

This function transfers spoken numbers into DTMF tones. For example, to make a remote enquiry to your home answering machine or to enter a PIN number etc.

Note: DTMF can only be used during an ongoing call. Press the VOICE button and wait for the system prompt.

Can only be used with vehicles installed with a dedicated VOICE button.

Steps	User says	System answer
1		"NUMBER PLEASE"
2	"<numbers 1 to 9, zero, hash, star>"	

Main settings

Reject calls

Calls can be set to be automatically rejected using voice control.

Steps	User says	System answer
1	"PHONE"	"PHONE"
2	"REJECT CALLS"	"REJECT CALLS"
	"ACCEPT CALLS"*	"ACCEPT CALLS"

* use this command to turn the reject mode off

NAVIGATION SYSTEM COMMANDS

Please refer to your separate Navigation handbook for details of the command menus.

Appendices

TYPE APPROVALS

FCC/INDUSTRY CANADA NOTICE

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC ID: WJLRX-42

IC: 7847A-RX42

Changes or modifications to your device not expressly approved by the party responsible for compliance can void the user's authority to operate the equipment.

RX-42 - declaration of conformity

We, the party responsible for compliance, declare under our sole responsibility that the Handset Integration product RX-42 is in conformity with the provisions of the following Council Directive: 1999/5/EC. A copy of the Declaration of Conformity can be found at:

www.novero.com/declaration_of_conformity

The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Ford Motor Company is under license. Other trademarks and trade names are those of their respective owners.

ELECTROMAGNETIC COMPATIBILITY

WARNINGS



Your vehicle has been tested and certified to European legislations relating to electromagnetic compatibility (2004/104/EC). It is your responsibility to ensure that any equipment you have fitted complies with applicable local legislations. Have any equipment fitted by properly trained technicians.



Radio frequency (RF) transmitter equipment (e.g. cellular telephones, amateur radio transmitters etc.) may only be fitted to your vehicle if they comply with the parameters shown in the table below. There are no special provisions or conditions for installations or use.



Do not mount any transceiver, microphones, speakers, or any other item in the deployment path of the airbag system.




Do not fasten antenna cables to original vehicle wiring, fuel pipes and brake pipes.



Keep antenna and power cables at least 100mm from any electronic modules and airbags.

Appendices



E100566

Frequency Band MHz	Maximum output power Watt (Peak RMS)	Antenna Positions
1 – 30	50 W	1, 2, 3
30 – 54	50 W	1, 2, 3
68 – 87.5	50 W	1, 2, 3
142 – 176	50 W	1, 2, 3
380 – 512	50 W	1, 2, 3
806 – 940	10 W	1, 2, 3
806 – 940	2 W ¹	4, 5
1200 – 1400	10 W	1, 2, 3
1710 – 1885	10 W	1, 2, 3
1710 – 1885	1 W ¹	4, 5
1885 – 2025	10 W	1, 2, 3
1885 – 2025	1 W ¹	4, 5

Appendices

Frequency Band MHz	Maximum output power Watt (Peak RMS)	Antenna Positions
2400 – 2500	0.1 W	Anywhere

¹Only for GSM/3G cellular phones, with a patch antenna installed inside of the front windscreen.

Note: *After the installation of RF transmitters, check for disturbances from and to all electrical equipment in the vehicle, both in the standby and transmit modes.*

Check all electrical equipment:

- with the ignition **ON**
- with the engine running
- during a road test at various speeds.

Check that electromagnetic fields generated inside the vehicle cabin by the transmitter installed do not exceed human exposure limits specified in EU directive 2004/40/EC.

Index

A

A/C	
See: Climate control.....	60
About this handbook.....	5
ABS	
See: Brakes.....	86
ABS driving hints	
See: Hints on driving with ABS.....	86
Accessories	
See: Parts and accessories.....	5
Air conditioning	
See: Climate control.....	60
Air vents.....	60
Alarm.....	24
Principle of operation.....	24
All-wheel drive (AWD).....	85
Automatic mode.....	85
Manual mode.....	85
Appendices.....	197
Arming the alarm.....	24
Category one alarm.....	25
Perimeter alarm.....	24
Arming the engine immobiliser.....	23
Asht-ray.....	73
ASL	
See: Automatic speed limiter (ASL).....	100
Audible warnings and indicators.....	52
Door open warning.....	52
Message centre.....	52
Audio control.....	26
Mode.....	26
Seek.....	26
Volume.....	26
Audio unit commands.....	186
Auxiliary input.....	190
CD Player.....	186
Radio.....	187
SD Card.....	191
Autolamps.....	32
Automatic speed limiter (ASL).....	100
Principle of operation.....	100
Autowipers.....	28
Autowipers.....	28
Auxiliary heater.....	63
General information.....	63
Principle of operation.....	64
Auxiliary input (AUX IN) socket.....	75

Auxiliary power sockets.....	73
AWD	
See: All-wheel drive (AWD).....	85

B

Battery connection points.....	137
Bluetooth setup.....	179
Handling of phones.....	179
Requirements for Bluetooth connection.....	179
Bonnet lock	
See: Opening and closing the bonnet.....	122
Booster cables	
See: Using booster cables.....	136
Booster cushions.....	141
Booster cushion (Group 3).....	141
Booster seat (Group 2).....	141
Bottle holder.....	74
Brake and clutch fluid check.....	129
Brakes.....	86
Principle of operation.....	86
Bulb changing	
See: Changing a bulb.....	34
Bulb specification chart.....	42

C

Car wash	
See: Cleaning the exterior.....	134
Catalytic converter.....	79
Driving with a catalytic converter.....	79

Index

Changing a bulb.....	34	Climate control.....	60
Central brake lamp.....	39	Principle of operation.....	60
Front direction indicators.....	36	Clock.....	72
Front fog lamps.....	36	Vehicles with clock displayed in the audio	
Front interior lamps.....	41	or navigation unit.....	72
Front reading lamps.....	41	Vehicles with high series instrument	
Headlamp main and dipped beam.....	35	cluster.....	72
Number plate lamp.....	40	Vehicles with low series instrument	
Rear interior lamps.....	41	cluster.....	72
Rear lamps.....	38	Coded keys.....	23
Rear side lamps.....	39	Cold weather precautions.....	105
Removing a headlamp.....	35	Convenience features.....	72
Roof position lamps.....	40	Coolant check	
Side lamps.....	36	See: Engine coolant check.....	128
Side marker lamps.....	37	Cruise control.....	98
Side repeaters.....	37	Principle of operation.....	98
Stepwell lamps.....	42	Cruise control	
Changing a fuse.....	110	See: Using cruise control.....	98
Changing a road wheel.....	144	Cup holders.....	73
Front jacking points.....	146		
Installing a road wheel.....	150	D	
Locking wheel nuts.....	144	Diesel particulate filter (DPF).....	77
Rear jacking points.....	147	Regeneration.....	77
Removing a road wheel.....	149	Direction indicators.....	33
Spare wheel.....	144	Disabling the passenger airbag.....	16
Stowing the wheel.....	151	Disabling the passenger airbag.....	16
Vehicle jack.....	145	Enabling the passenger airbag.....	17
Changing the vehicle battery.....	137	Disarming the alarm.....	25
Changing the wiper blades.....	30	Category one alarm.....	25
Checking the wiper blades.....	30	Perimeter alarm.....	25
Child safety.....	138	Disarming the engine immobiliser.....	23
Child safety locks.....	142	DPF	
Left-hand side.....	143	See: Diesel particulate filter (DPF).....	77
Right-hand side.....	143	Draining the fuel filter water trap.....	129
Child seat positioning.....	139	Vehicles with a diesel engine.....	129
Child seats.....	138	Driving hints.....	105
Child restraints for different mass			
groups.....	138	E	
Cigar lighter.....	72	Electric exterior mirrors.....	44
Cleaning the exterior.....	134	Electric windows.....	44
Body paintwork preservation.....	134	Opening the driver window	
Cleaning the chrome trim.....	134	automatically.....	44
Cleaning the headlamps.....	134	Electromagnetic compatibility.....	197
Cleaning the rear window.....	134	Emergency equipment.....	106
Cleaning the interior.....	134	Emergency exit.....	106
Instrument cluster screens, LCD screens,			
radio screens.....	135		
Seat belts.....	134		

Index

Engine compartment overview - 2.2L Duratorq-TDCi (Puma) Diesel.....	124	Fuel consumption.....	80
Engine compartment overview - 2.3L Duratec-HE (M14).....	123	Fuel consumption See: Technical specifications.....	81
Engine compartment overview - 3.2L Duratorq-TDCi (Puma) Diesel/2.4L Duratorq-TDCi (Puma) Diesel.....	126	Fuel cut-off switch.....	107
Engine coolant check.....	128	Resetting the fuel cut-off switch.....	107
Checking the coolant level.....	128	Fuel filler flap.....	80
Topping up.....	128	Fuel filter service indicator check.....	130
Engine immobiliser.....	23	Fuel quality - Diesel.....	79
Principle of operation.....	23	Long-term storage.....	79
Engine oil check.....	127	Fuel quality - Petrol.....	79
Checking the oil level.....	128	Fuse box locations.....	108
Topping up.....	128	Engine junction box.....	109
Engine oil dipstick - 2.2L Duratorq-TDCi (Puma) Diesel.....	127	Passenger junction box.....	109
Engine oil dipstick - 2.3L Duratec-HE (M14).....	127	Pre-fuse box.....	108
Engine oil dipstick - 3.2L Duratorq-TDCi (Puma) Diesel/2.4L Duratorq-TDCi (Puma) Diesel.....	127	Standard relay box.....	108
Exterior mirrors.....	44	Fuses.....	108
Manual folding mirrors.....	44	Fuse specification chart.....	110
		Auxiliary fuses.....	118
		Engine junction box.....	111
		Passenger junction box.....	117
		Pre-fuse box.....	110
		Standard relay box.....	114
F		G	
Fastening the seat belts.....	14	Gauges.....	46
First aid kit.....	106	Engine coolant temperature gauge.....	48
Bus.....	106	Fuel gauge.....	48
Van, Kombi, Chassis cab, Flatbed truck.....	106	High series instrument cluster.....	47
Floor mats.....	75	Low series instrument cluster.....	46
Fog lamp		Odometer, tripmeter and clock.....	48
See: Front fog lamps.....	32		
Front fog lamps.....	32	Gearbox	
Front seats.....	67	See: Transmission.....	85
Adjusting the angle of the seatback.....	68	General information on radio frequencies.....	18
Adjusting the angle of the seat base.....	68		
Adjusting the armrest.....	68		
Adjusting the lumbar support.....	68	H	
Moving the seats backwards and forwards.....	67	Handbrake	
Rotating the seat.....	69	See: Parking brake.....	86
Fuel and refuelling.....	79	Hazard warning flashers.....	33
Technical specifications.....	81	Headlamp levelling.....	33
Fuel burning heater		Head restraints.....	70
See: Auxiliary heater.....	63	Adjusting the head restraint.....	70
		Removing the head restraint.....	71
		Heated seats.....	71

Index

Heated windows and mirrors.....	63
Heated exterior mirrors.....	63
Heated windows.....	63
Heating	
See: Climate control.....	60
Hill launch assist	
See: Using hill start assist.....	89
Hill start assist.....	89
Principle of operation.....	89
Hints on driving with ABS.....	86
HLA	
See: Hill start assist.....	89
See: Using hill start assist.....	89

I

Immobiliser	
See: Engine immobiliser.....	23
Information displays.....	53
General information.....	53
Information messages.....	55
Warning messages.....	55
Inspecting safety system	
components.....	107
Seat belts.....	107
Instruments.....	46
Interior lamps.....	33
Courtesy lamps - Vehicles without interior	
sensors.....	33
Courtesy lamp - Vehicles with interior	
sensors.....	34
Reading lamps.....	34
Vehicles with double locking.....	34
Introduction.....	5
ISOFIX anchor points.....	142
Attaching a child restraint with a top	
tether.....	142

J

Jump starting	
See: Using booster cables.....	136

K

Keys and remote controls.....	18
-------------------------------	----

L

Lighting control.....	31
Headlamp flasher.....	31
Home safe lighting.....	32
Lighting control positions.....	31
Main and dipped beam.....	31
Parking lamps.....	31
Lighting.....	31
Load carriers	
See: Roof racks and load carriers.....	103
Load carrying.....	101
General information.....	101
Load retaining fixtures.....	101
Securing cargo.....	102
Supplementary retaining fixtures.....	103
Locking and unlocking.....	19
Automatic locking.....	21
Automatic re-locking.....	21
Configurable unlocking.....	22
Double locking.....	19
Locking and unlocking the doors with the	
handles.....	20
Locking and unlocking the doors with the	
key.....	19
Locking and unlocking the doors with the	
remote control.....	20
One-stage unlocking.....	22
Slam locking.....	21
Two-stage unlocking.....	22
Zone re-locking.....	22
Locks.....	19

M

Maintenance.....	121
General information.....	121
Technical specifications.....	131
Manual climate control.....	61
Air conditioning.....	62
Air distribution control.....	61
Blower.....	61
Defrosting and demisting the windscreen	
quickly.....	61
Heating the interior quickly.....	61
Recirculated air.....	61
Temperature control.....	61
Ventilation.....	62

Index

Manual transmission.....	85	Power steering fluid check.....	129
All vehicles.....	85	Topping up.....	129
Selecting reverse gear.....	85	Programming the remote control.....	18
Message centre		Q	
See: Information displays.....	53	Quick start.....	6
Mirrors			11
See: Heated windows and mirrors.....	63	Auxiliary power sockets.....	11
See: Windows and mirrors.....	44	Diesel particulate filter (DPF).....	12
N		Engine idle speed after starting.....	11
Navigation system commands.....	196	Information displays.....	9
O		Instrument panel overview - left-hand	
Occupant protection.....	13	drive.....	6
Principle of operation.....	13	Instrument panel overview - right-hand	
Oil check		drive.....	7
See: Engine oil check.....	127	Locking and unlocking.....	10
See: Opening and closing the bonnet.....	122	Manual transmission.....	11
O		Warning lamps and indicators.....	9
Opening and closing the bonnet.....	122	R	
Closing the bonnet.....	122	Rear fog lamps.....	32
Opening the bonnet.....	122	Rear quarter windows.....	45
P		Rear seats.....	69
Parking aid.....	92	Folding a single seatback forwards.....	69
Principle of operation.....	92	Folding the entire seatback forwards.....	69
Parking aid		Removing the bench seats.....	70
See: Using the parking aid.....	92	Rear view camera.....	94
Parking brake.....	86	Principle of operation.....	94
All vehicles.....	86	Rear window wiper and washers.....	29
Parts and accessories.....	5	Intermittent wipe.....	29
Personalised settings.....	57	Rear window washer.....	29
Alarm setting.....	58	Reverse gear wipe.....	29
Clock setting.....	57	Reduced engine performance.....	105
Language setting.....	57	Refuelling.....	80
Message chimes.....	58	Remote control programming	
Overview of the your settings menu		See: Programming the remote control.....	18
displays.....	57	Repairing minor paint damage.....	135
Time format.....	58	Roof racks and load carriers.....	103
Units of measure.....	58	Roof rack.....	103
Your Settings - Exit.....	59	Vehicles with an emergency exit.....	103
Your settings menu.....	57	Running-in.....	105
		Brakes and clutch.....	105
		Engine.....	105
		Tyres.....	105

Index

S

Safety precautions.....	79
Seat belt height adjustment.....	15
Front seat belt.....	15
Rear seat belt.....	15
Seats.....	67
Sitting in the correct position.....	67
Sliding windows.....	45
Snow chains	
See: Using snow chains.....	156
Speed control	
See: Cruise control.....	98
Stability control.....	87
Principle of operation.....	87
Stability control	
See: Using stability control.....	87
Starting a diesel engine.....	77
Cold or hot engine.....	77
Starting a petrol engine.....	76
Cold or hot engine.....	76
Engine idle speed after starting.....	77
Flooded engine.....	76
Starting the engine.....	76
General information.....	76
Status after a collision.....	107
Steering wheel.....	26
Stepwell lamps.....	34
Storage compartments.....	74
Front storage compartment.....	74
Overhead storage compartment.....	74
Switching off the engine.....	78
Vehicles with a turbocharger.....	78
Symbols glossary.....	5
Symbols in this handbook.....	5
Symbols on your vehicle.....	5

T

Technical specifications.....	165
Technical specifications.....	165
Telephone commands.....	192
Create a phonebook.....	193
Main settings.....	196
Phone.....	192
Phone functions.....	194
Telephone controls.....	180
Remote control.....	180

Telephone setup.....	178
Bond another Bluetooth phone.....	179
Making a phone an active phone.....	179
Phonebook.....	178
Phonebook categories.....	178
Telephone.....	178
General information.....	178
Telephone	
See: Using the telephone - Vehicles With:	
Navigation System.....	183
See: Using the telephone - Vehicles Without:	
Navigation System.....	180
Ticket holders.....	72
Towing a trailer.....	104
Steep gradients.....	104
Towing points.....	119
Towing the vehicle on four wheels -	
AWD.....	120
Towing the vehicle on four wheels.....	119
All vehicles.....	119
Vehicles with automatic	
transmission.....	119
Towing.....	104
Traction control.....	91
Principle of operation.....	91
Traction control	
See: Using traction control.....	91
Transmission.....	85
Type approvals.....	197
FCC/INDUSTRY CANADA NOTICE.....	197
RX-42 - declaration of conformity.....	197
Tyre care.....	155
Tyre pressures	
See: Technical specifications.....	157
Tyre repair kit.....	151
Checking the tyre pressure.....	155
General information.....	151
Inflating the tyre.....	152
Using the tyre repair kit.....	152
Tyres	
See: Wheels and tyres.....	144

U

Using booster cables.....	136
To connect the booster cables.....	136
To start the engine.....	136

Index

Using cruise control.....	98
Cancelling the set speed.....	99
Changing the set speed.....	98
Resuming the set speed.....	99
Setting a speed.....	98
Switching cruise control off.....	99
Switching cruise control on.....	98
Using hill start assist.....	89
Activating the system.....	89
Deactivating the system.....	89
Disabling the system.....	90
Using seat belts during pregnancy.....	16
Using snow chains.....	156
All vehicles.....	156
Front wheel drive vehicles.....	156
Vehicles with stability control (ESP).....	156
Using stability control.....	87
Using the parking aid.....	92
Using the rear view camera.....	94
Activating the rear view camera.....	95
Deactivating the rear view camera.....	97
Switching the rear view camera on and off.....	97
Using the display.....	95
Using the telephone - Vehicles With:	
Navigation System.....	183
Changing the active phone.....	184
Debonding a bonded phone.....	184
Making a call.....	183
Muting the microphone.....	183
Receiving an incoming call.....	183
Receiving a second incoming call.....	183
Using the telephone - Vehicles Without:	
Navigation System.....	180
Changing the active phone.....	182
Debonding a bonded phone.....	182
Debonding a bonded phone - Sony radio.....	182
Making a call.....	180
Muting the microphone.....	182
Receiving an incoming call.....	181
Receiving a second incoming call.....	181
Using traction control.....	91
Using voice control.....	185
Name tag.....	186
System operation.....	185
Using winter tyres.....	156

V

Vehicle battery.....	136
Vehicle care.....	134
Vehicle identification number (VIN).....	164
Vehicle identification plate.....	164
Vehicle identification.....	164
Vehicle recovery.....	119
Ventilation	
See: Climate control.....	60
Vents	
See: Air vents.....	60
VIN	
See: Vehicle identification number (VIN).....	164
Voice control.....	27
Principle of operation.....	185

W

Warning lamps and indicators.....	48
ABS warning lamp.....	49
Airbag warning lamp.....	49
Brake pad wear warning lamp.....	49
Brake system lamp.....	49
Cruise control indicator.....	49
Direction indicator.....	50
Door open warning lamp.....	50
Engine warning lamps.....	50
Front fog lamp indicator.....	50
Glow plug indicator.....	50
Headlamp indicator.....	50
High series instrument cluster.....	49
Hill start assist indicator.....	50
Ignition warning lamp.....	50
Low fuel level warning lamp.....	51
Low series instrument cluster.....	48
Main beam indicator.....	51
Message indicator.....	51
Oil pressure warning lamp.....	51
Rear fog lamp indicator.....	51
Service interval indicator.....	51
Shift indicator.....	51
Stability control (ESP) and traction control warning lamp.....	51
Water-in-fuel indicator.....	52
Warning triangle.....	106

Index

Washer fluid check.....	131
Washers	
See: Wipers and washers.....	28
Washing	
See: Cleaning the exterior.....	134
Wheels and tyres.....	144
General information.....	144
Technical specifications.....	157
Windows and mirrors.....	44
Windscreen washers.....	29
Windscreen wipers.....	28
Intermittent wipe.....	28
Winter tyres	
See: Using winter tyres.....	156
Wipers and washers.....	28



Feel the difference

